



Color Matching System formulations

MARCH 2012 / MARZO 2012

Printop's Atomix® mixing ink formulations produce only simulations for Pantone Colors. The accuracy of the colors may be affected by the ink film thickness, opacity, metamerism and pigment selection. Pantone Inc. assumes no responsibility for formula accuracy. PANTONE® and other Pantone, Inc. trademarks are the property of Pantone, Inc. Portions © Pantone, Inc., 2007

AST PC Atomix[®] formulas

Printing & Test Parameters used for Formulations

Substrate: 100% cotton - 1 layer

Mesh N°:

90 (h/cm) - 230(th/in)

Polyester Monofilament

Mesh tension: 20N

Off-Contact: 2mm

Emulsion: Direct

Squeegee:

Type: Polyurethane

Hardness: 70D

Profile: Square

Substrate: 100% cotton

Curing: Dryer: 160° C (320°F)/ 60s

Light source: Fluorescent tubes 6500K - Standardized D65 Daylight Source

PANTONE® Yellow 012 C

1	P7218	AST PC Atomix Opaque Mix Base	82.190
2	P8410	AST PC Atomix Fluo Yellow DTA FF	0.800
3	P7208	AST PC Atomix Lemon MX	17.010
TOTAL			100%

PANTONE® Hexachrome Yellow C

1	P7218	AST PC Atomix Opaque Mix Base	81.080
2	P7217	AST PC Atomix White	2.520
3	P8410	AST PC Atomix Fluo Yellow DTA FF	8.400
4	P7208	AST PC Atomix Lemon MX	8.000
TOTAL			100%

PANTONE® Hexachrome Orange C

1	P7218	AST PC Atomix Opaque Mix Base	75.100
2	P8412	AST PC Atomix Fluo Orange DTA FF	7.750
3	P7207	AST PC Atomix Red MX	0.450
4	P7208	AST PC Atomix Lemon MX	16.700
TOTAL			100%

PANTONE® Hexachrome Magenta C

1	P7218	AST PC Atomix Opaque Mix Base	72.950
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	27.000
3	P7206	AST PC Atomix Violet	0.050
TOTAL			100%

PANTONE® Hexachrome Cyan C

1	P7218	AST PC Atomix Opaque Mix Base	98.650
2	P8410	AST PC Atomix Fluo Yellow DTA FF	0.200
3	P7204	AST PC Atomix Blue B	1.150
TOTAL			100%

PANTONE® Hexachrome Black C

1	P7218	AST PC Atomix Opaque Mix Base	83.680
2	P7199	AST PC Atomix Black	12.000
3	P7206	AST PC Atomix Violet	0.320
4	P7203	AST PC Atomix Blue 1500	2.000
5	P8258	AST PC Atomix Yellow II	2.000
TOTAL			100%

PANTONE® Hexachrome Green C

1	P7218	AST PC Atomix Opaque Mix Base	84.780
2	P7217	AST PC Atomix White	2.360
3	P8410	AST PC Atomix Fluo Yellow DTA FF	8.600
4	P7200	AST PC Atomix Green	2.400
5	P7208	AST PC Atomix Lemon MX	1.860
TOTAL			100%

PANTONE® 100 C

1	P7218	AST PC Atomix Opaque Mix Base	81.000
2	P7217	AST PC Atomix White	14.600
3	P8410	AST PC Atomix Fluo Yellow DTA FF	1.500
4	P7213	AST PC Atomix Blue RQ	0.100
5	P7208	AST PC Atomix Lemon MX	2.800
TOTAL			100%

PANTONE® 101 C

1	P7218	AST PC Atomix Opaque Mix Base	76.140
2	P7217	AST PC Atomix White	13.520
3	P8410	AST PC Atomix Fluo Yellow DTA FF	6.800
4	P7213	AST PC Atomix Blue RQ	0.020
5	P7208	AST PC Atomix Lemon MX	3.520
TOTAL			100%

PANTONE® 102 C

1	P7218	AST PC Atomix Opaque Mix Base	64.820
2	P7217	AST PC Atomix White	2.900
3	P8410	AST PC Atomix Fluo Yellow DTA FF	23.000
4	P7208	AST PC Atomix Lemon MX	9.280
TOTAL			100%

PANTONE® Yellow C

1	P7218	AST PC Atomix Opaque Mix Base	83.400
2	P7217	AST PC Atomix White	1.800
3	P8410	AST PC Atomix Fluo Yellow DTA FF	8.000
4	P7208	AST PC Atomix Lemon MX	6.800
TOTAL			100%

PANTONE® 103 C

1	P7218	AST PC Atomix Opaque Mix Base	68.350
2	P7217	AST PC Atomix White	6.000
3	P7199	AST PC Atomix Black	0.150
4	P8258	AST PC Atomix Yellow II	1.500
5	P7208	AST PC Atomix Lemon MX	24.000
TOTAL			100%

PANTONE® 104 C

1	P7218	AST PC Atomix Opaque Mix Base	67.830
2	P7217	AST PC Atomix White	5.000
3	P7199	AST PC Atomix Black	0.270
4	P8258	AST PC Atomix Yellow II	2.100
5	P7208	AST PC Atomix Lemon MX	24.800
TOTAL			100%

PANTONE® 105 C

1	P7218	AST PC Atomix Opaque Mix Base	77.680
2	P7217	AST PC Atomix White	3.900
3	P7199	AST PC Atomix Black	0.720
4	P8258	AST PC Atomix Yellow II	7.400
5	P7208	AST PC Atomix Lemon MX	10.300
TOTAL			100%

PANTONE® 106 C

1	P7218	AST PC Atomix Opaque Mix Base	87.000
2	P7217	AST PC Atomix White	10.400
3	P8258	AST PC Atomix Yellow II	0.200
4	P7208	AST PC Atomix Lemon MX	2.400
TOTAL			100%

PANTONE® 107 C

1	P7218	AST PC Atomix Opaque Mix Base	76.900
2	P7217	AST PC Atomix White	14.600
3	P7208	AST PC Atomix Lemon MX	8.500
TOTAL			100%

PANTONE® 108 C

1	P7218	AST PC Atomix Opaque Mix Base	83.720
2	P7217	AST PC Atomix White	6.200
3	P8412	AST PC Atomix Fluo Orange DTA FF	0.080
4	P7208	AST PC Atomix Lemon MX	10.000
TOTAL			100%

PANTONE® 109 C

1	P7218	AST PC Atomix Opaque Mix Base	83.940
2	P7217	AST PC Atomix White	6.600
3	P8258	AST PC Atomix Yellow II	0.680
4	P7208	AST PC Atomix Lemon MX	8.780
TOTAL			100%

PANTONE® 110 C

1	P7218	AST PC Atomix Opaque Mix Base	79.890
2	P7217	AST PC Atomix White	4.620
3	P7199	AST PC Atomix Black	0.090
4	P8258	AST PC Atomix Yellow II	8.470
5	P7208	AST PC Atomix Lemon MX	6.930
TOTAL			100%

PANTONE® 111 C

1	P7218	AST PC Atomix Opaque Mix Base	75.060
2	P7217	AST PC Atomix White	3.700
3	P7199	AST PC Atomix Black	0.240
4	P8258	AST PC Atomix Yellow II	8.000
5	P7208	AST PC Atomix Lemon MX	13.000
TOTAL			100%

PANTONE® 112 C

1	P7218	AST PC Atomix Opaque Mix Base	73.810
2	P7217	AST PC Atomix White	5.600
3	P7199	AST PC Atomix Black	0.490
4	P8258	AST PC Atomix Yellow II	8.200
5	P7208	AST PC Atomix Lemon MX	11.900
TOTAL			100%

PANTONE® 113 C

1	P7218	AST PC Atomix Opaque Mix Base	70.050
2	P7217	AST PC Atomix White	24.650
3	P8258	AST PC Atomix Yellow II	0.400
4	P7208	AST PC Atomix Lemon MX	4.900
TOTAL			100%

PANTONE® 114 C

1	P7218	AST PC Atomix Opaque Mix Base	73.860
2	P7217	AST PC Atomix White	20.400
3	P8258	AST PC Atomix Yellow II	0.500
4	P7208	AST PC Atomix Lemon MX	5.240
TOTAL			100%

PANTONE® 115 C

1	P7218	AST PC Atomix Opaque Mix Base	77.800
2	P7217	AST PC Atomix White	16.000
3	P8258	AST PC Atomix Yellow II	0.800
4	P7208	AST PC Atomix Lemon MX	5.400
TOTAL			100%

PANTONE® 116 C

1	P7218	AST PC Atomix Opaque Mix Base	67.040
2	P7217	AST PC Atomix White	10.140
3	P8258	AST PC Atomix Yellow II	4.510
4	P7208	AST PC Atomix Lemon MX	18.310
TOTAL			100%

PANTONE® 117 C

1	P7218	AST PC Atomix Opaque Mix Base	84.640
2	P7217	AST PC Atomix White	2.800
3	P7199	AST PC Atomix Black	0.160
4	P8258	AST PC Atomix Yellow II	8.400
5	P7208	AST PC Atomix Lemon MX	4.000
TOTAL			100%

PANTONE® 118 C

1	P7218	AST PC Atomix Opaque Mix Base	72.400
2	P7217	AST PC Atomix White	4.400
3	P7199	AST PC Atomix Black	0.280
4	P8258	AST PC Atomix Yellow II	14.400
5	P7208	AST PC Atomix Lemon MX	8.520
TOTAL			100%

PANTONE® 119 C

1	P7218	AST PC Atomix Opaque Mix Base	87.700
2	P7217	AST PC Atomix White	1.400
3	P7199	AST PC Atomix Black	0.500
4	P8258	AST PC Atomix Yellow II	5.600
5	P7208	AST PC Atomix Lemon MX	4.800
TOTAL			100%

PANTONE® 120 C

1	P7218	AST PC Atomix Opaque Mix Base	77.790
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.010
4	P8258	AST PC Atomix Yellow II	2.200
TOTAL			100%

PANTONE® 121 C

1	P7218	AST PC Atomix Opaque Mix Base	79.390
2	P7217	AST PC Atomix White	18.000
3	P7199	AST PC Atomix Black	0.010
4	P8258	AST PC Atomix Yellow II	2.600
TOTAL			100%

PANTONE® 122 C

1	P7218	AST PC Atomix Opaque Mix Base	80.230
2	P7217	AST PC Atomix White	14.000
3	P8410	AST PC Atomix Fluo Yellow DTA FF	2.600
4	P7199	AST PC Atomix Black	0.020
5	P8258	AST PC Atomix Yellow II	3.150
TOTAL			100%

PANTONE® 123 C

1	P7218	AST PC Atomix Opaque Mix Base	77.310
2	P7217	AST PC Atomix White	12.540
3	P7199	AST PC Atomix Black	0.020
4	P8258	AST PC Atomix Yellow II	8.440
5	P7208	AST PC Atomix Lemon MX	1.690
TOTAL			100%

PANTONE® 124 C

1	P7218	AST PC Atomix Opaque Mix Base	74.590
2	P7217	AST PC Atomix White	8.440
3	P7199	AST PC Atomix Black	0.080
4	P8258	AST PC Atomix Yellow II	16.890
TOTAL			100%

PANTONE® 125 C

1	P7218	AST PC Atomix Opaque Mix Base	84.820
2	P7217	AST PC Atomix White	3.190
3	P7199	AST PC Atomix Black	0.210
4	P7207	AST PC Atomix Red MX	0.040
5	P8258	AST PC Atomix Yellow II	11.740
TOTAL			100%

PANTONE® 126 C

1	P7218	AST PC Atomix Opaque Mix Base	84.550
2	P7199	AST PC Atomix Black	0.230
3	P8258	AST PC Atomix Yellow II	11.270
4	P7208	AST PC Atomix Lemon MX	3.950
TOTAL			100%

PANTONE® 1205 C

1	P7218	AST PC Atomix Opaque Mix Base	86.450
2	P7217	AST PC Atomix White	13.000
3	P7207	AST PC Atomix Red MX	0.020
4	P7208	AST PC Atomix Lemon MX	0.530
TOTAL			100%

PANTONE® 1215 C

1	P7218	AST PC Atomix Opaque Mix Base	88.120
2	P7217	AST PC Atomix White	10.800
3	P7207	AST PC Atomix Red MX	0.030
4	P7208	AST PC Atomix Lemon MX	1.050
TOTAL			100%

PANTONE® 1225 C

1	P7218	AST PC Atomix Opaque Mix Base	70.470
2	P7217	AST PC Atomix White	17.000
3	P7207	AST PC Atomix Red MX	0.130
4	P7208	AST PC Atomix Lemon MX	12.400
TOTAL			100%

PANTONE® 1235 C

1	P7218	AST PC Atomix Opaque Mix Base	78.180
2	P7217	AST PC Atomix White	5.680
3	P7207	AST PC Atomix Red MX	0.140
4	P7208	AST PC Atomix Lemon MX	16.000
TOTAL			100%

PANTONE® 1245 C

1	P7218	AST PC Atomix Opaque Mix Base	83.190
2	P7217	AST PC Atomix White	4.600
3	P7199	AST PC Atomix Black	0.150
4	P7207	AST PC Atomix Red MX	0.060
5	P8258	AST PC Atomix Yellow II	12.000
TOTAL			100%

PANTONE® 1255 C

1	P7218	AST PC Atomix Opaque Mix Base	83.640
2	P7217	AST PC Atomix White	4.000
3	P7199	AST PC Atomix Black	0.320
4	P7207	AST PC Atomix Red MX	0.040
5	P8258	AST PC Atomix Yellow II	12.000
TOTAL			100%

PANTONE® 1265 C

1	P7218	AST PC Atomix Opaque Mix Base	88.480
2	P7217	AST PC Atomix White	2.500
3	P7199	AST PC Atomix Black	0.500
4	P7207	AST PC Atomix Red MX	0.120
5	P8258	AST PC Atomix Yellow II	8.400
TOTAL			100%

PANTONE® 127 C

1	P7218	AST PC Atomix Opaque Mix Base	85.970
2	P7217	AST PC Atomix White	12.000
3	P7199	AST PC Atomix Black	0.030
4	P8258	AST PC Atomix Yellow II	1.300
5	P7208	AST PC Atomix Lemon MX	0.700
TOTAL			100%

PANTONE® 128 C

1	P7218	AST PC Atomix Opaque Mix Base	96.080
2	P7217	AST PC Atomix White	2.600
3	P7199	AST PC Atomix Black	0.020
4	P8258	AST PC Atomix Yellow II	1.300
TOTAL			100%

PANTONE® 129 C

1	P7218	AST PC Atomix Opaque Mix Base	67.570
2	P7217	AST PC Atomix White	19.000
3	P8410	AST PC Atomix Fluo Yellow DTA FF	8.400
4	P7199	AST PC Atomix Black	0.030
5	P8258	AST PC Atomix Yellow II	5.000
TOTAL			100%

PANTONE® 130 C

1	P7218	AST PC Atomix Opaque Mix Base	72.270
2	P7217	AST PC Atomix White	7.500
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	0.180
4	P7199	AST PC Atomix Black	0.050
5	P8258	AST PC Atomix Yellow II	20.000
TOTAL			100%

PANTONE® 131 C

1	P7218	AST PC Atomix Opaque Mix Base	88.270
2	P7217	AST PC Atomix White	1.060
3	P7199	AST PC Atomix Black	0.070
4	P7207	AST PC Atomix Red MX	0.010
5	P8258	AST PC Atomix Yellow II	10.590
TOTAL			100%

PANTONE® 132 C

1	P7218	AST PC Atomix Opaque Mix Base	84.610
2	P7199	AST PC Atomix Black	0.160
3	P8258	AST PC Atomix Yellow II	11.280
4	P7208	AST PC Atomix Lemon MX	3.950
TOTAL			100%

PANTONE® 133 C

1	P7218	AST PC Atomix Opaque Mix Base	81.700
2	P7199	AST PC Atomix Black	0.500
3	P8258	AST PC Atomix Yellow II	17.300
4	P7208	AST PC Atomix Lemon MX	0.500
TOTAL			100%

PANTONE® 134 C

1	P7218	AST PC Atomix Opaque Mix Base	58.600
2	P7217	AST PC Atomix White	38.000
3	P7207	AST PC Atomix Red MX	0.100
4	P7208	AST PC Atomix Lemon MX	3.300
TOTAL			100%

PANTONE® 135 C

1	P7218	AST PC Atomix Opaque Mix Base	60.230
2	P7217	AST PC Atomix White	32.000
3	P7207	AST PC Atomix Red MX	0.170
4	P7208	AST PC Atomix Lemon MX	7.600
TOTAL			100%

PANTONE® 136 C

1	P7218	AST PC Atomix Opaque Mix Base	72.400
2	P7217	AST PC Atomix White	14.800
3	P7207	AST PC Atomix Red MX	0.200
4	P7208	AST PC Atomix Lemon MX	12.600
TOTAL			100%

PANTONE® 137 C

1	P7218	AST PC Atomix Opaque Mix Base	76.600
2	P7217	AST PC Atomix White	3.200
3	P7207	AST PC Atomix Red MX	0.200
4	P7208	AST PC Atomix Lemon MX	20.000
TOTAL			100%

PANTONE® 138 C

1	P7218	AST PC Atomix Opaque Mix Base	84.210
2	P7217	AST PC Atomix White	1.000
3	P7199	AST PC Atomix Black	0.030
4	P7207	AST PC Atomix Red MX	0.160
5	P8258	AST PC Atomix Yellow II	14.600
TOTAL			100%

PANTONE® 139 C

1	P7218	AST PC Atomix Opaque Mix Base	76.040
2	P7217	AST PC Atomix White	0.600
3	P7199	AST PC Atomix Black	0.140
4	P7207	AST PC Atomix Red MX	0.820
5	P7208	AST PC Atomix Lemon MX	22.400
TOTAL			100%

PANTONE® 140 C

1	P7218	AST PC Atomix Opaque Mix Base	72.690
2	P7217	AST PC Atomix White	3.000
3	P7199	AST PC Atomix Black	0.760
4	P7207	AST PC Atomix Red MX	1.650
5	P7208	AST PC Atomix Lemon MX	21.900
TOTAL			100%

PANTONE® 1345 C

1	P7218	AST PC Atomix Opaque Mix Base	81.060
2	P7217	AST PC Atomix White	17.370
3	P7207	AST PC Atomix Red MX	0.110
4	P7208	AST PC Atomix Lemon MX	1.460
TOTAL			100%

PANTONE® 1355 C

1	P7218	AST PC Atomix Opaque Mix Base	79.700
2	P7217	AST PC Atomix White	17.080
3	P7207	AST PC Atomix Red MX	0.180
4	P7208	AST PC Atomix Lemon MX	3.040
TOTAL			100%

PANTONE® 1365 C

1	P7218	AST PC Atomix Opaque Mix Base	77.240
2	P7217	AST PC Atomix White	16.550
3	P7207	AST PC Atomix Red MX	0.330
4	P7208	AST PC Atomix Lemon MX	5.880
TOTAL			100%

PANTONE® 1375 C

1	P7218	AST PC Atomix Opaque Mix Base	75.430
2	P7217	AST PC Atomix White	6.000
3	P8412	AST PC Atomix Fluo Orange DTA FF	3.300
4	P7207	AST PC Atomix Red MX	0.270
5	P7208	AST PC Atomix Lemon MX	15.000
TOTAL			100%

PANTONE® 1385 C

1	P7218	AST PC Atomix Opaque Mix Base	80.220
2	P7217	AST PC Atomix White	2.380
3	P7199	AST PC Atomix Black	0.060
4	P7207	AST PC Atomix Red MX	0.320
5	P8258	AST PC Atomix Yellow II	17.020
TOTAL			100%

PANTONE® 1395 C

1	P7218	AST PC Atomix Opaque Mix Base	84.890
2	P7217	AST PC Atomix White	0.800
3	P7199	AST PC Atomix Black	0.240
4	P7207	AST PC Atomix Red MX	0.270
5	P8258	AST PC Atomix Yellow II	13.800
TOTAL			100%

PANTONE® 1405 C

1	P7218	AST PC Atomix Opaque Mix Base	73.290
2	P7199	AST PC Atomix Black	0.690
3	P7207	AST PC Atomix Red MX	1.720
4	P8258	AST PC Atomix Yellow II	2.300
5	P7208	AST PC Atomix Lemon MX	22.000
TOTAL			100%

PANTONE® 141 C

1	P7218	AST PC Atomix Opaque Mix Base	72.530
2	P7217	AST PC Atomix White	23.500
3	P7199	AST PC Atomix Black	0.020
4	P7207	AST PC Atomix Red MX	0.100
5	P7208	AST PC Atomix Lemon MX	3.850
TOTAL			100%

PANTONE® 142 C

1	P7218	AST PC Atomix Opaque Mix Base	62.010
2	P7217	AST PC Atomix White	26.000
3	P7199	AST PC Atomix Black	0.010
4	P7207	AST PC Atomix Red MX	0.180
5	P7208	AST PC Atomix Lemon MX	11.800
TOTAL			100%

PANTONE® 143 C

1	P7218	AST PC Atomix Opaque Mix Base	65.370
2	P7217	AST PC Atomix White	18.000
3	P7207	AST PC Atomix Red MX	0.230
4	P7208	AST PC Atomix Lemon MX	16.400
TOTAL			100%

PANTONE® 144 C

1	P7218	AST PC Atomix Opaque Mix Base	84.460
2	P7217	AST PC Atomix White	0.800
3	P7199	AST PC Atomix Black	0.030
4	P7207	AST PC Atomix Red MX	0.160
5	P8258	AST PC Atomix Yellow II	14.550
TOTAL			100%

PANTONE® 145 C

1	P7218	AST PC Atomix Opaque Mix Base	84.990
2	P7217	AST PC Atomix White	0.800
3	P7199	AST PC Atomix Black	0.090
4	P7207	AST PC Atomix Red MX	0.120
5	P8258	AST PC Atomix Yellow II	14.000
TOTAL			100%

PANTONE® 146 C

1	P7218	AST PC Atomix Opaque Mix Base	84.970
2	P7217	AST PC Atomix White	0.800
3	P7199	AST PC Atomix Black	0.210
4	P7207	AST PC Atomix Red MX	0.220
5	P8258	AST PC Atomix Yellow II	13.800
TOTAL			100%

PANTONE® 147 C

1	P7218	AST PC Atomix Opaque Mix Base	88.810
2	P7217	AST PC Atomix White	1.800
3	P7199	AST PC Atomix Black	0.760
4	P7207	AST PC Atomix Red MX	0.230
5	P8258	AST PC Atomix Yellow II	8.400
TOTAL			100%

PANTONE® 148 C

1	P7218	AST PC Atomix Opaque Mix Base	81.030
2	P7217	AST PC Atomix White	17.370
3	P7207	AST PC Atomix Red MX	0.140
4	P7208	AST PC Atomix Lemon MX	1.460
TOTAL			100%

PANTONE® 149 C

1	P7218	AST PC Atomix Opaque Mix Base	80.330
2	P7217	AST PC Atomix White	17.370
3	P7207	AST PC Atomix Red MX	0.230
4	P7208	AST PC Atomix Lemon MX	2.070
TOTAL			100%

PANTONE® 150 C

1	P7218	AST PC Atomix Opaque Mix Base	84.720
2	P7217	AST PC Atomix White	9.930
3	P7207	AST PC Atomix Red MX	0.380
4	P7208	AST PC Atomix Lemon MX	4.970
TOTAL			100%

PANTONE® 151 C

1	P7218	AST PC Atomix Opaque Mix Base	73.150
2	P7217	AST PC Atomix White	0.600
3	P8412	AST PC Atomix Fluo Orange DTA FF	2.000
4	P7211	AST PC Atomix Magenta MX	0.250
5	P8258	AST PC Atomix Yellow II	24.000
TOTAL			100%

PANTONE® 152 C

1	P7218	AST PC Atomix Opaque Mix Base	68.330
2	P7217	AST PC Atomix White	1.900
3	P8412	AST PC Atomix Fluo Orange DTA FF	10.000
4	P7206	AST PC Atomix Violet	0.070
5	P7207	AST PC Atomix Red MX	0.700
6	P7208	AST PC Atomix Lemon MX	19.000
TOTAL			100%

PANTONE® 153 C

1	P7218	AST PC Atomix Opaque Mix Base	84.900
2	P7217	AST PC Atomix White	1.100
3	P7199	AST PC Atomix Black	0.200
4	P7207	AST PC Atomix Red MX	0.500
5	P8258	AST PC Atomix Yellow II	13.300
TOTAL			100%

PANTONE® 154 C

1	P7218	AST PC Atomix Opaque Mix Base	89.350
2	P7217	AST PC Atomix White	0.900
3	P7199	AST PC Atomix Black	0.200
4	P7211	AST PC Atomix Magenta MX	0.550
5	P8258	AST PC Atomix Yellow II	9.000
TOTAL			100%

PANTONE® 1485 C

1	P7218	AST PC Atomix Opaque Mix Base	75.480
2	P7217	AST PC Atomix White	17.400
3	P8412	AST PC Atomix Fluo Orange DTA FF	3.600
4	P7211	AST PC Atomix Magenta MX	0.320
5	P7208	AST PC Atomix Lemon MX	3.200
TOTAL			100%

PANTONE® 1495 C

1	P7218	AST PC Atomix Opaque Mix Base	66.320
2	P7217	AST PC Atomix White	14.000
3	P8412	AST PC Atomix Fluo Orange DTA FF	8.760
4	P7207	AST PC Atomix Red MX	0.240
5	P8258	AST PC Atomix Yellow II	10.680
TOTAL			100%

PANTONE® 1505 C

1	P7218	AST PC Atomix Opaque Mix Base	72.200
2	P7217	AST PC Atomix White	1.600
3	P8412	AST PC Atomix Fluo Orange DTA FF	7.200
4	P7207	AST PC Atomix Red MX	0.200
5	P8258	AST PC Atomix Yellow II	18.800
TOTAL			100%

PANTONE® Orange 021 C

1	P7218	AST PC Atomix Opaque Mix Base	67.340
2	P7217	AST PC Atomix White	3.800
3	P8412	AST PC Atomix Fluo Orange DTA FF	12.000
4	P7207	AST PC Atomix Red MX	0.460
5	P8258	AST PC Atomix Yellow II	16.400
TOTAL			100%

PANTONE® 1525 C

1	P7218	AST PC Atomix Opaque Mix Base	88.140
2	P7217	AST PC Atomix White	0.900
3	P7199	AST PC Atomix Black	0.080
4	P7207	AST PC Atomix Red MX	0.880
5	P8258	AST PC Atomix Yellow II	10.000
TOTAL			100%

PANTONE® 1535 C

1	P7218	AST PC Atomix Opaque Mix Base	83.980
2	P7217	AST PC Atomix White	1.400
3	P7199	AST PC Atomix Black	0.270
4	P7207	AST PC Atomix Red MX	1.350
5	P8258	AST PC Atomix Yellow II	13.000
TOTAL			100%

PANTONE® 1545 C

1	P7218	AST PC Atomix Opaque Mix Base	82.300
2	P7217	AST PC Atomix White	1.100
3	P7199	AST PC Atomix Black	0.800
4	P7207	AST PC Atomix Red MX	1.800
5	P8258	AST PC Atomix Yellow II	14.000
TOTAL			100%

PANTONE® 155 C

1	P7218	AST PC Atomix Opaque Mix Base	81.300
2	P7217	AST PC Atomix White	18.000
3	P7206	AST PC Atomix Violet	0.010
4	P7211	AST PC Atomix Magenta MX	0.040
5	P8258	AST PC Atomix Yellow II	0.650
TOTAL			100%

PANTONE® 156 C

1	P7218	AST PC Atomix Opaque Mix Base	89.240
2	P7217	AST PC Atomix White	9.300
3	P7207	AST PC Atomix Red MX	0.160
4	P7208	AST PC Atomix Lemon MX	1.300
TOTAL			100%

PANTONE® 157 C

1	P7218	AST PC Atomix Opaque Mix Base	82.900
2	P7217	AST PC Atomix White	10.800
3	P7199	AST PC Atomix Black	0.020
4	P7207	AST PC Atomix Red MX	0.280
5	P8258	AST PC Atomix Yellow II	6.000
TOTAL			100%

PANTONE® 158 C

1	P7218	AST PC Atomix Opaque Mix Base	75.570
2	P7217	AST PC Atomix White	2.700
3	P7213	AST PC Atomix Blue RQ	0.030
4	P7207	AST PC Atomix Red MX	0.400
5	P8258	AST PC Atomix Yellow II	21.300
TOTAL			100%

PANTONE® 159 C

1	P7218	AST PC Atomix Opaque Mix Base	83.160
2	P7217	AST PC Atomix White	2.200
3	P7199	AST PC Atomix Black	0.040
4	P7207	AST PC Atomix Red MX	0.600
5	P8258	AST PC Atomix Yellow II	14.000
TOTAL			100%

PANTONE® 160 C

1	P7218	AST PC Atomix Opaque Mix Base	84.580
2	P7217	AST PC Atomix White	1.400
3	P7199	AST PC Atomix Black	0.170
4	P7207	AST PC Atomix Red MX	0.850
5	P8258	AST PC Atomix Yellow II	13.000
TOTAL			100%

PANTONE® 161 C

1	P7218	AST PC Atomix Opaque Mix Base	80.150
2	P7217	AST PC Atomix White	1.900
3	P7199	AST PC Atomix Black	0.750
4	P7207	AST PC Atomix Red MX	1.200
5	P8258	AST PC Atomix Yellow II	16.000
TOTAL			100%

PANTONE® 1555 C

1	P7218	AST PC Atomix Opaque Mix Base	85.360
2	P7217	AST PC Atomix White	13.660
3	P7207	AST PC Atomix Red MX	0.220
4	P8258	AST PC Atomix Yellow II	0.760
TOTAL			100%

PANTONE® 1565 C

1	P7218	AST PC Atomix Opaque Mix Base	83.400
2	P7217	AST PC Atomix White	13.300
3	P7211	AST PC Atomix Magenta MX	0.600
4	P8258	AST PC Atomix Yellow II	2.700
TOTAL			100%

PANTONE® 1575 C

1	P7218	AST PC Atomix Opaque Mix Base	69.300
2	P7217	AST PC Atomix White	12.200
3	P8412	AST PC Atomix Fluo Orange DTA FF	6.500
4	P7211	AST PC Atomix Magenta MX	0.800
5	P8258	AST PC Atomix Yellow II	11.200
TOTAL			100%

PANTONE® 1585 C

1	P7218	AST PC Atomix Opaque Mix Base	76.700
2	P7217	AST PC Atomix White	4.400
3	P8412	AST PC Atomix Fluo Orange DTA FF	7.000
4	P7207	AST PC Atomix Red MX	0.600
5	P8258	AST PC Atomix Yellow II	11.300
TOTAL			100%

PANTONE® 1595 C

1	P7218	AST PC Atomix Opaque Mix Base	84.740
2	P7217	AST PC Atomix White	3.390
3	P7199	AST PC Atomix Black	0.030
4	P7207	AST PC Atomix Red MX	0.830
5	P8258	AST PC Atomix Yellow II	11.010
TOTAL			100%

PANTONE® 1605 C

1	P7218	AST PC Atomix Opaque Mix Base	84.260
2	P7217	AST PC Atomix White	2.110
3	P7199	AST PC Atomix Black	0.160
4	P7207	AST PC Atomix Red MX	0.820
5	P8258	AST PC Atomix Yellow II	12.650
TOTAL			100%

PANTONE® 1615 C

1	P7218	AST PC Atomix Opaque Mix Base	83.670
2	P7217	AST PC Atomix White	2.090
3	P7199	AST PC Atomix Black	0.310
4	P7207	AST PC Atomix Red MX	1.380
5	P8258	AST PC Atomix Yellow II	12.550
TOTAL			100%

PANTONE® 162 C

1	P7218	AST PC Atomix Opaque Mix Base	80.950
2	P7217	AST PC Atomix White	17.000
3	P8412	AST PC Atomix Fluo Orange DTA FF	1.400
4	P7211	AST PC Atomix Magenta MX	0.250
5	P7208	AST PC Atomix Lemon MX	0.400
TOTAL			100%

PANTONE® 163 C

1	P7218	AST PC Atomix Opaque Mix Base	86.890
2	P7217	AST PC Atomix White	4.100
3	P8412	AST PC Atomix Fluo Orange DTA FF	6.650
4	P7211	AST PC Atomix Magenta MX	0.440
5	P7208	AST PC Atomix Lemon MX	1.920
TOTAL			100%

PANTONE® 164 C

1	P7218	AST PC Atomix Opaque Mix Base	63.080
2	P7217	AST PC Atomix White	15.200
3	P8412	AST PC Atomix Fluo Orange DTA FF	14.400
4	P7207	AST PC Atomix Red MX	0.920
5	P7208	AST PC Atomix Lemon MX	6.400
TOTAL			100%

PANTONE® 165 C

1	P7218	AST PC Atomix Opaque Mix Base	72.800
2	P7217	AST PC Atomix White	4.800
3	P8412	AST PC Atomix Fluo Orange DTA FF	7.500
4	P7207	AST PC Atomix Red MX	0.700
5	P8258	AST PC Atomix Yellow II	14.200
TOTAL			100%

PANTONE® 166 C

1	P7218	AST PC Atomix Opaque Mix Base	88.580
2	P7217	AST PC Atomix White	1.600
3	P7199	AST PC Atomix Black	0.010
4	P7207	AST PC Atomix Red MX	0.810
5	P8258	AST PC Atomix Yellow II	9.000
TOTAL			100%

PANTONE® 1665 C

1	P7218	AST PC Atomix Opaque Mix Base	84.520
2	P7217	AST PC Atomix White	1.600
3	P7213	AST PC Atomix Blue RQ	0.030
4	P7207	AST PC Atomix Red MX	1.150
5	P8258	AST PC Atomix Yellow II	12.700
TOTAL			100%

PANTONE® 167 C

1	P7218	AST PC Atomix Opaque Mix Base	87.900
2	P7217	AST PC Atomix White	1.100
3	P7199	AST PC Atomix Black	0.080
4	P7207	AST PC Atomix Red MX	0.920
5	P8258	AST PC Atomix Yellow II	10.000
TOTAL			100%

PANTONE® 1675 C

1	P7218	AST PC Atomix Opaque Mix Base	79.650
2	P7217	AST PC Atomix White	3.400
3	P7199	AST PC Atomix Black	0.150
4	P7207	AST PC Atomix Red MX	2.200
5	P8258	AST PC Atomix Yellow II	14.600
TOTAL			100%

PANTONE® 168 C

1	P7218	AST PC Atomix Opaque Mix Base	83.340
2	P7217	AST PC Atomix White	1.200
3	P7199	AST PC Atomix Black	0.500
4	P7207	AST PC Atomix Red MX	1.960
5	P8258	AST PC Atomix Yellow II	13.000
TOTAL			100%

PANTONE® 1685 C

1	P7218	AST PC Atomix Opaque Mix Base	78.900
2	P7217	AST PC Atomix White	3.400
3	P7199	AST PC Atomix Black	0.400
4	P7207	AST PC Atomix Red MX	2.700
5	P8258	AST PC Atomix Yellow II	14.600
TOTAL			100%

PANTONE® 1625 C

1	P7218	AST PC Atomix Opaque Mix Base	80.360
2	P7217	AST PC Atomix White	14.500
3	P8412	AST PC Atomix Fluo Orange DTA FF	4.000
4	P7211	AST PC Atomix Magenta MX	0.520
5	P7208	AST PC Atomix Lemon MX	0.620
TOTAL			100%

PANTONE® 169 C

1	P7218	AST PC Atomix Opaque Mix Base	76.860
2	P7217	AST PC Atomix White	18.800
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	3.800
4	P7211	AST PC Atomix Magenta MX	0.160
5	P7208	AST PC Atomix Lemon MX	0.380
TOTAL			100%

PANTONE® 1635 C

1	P7218	AST PC Atomix Opaque Mix Base	76.240
2	P7217	AST PC Atomix White	13.000
3	P8412	AST PC Atomix Fluo Orange DTA FF	7.600
4	P7211	AST PC Atomix Magenta MX	1.000
5	P7208	AST PC Atomix Lemon MX	2.160
TOTAL			100%

PANTONE® 170 C

1	P7218	AST PC Atomix Opaque Mix Base	78.200
2	P7217	AST PC Atomix White	9.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	11.000
4	P7211	AST PC Atomix Magenta MX	0.200
5	P7208	AST PC Atomix Lemon MX	1.600
TOTAL			100%

PANTONE® 1645 C

1	P7218	AST PC Atomix Opaque Mix Base	89.020
2	P7217	AST PC Atomix White	1.000
3	P8412	AST PC Atomix Fluo Orange DTA FF	6.520
4	P7211	AST PC Atomix Magenta MX	0.680
5	P7208	AST PC Atomix Lemon MX	2.780
TOTAL			100%

PANTONE® 171 C

1	P7218	AST PC Atomix Opaque Mix Base	75.300
2	P7217	AST PC Atomix White	2.200
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	18.000
4	P7208	AST PC Atomix Lemon MX	4.500
TOTAL			100%

PANTONE® 1655 C

1	P7218	AST PC Atomix Opaque Mix Base	75.270
2	P7217	AST PC Atomix White	2.250
3	P8412	AST PC Atomix Fluo Orange DTA FF	10.400
4	P7207	AST PC Atomix Red MX	0.760
5	P8258	AST PC Atomix Yellow II	11.320
TOTAL			100%

PANTONE® 172 C

1	P7218	AST PC Atomix Opaque Mix Base	72.760
2	P7217	AST PC Atomix White	2.600
3	P8412	AST PC Atomix Fluo Orange DTA FF	14.000
4	P7207	AST PC Atomix Red MX	1.240
5	P8258	AST PC Atomix Yellow II	9.400
TOTAL			100%

PANTONE® 173 C

1	P7218	AST PC Atomix Opaque Mix Base	80.420
2	P7217	AST PC Atomix White	2.800
3	P7199	AST PC Atomix Black	0.030
4	P7207	AST PC Atomix Red MX	2.250
5	P8258	AST PC Atomix Yellow II	14.500
TOTAL			100%

PANTONE® 174 C

1	P7218	AST PC Atomix Opaque Mix Base	78.700
2	P7217	AST PC Atomix White	3.200
3	P7199	AST PC Atomix Black	0.200
4	P7207	AST PC Atomix Red MX	3.300
5	P8258	AST PC Atomix Yellow II	14.600
TOTAL			100%

PANTONE® 175 C

1	P7218	AST PC Atomix Opaque Mix Base	77.850
2	P7217	AST PC Atomix White	3.000
3	P7199	AST PC Atomix Black	0.800
4	P7207	AST PC Atomix Red MX	4.350
5	P8258	AST PC Atomix Yellow II	14.000
TOTAL			100%

PANTONE® 176 C

1	P7218	AST PC Atomix Opaque Mix Base	76.590
2	P7217	AST PC Atomix White	20.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	3.100
4	P7207	AST PC Atomix Red MX	0.250
5	P7208	AST PC Atomix Lemon MX	0.060
TOTAL			100%

PANTONE® 177 C

1	P7218	AST PC Atomix Opaque Mix Base	83.850
2	P7217	AST PC Atomix White	6.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	9.000
4	P7211	AST PC Atomix Magenta MX	0.200
5	P7208	AST PC Atomix Lemon MX	0.950
TOTAL			100%

PANTONE® 178 C

1	P7218	AST PC Atomix Opaque Mix Base	74.750
2	P7217	AST PC Atomix White	2.500
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	13.600
4	P8412	AST PC Atomix Fluo Orange DTA FF	8.000
5	P7207	AST PC Atomix Red MX	0.430
6	P7208	AST PC Atomix Lemon MX	0.720
TOTAL			100%

PANTONE® Warm Red C

1	P7218	AST PC Atomix Opaque Mix Base	73.500
2	P7217	AST PC Atomix White	0.800
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	15.900
4	P8412	AST PC Atomix Fluo Orange DTA FF	8.100
5	P7208	AST PC Atomix Lemon MX	1.700
TOTAL			100%

PANTONE® 179 C

1	P7218	AST PC Atomix Opaque Mix Base	89.060
2	P7217	AST PC Atomix White	2.640
3	P7211	AST PC Atomix Magenta MX	2.600
4	P8258	AST PC Atomix Yellow II	5.700
TOTAL			100%

PANTONE® 180 C

1	P7218	AST PC Atomix Opaque Mix Base	82.960
2	P7217	AST PC Atomix White	3.750
3	P7199	AST PC Atomix Black	0.090
4	P7207	AST PC Atomix Red MX	4.400
5	P8258	AST PC Atomix Yellow II	8.800
TOTAL			100%

PANTONE® 181 C

1	P7218	AST PC Atomix Opaque Mix Base	77.680
2	P7217	AST PC Atomix White	3.820
3	P7199	AST PC Atomix Black	0.790
4	P7207	AST PC Atomix Red MX	8.150
5	P8258	AST PC Atomix Yellow II	9.560
TOTAL			100%

PANTONE® 1765 C

1	P7218	AST PC Atomix Opaque Mix Base	75.090
2	P7217	AST PC Atomix White	20.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	4.500
4	P7207	AST PC Atomix Red MX	0.350
5	P7208	AST PC Atomix Lemon MX	0.060
TOTAL			100%

PANTONE® 1775 C

1	P7218	AST PC Atomix Opaque Mix Base	68.920
2	P7217	AST PC Atomix White	19.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	11.000
4	P7211	AST PC Atomix Magenta MX	0.600
5	P7208	AST PC Atomix Lemon MX	0.480
TOTAL			100%

PANTONE® 1785 C

1	P7218	AST PC Atomix Opaque Mix Base	67.950
2	P7217	AST PC Atomix White	2.200
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	20.000
4	P8412	AST PC Atomix Fluo Orange DTA FF	9.300
5	P7211	AST PC Atomix Magenta MX	0.400
6	P7208	AST PC Atomix Lemon MX	0.150
TOTAL			100%

PANTONE® 1788 C

1	P7218	AST PC Atomix Opaque Mix Base	69.850
2	P7217	AST PC Atomix White	1.200
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	15.500
4	P8412	AST PC Atomix Fluo Orange DTA FF	11.000
5	P7207	AST PC Atomix Red MX	1.500
6	P7208	AST PC Atomix Lemon MX	0.950
TOTAL			100%

PANTONE® 1795 C

1	P7218	AST PC Atomix Opaque Mix Base	82.340
2	P8412	AST PC Atomix Fluo Orange DTA FF	11.720
3	P7207	AST PC Atomix Red MX	4.500
4	P8258	AST PC Atomix Yellow II	1.440
TOTAL			100%

PANTONE® 1805 C

1	P7218	AST PC Atomix Opaque Mix Base	78.910
2	P7217	AST PC Atomix White	4.000
3	P7199	AST PC Atomix Black	0.090
4	P7207	AST PC Atomix Red MX	8.600
5	P8258	AST PC Atomix Yellow II	8.400
TOTAL			100%

PANTONE® 1815 C

1	P7218	AST PC Atomix Opaque Mix Base	78.040
2	P7217	AST PC Atomix White	3.500
3	P7199	AST PC Atomix Black	0.560
4	P7207	AST PC Atomix Red MX	8.900
5	P8258	AST PC Atomix Yellow II	9.000
TOTAL			100%

PANTONE® 1767 C

1	P7218	AST PC Atomix Opaque Mix Base	76.210
2	P7217	AST PC Atomix White	20.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	3.500
4	P7207	AST PC Atomix Red MX	0.250
5	P7208	AST PC Atomix Lemon MX	0.040
TOTAL			100%

PANTONE® 1777 C

1	P7218	AST PC Atomix Opaque Mix Base	79.650
2	P7217	AST PC Atomix White	8.450
3	P8412	AST PC Atomix Fluo Orange DTA FF	9.900
4	P7211	AST PC Atomix Magenta MX	2.000
TOTAL			100%

PANTONE® 1787 C

1	P7218	AST PC Atomix Opaque Mix Base	79.600
2	P7217	AST PC Atomix White	3.400
3	P8412	AST PC Atomix Fluo Orange DTA FF	14.000
4	P7207	AST PC Atomix Red MX	3.000
TOTAL			100%

PANTONE® Red 032 C

1	P7218	AST PC Atomix Opaque Mix Base	83.800
2	P7217	AST PC Atomix White	1.200
3	P8412	AST PC Atomix Fluo Orange DTA FF	12.500
4	P7207	AST PC Atomix Red MX	2.050
5	P7208	AST PC Atomix Lemon MX	0.450
TOTAL			100%

PANTONE® 1797 C

1	P7218	AST PC Atomix Opaque Mix Base	83.820
2	P7217	AST PC Atomix White	3.450
3	P7211	AST PC Atomix Magenta MX	7.140
4	P8258	AST PC Atomix Yellow II	5.590
TOTAL			100%

PANTONE® 1807 C

1	P7218	AST PC Atomix Opaque Mix Base	81.880
2	P7217	AST PC Atomix White	3.600
3	P7199	AST PC Atomix Black	0.120
4	P7211	AST PC Atomix Magenta MX	8.800
5	P8258	AST PC Atomix Yellow II	5.600
TOTAL			100%

PANTONE® 1817 C

1	P7218	AST PC Atomix Opaque Mix Base	82.720
2	P7217	AST PC Atomix White	2.830
3	P7199	AST PC Atomix Black	0.870
4	P7211	AST PC Atomix Magenta MX	8.150
5	P8258	AST PC Atomix Yellow II	5.430
TOTAL			100%

PANTONE® 182 C

1	P7218	AST PC Atomix Opaque Mix Base	80.150
2	P7217	AST PC Atomix White	19.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	0.650
4	P7207	AST PC Atomix Red MX	0.200
TOTAL			100%

PANTONE® 183 C

1	P7218	AST PC Atomix Opaque Mix Base	74.030
2	P7217	AST PC Atomix White	20.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	5.100
4	P7211	AST PC Atomix Magenta MX	0.750
5	P7208	AST PC Atomix Lemon MX	0.120
TOTAL			100%

PANTONE® 184 C

1	P7218	AST PC Atomix Opaque Mix Base	87.200
2	P7217	AST PC Atomix White	4.350
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	7.000
4	P7207	AST PC Atomix Red MX	1.100
5	P7208	AST PC Atomix Lemon MX	0.350
TOTAL			100%

PANTONE® 185 C

1	P7218	AST PC Atomix Opaque Mix Base	68.890
2	P7217	AST PC Atomix White	0.700
3	P8412	AST PC Atomix Fluo Orange DTA FF	25.870
4	P7207	AST PC Atomix Red MX	4.540
TOTAL			100%

PANTONE® 186 C

1	P7218	AST PC Atomix Opaque Mix Base	83.620
2	P8412	AST PC Atomix Fluo Orange DTA FF	6.500
3	P7211	AST PC Atomix Magenta MX	5.820
4	P8258	AST PC Atomix Yellow II	4.060
TOTAL			100%

PANTONE® 187 C

1	P7218	AST PC Atomix Opaque Mix Base	82.350
2	P7217	AST PC Atomix White	2.590
3	P7199	AST PC Atomix Black	0.070
4	P7211	AST PC Atomix Magenta MX	8.880
5	P8258	AST PC Atomix Yellow II	6.110
TOTAL			100%

PANTONE® 188 C

1	P7218	AST PC Atomix Opaque Mix Base	82.500
2	P7217	AST PC Atomix White	1.700
3	P7199	AST PC Atomix Black	0.400
4	P7211	AST PC Atomix Magenta MX	10.500
5	P8258	AST PC Atomix Yellow II	4.900
TOTAL			100%

PANTONE® 189 C

1	P7218	AST PC Atomix Opaque Mix Base	76.240
2	P7217	AST PC Atomix White	19.500
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	3.900
4	P7207	AST PC Atomix Red MX	0.350
5	P7208	AST PC Atomix Lemon MX	0.010
TOTAL			100%

PANTONE® 190 C

1	P7218	AST PC Atomix Opaque Mix Base	72.170
2	P7217	AST PC Atomix White	13.600
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	13.000
4	P7211	AST PC Atomix Magenta MX	1.050
5	P7208	AST PC Atomix Lemon MX	0.180
TOTAL			100%

PANTONE® 191 C

1	P7218	AST PC Atomix Opaque Mix Base	70.600
2	P7217	AST PC Atomix White	5.400
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	12.800
4	P8412	AST PC Atomix Fluo Orange DTA FF	8.800
5	P7211	AST PC Atomix Magenta MX	2.400
TOTAL			100%

PANTONE® 192 C

1	P7218	AST PC Atomix Opaque Mix Base	72.300
2	P7217	AST PC Atomix White	0.300
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	15.000
4	P8412	AST PC Atomix Fluo Orange DTA FF	11.000
5	P7211	AST PC Atomix Magenta MX	1.400
TOTAL			100%

PANTONE® 193 C

1	P7218	AST PC Atomix Opaque Mix Base	85.450
2	P7217	AST PC Atomix White	2.800
3	P7211	AST PC Atomix Magenta MX	9.600
4	P8258	AST PC Atomix Yellow II	2.150
TOTAL			100%

PANTONE® 194 C

1	P7218	AST PC Atomix Opaque Mix Base	80.660
2	P7217	AST PC Atomix White	3.600
3	P7199	AST PC Atomix Black	0.140
4	P7211	AST PC Atomix Magenta MX	14.000
5	P8258	AST PC Atomix Yellow II	1.600
TOTAL			100%

PANTONE® 195 C

1	P7218	AST PC Atomix Opaque Mix Base	81.500
2	P7217	AST PC Atomix White	3.600
3	P7199	AST PC Atomix Black	0.600
4	P7211	AST PC Atomix Magenta MX	12.000
5	P8258	AST PC Atomix Yellow II	2.300
TOTAL			100%

PANTONE® 1895 C

1	P7218	AST PC Atomix Opaque Mix Base	79.570
2	P7217	AST PC Atomix White	19.500
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	0.600
4	P7211	AST PC Atomix Magenta MX	0.320
5	P7208	AST PC Atomix Lemon MX	0.010
TOTAL			100%

PANTONE® 1905 C

1	P7218	AST PC Atomix Opaque Mix Base	80.860
2	P7217	AST PC Atomix White	18.000
3	P7211	AST PC Atomix Magenta MX	1.100
4	P7208	AST PC Atomix Lemon MX	0.040
TOTAL			100%

PANTONE® 1915 C

1	P7218	AST PC Atomix Opaque Mix Base	71.070
2	P7217	AST PC Atomix White	5.600
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	21.800
4	P7211	AST PC Atomix Magenta MX	1.500
5	P7208	AST PC Atomix Lemon MX	0.030
TOTAL			100%

PANTONE® 1925 C

1	P7218	AST PC Atomix Opaque Mix Base	66.800
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	26.000
3	P8412	AST PC Atomix Fluo Orange DTA FF	6.000
4	P7211	AST PC Atomix Magenta MX	1.200
TOTAL			100%

PANTONE® 1935 C

1	P7218	AST PC Atomix Opaque Mix Base	82.800
2	P7217	AST PC Atomix White	4.400
3	P7211	AST PC Atomix Magenta MX	11.600
4	P8258	AST PC Atomix Yellow II	1.200
TOTAL			100%

PANTONE® 1945 C

1	P7218	AST PC Atomix Opaque Mix Base	81.120
2	P7217	AST PC Atomix White	3.600
3	P7199	AST PC Atomix Black	0.080
4	P7211	AST PC Atomix Magenta MX	14.000
5	P8258	AST PC Atomix Yellow II	1.200
TOTAL			100%

PANTONE® 1955 C

1	P7218	AST PC Atomix Opaque Mix Base	81.220
2	P7217	AST PC Atomix White	3.600
3	P7199	AST PC Atomix Black	0.180
4	P7211	AST PC Atomix Magenta MX	13.500
5	P8258	AST PC Atomix Yellow II	1.500
TOTAL			100%

PANTONE® 196 C

1	P7218	AST PC Atomix Opaque Mix Base	79.940
2	P7217	AST PC Atomix White	19.700
3	P7213	AST PC Atomix Blue RQ	0.150
4	P7211	AST PC Atomix Magenta MX	0.150
5	P8258	AST PC Atomix Yellow II	0.060
TOTAL			100%

PANTONE® 197 C

1	P7218	AST PC Atomix Opaque Mix Base	78.600
2	P7217	AST PC Atomix White	20.000
3	P7211	AST PC Atomix Magenta MX	1.100
4	P7208	AST PC Atomix Lemon MX	0.300
TOTAL			100%

PANTONE® 198 C

1	P7218	AST PC Atomix Opaque Mix Base	68.390
2	P7217	AST PC Atomix White	12.000
3	P8412	AST PC Atomix Fluo Orange DTA FF	13.650
4	P7207	AST PC Atomix Red MX	5.830
5	P7208	AST PC Atomix Lemon MX	0.130
TOTAL			100%

PANTONE® 199 C

1	P7218	AST PC Atomix Opaque Mix Base	72.400
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	8.400
3	P8412	AST PC Atomix Fluo Orange DTA FF	14.800
4	P7207	AST PC Atomix Red MX	4.400
TOTAL			100%

PANTONE® 200 C

1	P7218	AST PC Atomix Opaque Mix Base	90.700
2	P7217	AST PC Atomix White	0.600
3	P7211	AST PC Atomix Magenta MX	6.000
4	P8258	AST PC Atomix Yellow II	2.700
TOTAL			100%

PANTONE® 201 C

1	P7218	AST PC Atomix Opaque Mix Base	90.300
2	P7217	AST PC Atomix White	0.300
3	P7199	AST PC Atomix Black	0.100
4	P7211	AST PC Atomix Magenta MX	6.500
5	P8258	AST PC Atomix Yellow II	2.800
TOTAL			100%

PANTONE® 202 C

1	P7218	AST PC Atomix Opaque Mix Base	87.530
2	P7217	AST PC Atomix White	1.720
3	P7199	AST PC Atomix Black	0.210
4	P7211	AST PC Atomix Magenta MX	7.600
5	P8258	AST PC Atomix Yellow II	2.940
TOTAL			100%

PANTONE® 203 C

1	P7218	AST PC Atomix Opaque Mix Base	79.960
2	P7217	AST PC Atomix White	19.500
3	P7211	AST PC Atomix Magenta MX	0.520
4	P7208	AST PC Atomix Lemon MX	0.020
TOTAL			100%

PANTONE® 204 C

1	P7218	AST PC Atomix Opaque Mix Base	87.000
2	P7217	AST PC Atomix White	8.400
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	3.600
4	P7213	AST PC Atomix Blue RQ	0.400
5	P7207	AST PC Atomix Red MX	0.600
TOTAL			100%

PANTONE® 205 C

1	P7218	AST PC Atomix Opaque Mix Base	71.280
2	P7217	AST PC Atomix White	2.800
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	24.000
4	P7211	AST PC Atomix Magenta MX	1.800
5	P7208	AST PC Atomix Lemon MX	0.120
TOTAL			100%

PANTONE® 206 C

1	P7218	AST PC Atomix Opaque Mix Base	70.700
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	11.800
3	P8412	AST PC Atomix Fluo Orange DTA FF	10.000
4	P7211	AST PC Atomix Magenta MX	2.000
5	P7207	AST PC Atomix Red MX	5.500
TOTAL			100%

PANTONE® 207 C

1	P7218	AST PC Atomix Opaque Mix Base	82.060
2	P7217	AST PC Atomix White	3.600
3	P7199	AST PC Atomix Black	0.040
4	P7211	AST PC Atomix Magenta MX	13.000
5	P8258	AST PC Atomix Yellow II	1.300
TOTAL			100%

PANTONE® 208 C

1	P7218	AST PC Atomix Opaque Mix Base	81.200
2	P7217	AST PC Atomix White	3.600
3	P7199	AST PC Atomix Black	0.300
4	P7211	AST PC Atomix Magenta MX	14.000
5	P8258	AST PC Atomix Yellow II	0.900
TOTAL			100%

PANTONE® 209 C

1	P7218	AST PC Atomix Opaque Mix Base	81.300
2	P7217	AST PC Atomix White	3.600
3	P7199	AST PC Atomix Black	0.600
4	P7211	AST PC Atomix Magenta MX	12.800
5	P8258	AST PC Atomix Yellow II	1.700
TOTAL			100%

PANTONE® 210 C

1	P7218	AST PC Atomix Opaque Mix Base	83.250
2	P7217	AST PC Atomix White	13.500
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	2.600
4	P7213	AST PC Atomix Blue RQ	0.200
5	P7211	AST PC Atomix Magenta MX	0.450
TOTAL			100%

PANTONE® 211 C

1	P7218	AST PC Atomix Opaque Mix Base	72.520
2	P7217	AST PC Atomix White	16.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	10.400
4	P7213	AST PC Atomix Blue RQ	0.080
5	P7211	AST PC Atomix Magenta MX	1.000
TOTAL			100%

PANTONE® 212 C

1	P7218	AST PC Atomix Opaque Mix Base	81.760
2	P7217	AST PC Atomix White	4.120
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	13.000
4	P7211	AST PC Atomix Magenta MX	1.120
TOTAL			100%

PANTONE® 213 C

1	P7218	AST PC Atomix Opaque Mix Base	70.300
2	P7217	AST PC Atomix White	0.700
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	28.000
4	P7211	AST PC Atomix Magenta MX	1.000
TOTAL			100%

PANTONE® 214 C

1	P7218	AST PC Atomix Opaque Mix Base	64.000
2	P7217	AST PC Atomix White	0.400
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	34.300
4	P7211	AST PC Atomix Magenta MX	1.300
TOTAL			100%

PANTONE® 215 C

1	P7218	AST PC Atomix Opaque Mix Base	80.240
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	15.600
3	P7213	AST PC Atomix Blue RQ	1.560
4	P7211	AST PC Atomix Magenta MX	2.600
TOTAL			100%

PANTONE® 216 C

1	P7218	AST PC Atomix Opaque Mix Base	75.500
2	P7217	AST PC Atomix White	6.400
3	P7199	AST PC Atomix Black	0.600
4	P7211	AST PC Atomix Magenta MX	17.500
TOTAL			100%

PANTONE® 217 C

1	P7218	AST PC Atomix Opaque Mix Base	79.450
2	P7217	AST PC Atomix White	20.000
3	P7213	AST PC Atomix Blue RQ	0.200
4	P7211	AST PC Atomix Magenta MX	0.350
TOTAL			100%

PANTONE® 218 C

1	P7218	AST PC Atomix Opaque Mix Base	74.300
2	P7217	AST PC Atomix White	8.500
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	15.800
4	P7213	AST PC Atomix Blue RQ	0.800
5	P7211	AST PC Atomix Magenta MX	0.600
TOTAL			100%

PANTONE® 219 C

1	P7218	AST PC Atomix Opaque Mix Base	71.650
2	P7217	AST PC Atomix White	0.500
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	27.000
4	P7213	AST PC Atomix Blue RQ	0.100
5	P7211	AST PC Atomix Magenta MX	0.750
TOTAL			100%

PANTONE® Rubine Red C

1	P7218	AST PC Atomix Opaque Mix Base	71.900
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	24.300
3	P8412	AST PC Atomix Fluo Orange DTA FF	2.000
4	P7211	AST PC Atomix Magenta MX	1.800
TOTAL			100%

PANTONE® 220 C

1	P7218	AST PC Atomix Opaque Mix Base	67.800
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	28.000
3	P7213	AST PC Atomix Blue RQ	1.200
4	P7211	AST PC Atomix Magenta MX	3.000
TOTAL			100%

PANTONE® 221 C

1	P7218	AST PC Atomix Opaque Mix Base	75.000
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	18.000
3	P7213	AST PC Atomix Blue RQ	2.600
4	P7211	AST PC Atomix Magenta MX	4.400
TOTAL			100%

PANTONE® 222 C

1	P7218	AST PC Atomix Opaque Mix Base	77.600
2	P7217	AST PC Atomix White	4.800
3	P7199	AST PC Atomix Black	0.800
4	P7211	AST PC Atomix Magenta MX	16.800
TOTAL			100%

PANTONE® 223 C

1	P7218	AST PC Atomix Opaque Mix Base	73.400
2	P7217	AST PC Atomix White	16.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	9.200
4	P7213	AST PC Atomix Blue RQ	1.200
5	P7211	AST PC Atomix Magenta MX	0.200
TOTAL			100%

PANTONE® 224 C

1	P7218	AST PC Atomix Opaque Mix Base	75.010
2	P7217	AST PC Atomix White	7.600
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	16.000
4	P7213	AST PC Atomix Blue RQ	1.150
5	P7211	AST PC Atomix Magenta MX	0.240
TOTAL			100%

PANTONE® 225 C

1	P7218	AST PC Atomix Opaque Mix Base	71.400
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	28.000
3	P7213	AST PC Atomix Blue RQ	0.600
TOTAL			100%

PANTONE® 226 C

1	P7218	AST PC Atomix Opaque Mix Base	72.100
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	27.000
3	P7213	AST PC Atomix Blue RQ	0.100
4	P7211	AST PC Atomix Magenta MX	0.800
TOTAL			100%

PANTONE® 227 C

1	P7218	AST PC Atomix Opaque Mix Base	74.700
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	22.000
3	P7213	AST PC Atomix Blue RQ	2.200
4	P7211	AST PC Atomix Magenta MX	1.100
TOTAL			100%

PANTONE® 228 C

1	P7218	AST PC Atomix Opaque Mix Base	70.120
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	28.000
3	P7206	AST PC Atomix Violet	0.480
4	P7211	AST PC Atomix Magenta MX	1.400
TOTAL			100%

PANTONE® 229 C

1	P7218	AST PC Atomix Opaque Mix Base	78.410
2	P7217	AST PC Atomix White	4.500
3	P7199	AST PC Atomix Black	0.910
4	P7211	AST PC Atomix Magenta MX	16.180
TOTAL			100%

PANTONE® 230 C

1	P7218	AST PC Atomix Opaque Mix Base	73.000
2	P7217	AST PC Atomix White	20.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	6.000
4	P7213	AST PC Atomix Blue RQ	0.800
5	P7211	AST PC Atomix Magenta MX	0.200
TOTAL			100%

PANTONE® 231 C

1	P7218	AST PC Atomix Opaque Mix Base	76.050
2	P7217	AST PC Atomix White	7.900
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	14.800
4	P7213	AST PC Atomix Blue RQ	1.200
5	P7207	AST PC Atomix Red MX	0.050
TOTAL			100%

PANTONE® 232 C

1	P7218	AST PC Atomix Opaque Mix Base	74.780
2	P7217	AST PC Atomix White	1.100
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	24.000
4	P7206	AST PC Atomix Violet	0.120
TOTAL			100%

PANTONE® Rhodamine Red C

1	P7218	AST PC Atomix Opaque Mix Base	71.600
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	28.000
3	P7213	AST PC Atomix Blue RQ	0.400
TOTAL			100%

PANTONE® 233 C

1	P7218	AST PC Atomix Opaque Mix Base	72.400
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	27.000
3	P7206	AST PC Atomix Violet	0.200
4	P7211	AST PC Atomix Magenta MX	0.400
TOTAL			100%

PANTONE® 234 C

1	P7218	AST PC Atomix Opaque Mix Base	71.730
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	27.000
3	P7206	AST PC Atomix Violet	0.270
4	P7211	AST PC Atomix Magenta MX	1.000
TOTAL			100%

PANTONE® 235 C

1	P7218	AST PC Atomix Opaque Mix Base	65.400
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	27.600
3	P7213	AST PC Atomix Blue RQ	5.200
4	P7211	AST PC Atomix Magenta MX	1.800
TOTAL			100%

PANTONE® 236 C

1	P7218	AST PC Atomix Opaque Mix Base	78.160
2	P7217	AST PC Atomix White	16.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	4.800
4	P7213	AST PC Atomix Blue RQ	0.960
5	P7211	AST PC Atomix Magenta MX	0.080
TOTAL			100%

PANTONE® 237 C

1	P7218	AST PC Atomix Opaque Mix Base	74.280
2	P7217	AST PC Atomix White	12.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	12.000
4	P7213	AST PC Atomix Blue RQ	1.600
5	P7211	AST PC Atomix Magenta MX	0.120
TOTAL			100%

PANTONE® 238 C

1	P7218	AST PC Atomix Opaque Mix Base	73.760
2	P7217	AST PC Atomix White	6.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	20.000
4	P7206	AST PC Atomix Violet	0.240
TOTAL			100%

PANTONE® 239 C

1	P7218	AST PC Atomix Opaque Mix Base	69.750
2	P7217	AST PC Atomix White	3.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	27.000
4	P7206	AST PC Atomix Violet	0.250
TOTAL			100%

PANTONE® 240 C

1	P7218	AST PC Atomix Opaque Mix Base	71.630
2	P7217	AST PC Atomix White	1.320
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	26.700
4	P7206	AST PC Atomix Violet	0.350
TOTAL			100%

PANTONE® 241 C

1	P7218	AST PC Atomix Opaque Mix Base	73.420
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	26.000
3	P7206	AST PC Atomix Violet	0.280
4	P7211	AST PC Atomix Magenta MX	0.300
TOTAL			100%

PANTONE® 242 C

1	P7218	AST PC Atomix Opaque Mix Base	71.200
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	26.000
3	P7206	AST PC Atomix Violet	0.800
4	P7211	AST PC Atomix Magenta MX	2.000
TOTAL			100%

PANTONE® 2365 C

1	P7218	AST PC Atomix Opaque Mix Base	77.150
2	P7217	AST PC Atomix White	20.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	2.250
4	P7213	AST PC Atomix Blue RQ	0.560
5	P7211	AST PC Atomix Magenta MX	0.040
TOTAL			100%

PANTONE® 2375 C

1	P7218	AST PC Atomix Opaque Mix Base	68.400
2	P7217	AST PC Atomix White	10.200
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	18.400
4	P7213	AST PC Atomix Blue RQ	3.000
TOTAL			100%

PANTONE® 2385 C

1	P7218	AST PC Atomix Opaque Mix Base	85.840
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	14.000
3	P7206	AST PC Atomix Violet	0.160
TOTAL			100%

PANTONE® 2395 C

1	P7218	AST PC Atomix Opaque Mix Base	72.980
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	26.800
3	P7206	AST PC Atomix Violet	0.220
TOTAL			100%

PANTONE® 2405 C

1	P7218	AST PC Atomix Opaque Mix Base	73.240
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	26.400
3	P7206	AST PC Atomix Violet	0.360
TOTAL			100%

PANTONE® 2415 C

1	P7218	AST PC Atomix Opaque Mix Base	74.520
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	25.000
3	P7206	AST PC Atomix Violet	0.400
4	P7211	AST PC Atomix Magenta MX	0.080
TOTAL			100%

PANTONE® 2425 C

1	P7218	AST PC Atomix Opaque Mix Base	71.800
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	26.800
3	P7206	AST PC Atomix Violet	0.600
4	P7211	AST PC Atomix Magenta MX	0.800
TOTAL			100%

PANTONE® 243 C

1	P7218	AST PC Atomix Opaque Mix Base	77.250
2	P7217	AST PC Atomix White	18.700
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	2.700
4	P7213	AST PC Atomix Blue RQ	1.300
5	P7211	AST PC Atomix Magenta MX	0.050
TOTAL			100%

PANTONE® 244 C

1	P7218	AST PC Atomix Opaque Mix Base	69.950
2	P7217	AST PC Atomix White	19.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	8.600
4	P7213	AST PC Atomix Blue RQ	2.400
5	P7211	AST PC Atomix Magenta MX	0.050
TOTAL			100%

PANTONE® 245 C

1	P7218	AST PC Atomix Opaque Mix Base	65.500
2	P7217	AST PC Atomix White	14.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	17.000
4	P7213	AST PC Atomix Blue RQ	3.500
TOTAL			100%

PANTONE® 246 C

1	P7218	AST PC Atomix Opaque Mix Base	78.790
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	18.570
3	P7213	AST PC Atomix Blue RQ	2.640
TOTAL			100%

PANTONE® 247 C

1	P7218	AST PC Atomix Opaque Mix Base	72.430
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	25.000
3	P7213	AST PC Atomix Blue RQ	2.570
TOTAL			100%

PANTONE® 248 C

1	P7218	AST PC Atomix Opaque Mix Base	79.280
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	20.000
3	P7206	AST PC Atomix Violet	0.480
4	P7211	AST PC Atomix Magenta MX	0.240
TOTAL			100%

PANTONE® 249 C

1	P7218	AST PC Atomix Opaque Mix Base	72.000
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	26.000
3	P7206	AST PC Atomix Violet	0.900
4	P7211	AST PC Atomix Magenta MX	1.100
TOTAL			100%

PANTONE® 250 C

1	P7218	AST PC Atomix Opaque Mix Base	82.810
2	P7217	AST PC Atomix White	14.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	2.240
4	P7213	AST PC Atomix Blue RQ	0.950
TOTAL			100%

PANTONE® 251 C

1	P7218	AST PC Atomix Opaque Mix Base	83.000
2	P7217	AST PC Atomix White	12.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	4.800
4	P7206	AST PC Atomix Violet	0.200
TOTAL			100%

PANTONE® 252 C

1	P7218	AST PC Atomix Opaque Mix Base	79.600
2	P7217	AST PC Atomix White	4.600
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	12.000
4	P7213	AST PC Atomix Blue RQ	3.800
TOTAL			100%

PANTONE® Purple C

1	P7218	AST PC Atomix Opaque Mix Base	88.850
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	10.400
3	P7206	AST PC Atomix Violet	0.750
TOTAL			100%

PANTONE® 253 C

1	P7218	AST PC Atomix Opaque Mix Base	76.300
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	19.500
3	P7213	AST PC Atomix Blue RQ	4.200
TOTAL			100%

PANTONE® 254 C

1	P7218	AST PC Atomix Opaque Mix Base	70.800
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	24.000
3	P7213	AST PC Atomix Blue RQ	5.200
TOTAL			100%

PANTONE® 255 C

1	P7218	AST PC Atomix Opaque Mix Base	71.050
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	26.800
3	P7206	AST PC Atomix Violet	1.350
4	P7211	AST PC Atomix Magenta MX	0.800
TOTAL			100%

PANTONE® 256 C

1	P7218	AST PC Atomix Opaque Mix Base	79.810
2	P7217	AST PC Atomix White	20.000
3	P7206	AST PC Atomix Violet	0.120
4	P7211	AST PC Atomix Magenta MX	0.070
TOTAL			100%

PANTONE® 257 C

1	P7218	AST PC Atomix Opaque Mix Base	80.750
2	P7217	AST PC Atomix White	18.500
3	P7206	AST PC Atomix Violet	0.300
4	P7211	AST PC Atomix Magenta MX	0.450
TOTAL			100%

PANTONE® 258 C

1	P7218	AST PC Atomix Opaque Mix Base	94.020
2	P7217	AST PC Atomix White	1.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	3.600
4	P7206	AST PC Atomix Violet	0.780
5	P7211	AST PC Atomix Magenta MX	0.600
TOTAL			100%

PANTONE® 259 C

1	P7218	AST PC Atomix Opaque Mix Base	88.800
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	9.200
3	P7206	AST PC Atomix Violet	1.200
4	P7211	AST PC Atomix Magenta MX	0.800
TOTAL			100%

PANTONE® 260 C

1	P7218	AST PC Atomix Opaque Mix Base	87.250
2	P7217	AST PC Atomix White	1.400
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	10.000
4	P7211	AST PC Atomix Magenta MX	1.350
TOTAL			100%

PANTONE® 261 C

1	P7218	AST PC Atomix Opaque Mix Base	84.280
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	11.520
3	P7206	AST PC Atomix Violet	2.000
4	P7211	AST PC Atomix Magenta MX	2.200
TOTAL			100%

PANTONE® 262 C

1	P7218	AST PC Atomix Opaque Mix Base	81.880
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	11.520
3	P7206	AST PC Atomix Violet	2.500
4	P7211	AST PC Atomix Magenta MX	4.100
TOTAL			100%

PANTONE® 2562 C

1	P7218	AST PC Atomix Opaque Mix Base	76.700
2	P7217	AST PC Atomix White	16.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	4.700
4	P7213	AST PC Atomix Blue RQ	2.600
TOTAL			100%

PANTONE® 2572 C

1	P7218	AST PC Atomix Opaque Mix Base	69.300
2	P7217	AST PC Atomix White	15.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	10.300
4	P7213	AST PC Atomix Blue RQ	5.400
TOTAL			100%

PANTONE® 2582 C

1	P7218	AST PC Atomix Opaque Mix Base	79.800
2	P7217	AST PC Atomix White	1.800
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	12.800
4	P7213	AST PC Atomix Blue RQ	5.600
TOTAL			100%

PANTONE® 2592 C

1	P7218	AST PC Atomix Opaque Mix Base	76.520
2	P7217	AST PC Atomix White	0.400
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	16.480
4	P7213	AST PC Atomix Blue RQ	6.600
TOTAL			100%

PANTONE® 2602 C

1	P7218	AST PC Atomix Opaque Mix Base	70.800
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	21.000
3	P7213	AST PC Atomix Blue RQ	8.200
TOTAL			100%

PANTONE® 2612 C

1	P7218	AST PC Atomix Opaque Mix Base	61.400
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	28.000
3	P7213	AST PC Atomix Blue RQ	10.400
4	P7211	AST PC Atomix Magenta MX	0.200
TOTAL			100%

PANTONE® 2622 C

1	P7218	AST PC Atomix Opaque Mix Base	79.800
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	16.400
3	P7206	AST PC Atomix Violet	1.800
4	P7211	AST PC Atomix Magenta MX	2.000
TOTAL			100%

PANTONE® 2563 C

1	P7218	AST PC Atomix Opaque Mix Base	82.730
2	P7217	AST PC Atomix White	10.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	4.000
4	P7199	AST PC Atomix Black	0.020
5	P7213	AST PC Atomix Blue RQ	3.250
TOTAL			100%

PANTONE® 2573 C

1	P7218	AST PC Atomix Opaque Mix Base	68.400
2	P7217	AST PC Atomix White	14.600
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	9.800
4	P7213	AST PC Atomix Blue RQ	7.000
5	P7211	AST PC Atomix Magenta MX	0.200
TOTAL			100%

PANTONE® 2583 C

1	P7218	AST PC Atomix Opaque Mix Base	82.840
2	P7217	AST PC Atomix White	2.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	9.000
4	P7213	AST PC Atomix Blue RQ	6.000
5	P7211	AST PC Atomix Magenta MX	0.160
TOTAL			100%

PANTONE® 2593 C

1	P7218	AST PC Atomix Opaque Mix Base	87.000
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	12.000
3	P7206	AST PC Atomix Violet	1.000
TOTAL			100%

PANTONE® 2603 C

1	P7218	AST PC Atomix Opaque Mix Base	82.200
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	16.200
3	P7206	AST PC Atomix Violet	1.480
4	P7211	AST PC Atomix Magenta MX	0.120
TOTAL			100%

PANTONE® 2613 C

1	P7218	AST PC Atomix Opaque Mix Base	79.280
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	18.400
3	P7206	AST PC Atomix Violet	1.800
4	P7211	AST PC Atomix Magenta MX	0.520
TOTAL			100%

PANTONE® 2623 C

1	P7218	AST PC Atomix Opaque Mix Base	76.000
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	20.640
3	P7206	AST PC Atomix Violet	2.400
4	P7211	AST PC Atomix Magenta MX	0.960
TOTAL			100%

PANTONE® 2567 C

1	P7218	AST PC Atomix Opaque Mix Base	78.650
2	P7217	AST PC Atomix White	20.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	0.900
4	P7206	AST PC Atomix Violet	0.450
TOTAL			100%

PANTONE® 2577 C

1	P7218	AST PC Atomix Opaque Mix Base	73.150
2	P7217	AST PC Atomix White	20.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	5.600
4	P7206	AST PC Atomix Violet	1.250
TOTAL			100%

PANTONE® 2587 C

1	P7218	AST PC Atomix Opaque Mix Base	79.500
2	P7217	AST PC Atomix White	0.800
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	10.400
4	P7213	AST PC Atomix Blue RQ	9.200
5	P7211	AST PC Atomix Magenta MX	0.100
TOTAL			100%

PANTONE® 2597 C

1	P7218	AST PC Atomix Opaque Mix Base	74.800
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	15.000
3	P7206	AST PC Atomix Violet	1.200
4	P7213	AST PC Atomix Blue RQ	9.000
TOTAL			100%

PANTONE® 2607 C

1	P7218	AST PC Atomix Opaque Mix Base	72.800
2	P7217	AST PC Atomix White	0.800
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	18.000
4	P7206	AST PC Atomix Violet	2.400
5	P7213	AST PC Atomix Blue RQ	6.000
TOTAL			100%

PANTONE® 2617 C

1	P7218	AST PC Atomix Opaque Mix Base	70.800
2	P7217	AST PC Atomix White	1.600
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	22.400
4	P7206	AST PC Atomix Violet	5.200
TOTAL			100%

PANTONE® 2627 C

1	P7218	AST PC Atomix Opaque Mix Base	95.650
2	P7206	AST PC Atomix Violet	2.100
3	P7211	AST PC Atomix Magenta MX	2.250
TOTAL			100%

PANTONE® 263 C

1	P7218	AST PC Atomix Opaque Mix Base	77.500
2	P7217	AST PC Atomix White	20.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	1.100
4	P7213	AST PC Atomix Blue RQ	1.400
TOTAL			100%

PANTONE® 264 C

1	P7218	AST PC Atomix Opaque Mix Base	70.700
2	P7217	AST PC Atomix White	20.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	4.300
4	P7213	AST PC Atomix Blue RQ	5.000
TOTAL			100%

PANTONE® 265 C

1	P7218	AST PC Atomix Opaque Mix Base	67.800
2	P7217	AST PC Atomix White	6.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	13.000
4	P7213	AST PC Atomix Blue RQ	13.200
TOTAL			100%

PANTONE® 266 C

1	P7218	AST PC Atomix Opaque Mix Base	79.440
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	10.280
3	P7213	AST PC Atomix Blue RQ	10.280
TOTAL			100%

PANTONE® 267 C

1	P7218	AST PC Atomix Opaque Mix Base	77.100
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	11.100
3	P7206	AST PC Atomix Violet	0.600
4	P7213	AST PC Atomix Blue RQ	11.200
TOTAL			100%

PANTONE® 268 C

1	P7218	AST PC Atomix Opaque Mix Base	87.800
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	10.000
3	P7206	AST PC Atomix Violet	2.200
TOTAL			100%

PANTONE® 269 C

1	P7218	AST PC Atomix Opaque Mix Base	79.650
2	P7217	AST PC Atomix White	2.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	14.800
4	P7199	AST PC Atomix Black	0.350
5	P7206	AST PC Atomix Violet	3.200
TOTAL			100%

PANTONE® 2635 C

1	P7218	AST PC Atomix Opaque Mix Base	77.500
2	P7217	AST PC Atomix White	18.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	1.600
4	P7213	AST PC Atomix Blue RQ	2.900
TOTAL			100%

PANTONE® 2645 C

1	P7218	AST PC Atomix Opaque Mix Base	71.400
2	P7217	AST PC Atomix White	18.800
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	3.900
4	P7206	AST PC Atomix Violet	0.200
5	P7213	AST PC Atomix Blue RQ	5.700
TOTAL			100%

PANTONE® 2655 C

1	P7218	AST PC Atomix Opaque Mix Base	86.400
2	P7217	AST PC Atomix White	3.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	3.800
4	P7213	AST PC Atomix Blue RQ	6.800
TOTAL			100%

PANTONE® 2665 C

1	P7218	AST PC Atomix Opaque Mix Base	73.900
2	P7217	AST PC Atomix White	1.900
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	8.900
4	P7213	AST PC Atomix Blue RQ	15.300
TOTAL			100%

PANTONE® Violet C

1	P7218	AST PC Atomix Opaque Mix Base	69.800
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	9.400
3	P7206	AST PC Atomix Violet	0.300
4	P7203	AST PC Atomix Blue 1500	0.500
5	P7213	AST PC Atomix Blue RQ	20.000
TOTAL			100%

PANTONE® 2685 C

1	P7218	AST PC Atomix Opaque Mix Base	69.550
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	7.800
3	P7206	AST PC Atomix Violet	1.650
4	P7203	AST PC Atomix Blue 1500	1.000
5	P7213	AST PC Atomix Blue RQ	20.000
TOTAL			100%

PANTONE® 2695 C

1	P7218	AST PC Atomix Opaque Mix Base	79.000
2	P7217	AST PC Atomix White	4.000
3	P7206	AST PC Atomix Violet	14.400
4	P7211	AST PC Atomix Magenta MX	2.600
TOTAL			100%

PANTONE® 270 C

1	P7218	AST PC Atomix Opaque Mix Base	74.770
2	P7217	AST PC Atomix White	20.000
3	P7213	AST PC Atomix Blue RQ	5.000
4	P7211	AST PC Atomix Magenta MX	0.230
TOTAL			100%

PANTONE® 271 C

1	P7218	AST PC Atomix Opaque Mix Base	75.900
2	P7217	AST PC Atomix White	14.460
3	P7213	AST PC Atomix Blue RQ	9.160
4	P7211	AST PC Atomix Magenta MX	0.480
TOTAL			100%

PANTONE® 272 C

1	P7218	AST PC Atomix Opaque Mix Base	86.720
2	P7217	AST PC Atomix White	11.000
3	P7206	AST PC Atomix Violet	1.690
4	P7204	AST PC Atomix Blue B	0.590
TOTAL			100%

PANTONE® 273 C

1	P7218	AST PC Atomix Opaque Mix Base	75.900
2	P7206	AST PC Atomix Violet	2.900
3	P7213	AST PC Atomix Blue RQ	21.200
TOTAL			100%

PANTONE® 274 C

1	P7218	AST PC Atomix Opaque Mix Base	91.600
2	P7217	AST PC Atomix White	0.800
3	P7206	AST PC Atomix Violet	6.800
4	P7203	AST PC Atomix Blue 1500	0.800
TOTAL			100%

PANTONE® 275 C

1	P7218	AST PC Atomix Opaque Mix Base	92.150
2	P7199	AST PC Atomix Black	0.150
3	P7206	AST PC Atomix Violet	7.000
4	P7203	AST PC Atomix Blue 1500	0.700
TOTAL			100%

PANTONE® 276 C

1	P7218	AST PC Atomix Opaque Mix Base	82.800
2	P7217	AST PC Atomix White	1.600
3	P7199	AST PC Atomix Black	1.600
4	P7206	AST PC Atomix Violet	14.000
TOTAL			100%

PANTONE® 2705 C

1	P7218	AST PC Atomix Opaque Mix Base	74.840
2	P7217	AST PC Atomix White	18.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	1.100
4	P7206	AST PC Atomix Violet	0.160
5	P7213	AST PC Atomix Blue RQ	5.900
TOTAL			100%

PANTONE® 2715 C

1	P7218	AST PC Atomix Opaque Mix Base	85.470
2	P7217	AST PC Atomix White	5.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	1.850
4	P7206	AST PC Atomix Violet	0.080
5	P7213	AST PC Atomix Blue RQ	7.600
TOTAL			100%

PANTONE® 2725 C

1	P7218	AST PC Atomix Opaque Mix Base	85.090
2	P7217	AST PC Atomix White	2.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	2.000
4	P7206	AST PC Atomix Violet	0.260
5	P7204	AST PC Atomix Blue B	0.050
6	P7213	AST PC Atomix Blue RQ	10.600
TOTAL			100%

PANTONE® 2735 C

1	P7218	AST PC Atomix Opaque Mix Base	78.100
2	P7206	AST PC Atomix Violet	1.500
3	P7213	AST PC Atomix Blue RQ	20.400
TOTAL			100%

PANTONE® 2745 C

1	P7218	AST PC Atomix Opaque Mix Base	74.100
2	P7206	AST PC Atomix Violet	2.800
3	P7203	AST PC Atomix Blue 1500	0.100
4	P7213	AST PC Atomix Blue RQ	23.000
TOTAL			100%

PANTONE® 2755 C

1	P7218	AST PC Atomix Opaque Mix Base	75.400
2	P7206	AST PC Atomix Violet	2.800
3	P7203	AST PC Atomix Blue 1500	0.800
4	P7213	AST PC Atomix Blue RQ	21.000
TOTAL			100%

PANTONE® 2765 C

1	P7218	AST PC Atomix Opaque Mix Base	92.250
2	P7199	AST PC Atomix Black	0.150
3	P7206	AST PC Atomix Violet	6.000
4	P7203	AST PC Atomix Blue 1500	1.600
TOTAL			100%

PANTONE® 2706 C

1	P7218	AST PC Atomix Opaque Mix Base	80.410
2	P7217	AST PC Atomix White	19.500
3	P7206	AST PC Atomix Violet	0.050
4	P7204	AST PC Atomix Blue B	0.040
TOTAL			100%

PANTONE® 2716 C

1	P7218	AST PC Atomix Opaque Mix Base	79.400
2	P7217	AST PC Atomix White	20.000
3	P7206	AST PC Atomix Violet	0.320
4	P7204	AST PC Atomix Blue B	0.280
TOTAL			100%

PANTONE® 2726 C

1	P7218	AST PC Atomix Opaque Mix Base	86.050
2	P7217	AST PC Atomix White	2.900
3	P7206	AST PC Atomix Violet	0.550
4	P7204	AST PC Atomix Blue B	0.500
5	P7213	AST PC Atomix Blue RQ	10.000
TOTAL			100%

PANTONE® 2736 C

1	P7218	AST PC Atomix Opaque Mix Base	81.800
2	P7206	AST PC Atomix Violet	0.600
3	P7204	AST PC Atomix Blue B	1.600
4	P7213	AST PC Atomix Blue RQ	16.000
TOTAL			100%

PANTONE® 2746 C

1	P7218	AST PC Atomix Opaque Mix Base	81.000
2	P7206	AST PC Atomix Violet	1.000
3	P7204	AST PC Atomix Blue B	2.200
4	P7213	AST PC Atomix Blue RQ	15.800
TOTAL			100%

PANTONE® 2756 C

1	P7218	AST PC Atomix Opaque Mix Base	81.700
2	P7217	AST PC Atomix White	2.000
3	P7206	AST PC Atomix Violet	4.300
4	P7204	AST PC Atomix Blue B	12.000
TOTAL			100%

PANTONE® 2766 C

1	P7218	AST PC Atomix Opaque Mix Base	83.600
2	P7217	AST PC Atomix White	2.000
3	P7199	AST PC Atomix Black	0.800
4	P7206	AST PC Atomix Violet	5.600
5	P7203	AST PC Atomix Blue 1500	8.000
TOTAL			100%

PANTONE® 2707 C

1	P7218	AST PC Atomix Opaque Mix Base	80.060
2	P7217	AST PC Atomix White	19.000
3	P7203	AST PC Atomix Blue 1500	0.040
4	P7213	AST PC Atomix Blue RQ	0.900
TOTAL			100%

PANTONE® 2717 C

1	P7218	AST PC Atomix Opaque Mix Base	77.720
2	P7217	AST PC Atomix White	20.000
3	P7203	AST PC Atomix Blue 1500	0.080
4	P7213	AST PC Atomix Blue RQ	2.200
TOTAL			100%

PANTONE® 2727 C

1	P7218	AST PC Atomix Opaque Mix Base	77.080
2	P7217	AST PC Atomix White	7.200
3	P7203	AST PC Atomix Blue 1500	0.720
4	P7213	AST PC Atomix Blue RQ	15.000
TOTAL			100%

PANTONE® Blue 072 C

1	P7218	AST PC Atomix Opaque Mix Base	70.600
2	P7206	AST PC Atomix Violet	0.400
3	P7204	AST PC Atomix Blue B	2.000
4	P7213	AST PC Atomix Blue RQ	27.000
TOTAL			100%

PANTONE® 2747 C

1	P7218	AST PC Atomix Opaque Mix Base	77.600
2	P7206	AST PC Atomix Violet	1.200
3	P7203	AST PC Atomix Blue 1500	14.800
4	P7204	AST PC Atomix Blue B	6.400
TOTAL			100%

PANTONE® 2757 C

1	P7218	AST PC Atomix Opaque Mix Base	82.850
2	P7217	AST PC Atomix White	2.400
3	P7199	AST PC Atomix Black	0.300
4	P7206	AST PC Atomix Violet	2.300
5	P7203	AST PC Atomix Blue 1500	12.150
TOTAL			100%

PANTONE® 2767 C

1	P7218	AST PC Atomix Opaque Mix Base	76.000
2	P7217	AST PC Atomix White	3.000
3	P7199	AST PC Atomix Black	3.500
4	P7206	AST PC Atomix Violet	1.900
5	P7203	AST PC Atomix Blue 1500	15.600
TOTAL			100%

PANTONE® 2708 C

1	P7218	AST PC Atomix Opaque Mix Base	79.840
2	P7217	AST PC Atomix White	20.000
3	P7206	AST PC Atomix Violet	0.060
4	P7203	AST PC Atomix Blue 1500	0.100
TOTAL			100%

PANTONE® 2718 C

1	P7218	AST PC Atomix Opaque Mix Base	70.380
2	P7217	AST PC Atomix White	14.000
3	P7203	AST PC Atomix Blue 1500	0.220
4	P7213	AST PC Atomix Blue RQ	15.400
TOTAL			100%

PANTONE® 2728 C

1	P7218	AST PC Atomix Opaque Mix Base	81.700
2	P7217	AST PC Atomix White	1.400
3	P7203	AST PC Atomix Blue 1500	1.900
4	P7213	AST PC Atomix Blue RQ	15.000
TOTAL			100%

PANTONE® 2738 C

1	P7218	AST PC Atomix Opaque Mix Base	78.000
2	P7206	AST PC Atomix Violet	0.850
3	P7204	AST PC Atomix Blue B	1.800
4	P7213	AST PC Atomix Blue RQ	19.350
TOTAL			100%

PANTONE® 2748 C

1	P7218	AST PC Atomix Opaque Mix Base	77.600
2	P7217	AST PC Atomix White	1.400
3	P7206	AST PC Atomix Violet	1.400
4	P7203	AST PC Atomix Blue 1500	9.600
5	P7213	AST PC Atomix Blue RQ	10.000
TOTAL			100%

PANTONE® 2758 C

1	P7218	AST PC Atomix Opaque Mix Base	79.000
2	P7217	AST PC Atomix White	2.400
3	P7199	AST PC Atomix Black	0.200
4	P7206	AST PC Atomix Violet	3.200
5	P7204	AST PC Atomix Blue B	15.200
TOTAL			100%

PANTONE® 2768 C

1	P7218	AST PC Atomix Opaque Mix Base	84.200
2	P7217	AST PC Atomix White	2.000
3	P7199	AST PC Atomix Black	1.000
4	P7206	AST PC Atomix Violet	3.600
5	P7203	AST PC Atomix Blue 1500	9.200
TOTAL			100%

PANTONE® 277 C

1	P7218	AST PC Atomix Opaque Mix Base	77.960
2	P7217	AST PC Atomix White	20.000
3	P7204	AST PC Atomix Blue B	0.120
4	P7213	AST PC Atomix Blue RQ	1.920
TOTAL			100%

PANTONE® 278 C

1	P7218	AST PC Atomix Opaque Mix Base	86.460
2	P7217	AST PC Atomix White	11.540
3	P7203	AST PC Atomix Blue 1500	0.200
4	P7213	AST PC Atomix Blue RQ	1.800
TOTAL			100%

PANTONE® 279 C

1	P7218	AST PC Atomix Opaque Mix Base	74.700
2	P7217	AST PC Atomix White	14.500
3	P7203	AST PC Atomix Blue 1500	0.800
4	P7213	AST PC Atomix Blue RQ	10.000
TOTAL			100%

PANTONE® Reflex Blue C

1	P7218	AST PC Atomix Opaque Mix Base	78.200
2	P7206	AST PC Atomix Violet	0.400
3	P7204	AST PC Atomix Blue B	2.300
4	P7213	AST PC Atomix Blue RQ	19.100
TOTAL			100%

PANTONE® 280 C

1	P7218	AST PC Atomix Opaque Mix Base	80.200
2	P7217	AST PC Atomix White	1.200
3	P7206	AST PC Atomix Violet	1.600
4	P7204	AST PC Atomix Blue B	10.000
5	P7213	AST PC Atomix Blue RQ	7.000
TOTAL			100%

PANTONE® 281 C

1	P7218	AST PC Atomix Opaque Mix Base	82.920
2	P7217	AST PC Atomix White	2.000
3	P7199	AST PC Atomix Black	0.280
4	P7203	AST PC Atomix Blue 1500	14.800
TOTAL			100%

PANTONE® 282 C

1	P7218	AST PC Atomix Opaque Mix Base	84.700
2	P7217	AST PC Atomix White	2.000
3	P7199	AST PC Atomix Black	1.400
4	P7206	AST PC Atomix Violet	1.600
5	P7203	AST PC Atomix Blue 1500	10.300
TOTAL			100%

PANTONE® 283 C

1	P7218	AST PC Atomix Opaque Mix Base	77.280
2	P7217	AST PC Atomix White	20.000
3	P7204	AST PC Atomix Blue B	0.200
4	P7213	AST PC Atomix Blue RQ	2.520
TOTAL			100%

PANTONE® 284 C

1	P7218	AST PC Atomix Opaque Mix Base	74.950
2	P7217	AST PC Atomix White	18.640
3	P7204	AST PC Atomix Blue B	0.450
4	P7213	AST PC Atomix Blue RQ	5.960
TOTAL			100%

PANTONE® 285 C

1	P7218	AST PC Atomix Opaque Mix Base	75.600
2	P7217	AST PC Atomix White	8.000
3	P7204	AST PC Atomix Blue B	2.400
4	P7213	AST PC Atomix Blue RQ	14.000
TOTAL			100%

PANTONE® 286 C

1	P7218	AST PC Atomix Opaque Mix Base	82.000
2	P7204	AST PC Atomix Blue B	2.000
3	P7213	AST PC Atomix Blue RQ	16.000
TOTAL			100%

PANTONE® 287 C

1	P7218	AST PC Atomix Opaque Mix Base	83.000
2	P7217	AST PC Atomix White	1.000
3	P7203	AST PC Atomix Blue 1500	4.800
4	P7213	AST PC Atomix Blue RQ	11.200
TOTAL			100%

PANTONE® 288 C

1	P7218	AST PC Atomix Opaque Mix Base	82.800
2	P7217	AST PC Atomix White	2.400
3	P7203	AST PC Atomix Blue 1500	8.800
4	P7204	AST PC Atomix Blue B	6.000
TOTAL			100%

PANTONE® 289 C

1	P7218	AST PC Atomix Opaque Mix Base	85.100
2	P7217	AST PC Atomix White	1.700
3	P7199	AST PC Atomix Black	1.700
4	P7206	AST PC Atomix Violet	0.300
5	P7203	AST PC Atomix Blue 1500	11.200
TOTAL			100%

PANTONE® 290 C

1	P7218	AST PC Atomix Opaque Mix Base	80.640
2	P7217	AST PC Atomix White	19.000
3	P7204	AST PC Atomix Blue B	0.090
4	P7213	AST PC Atomix Blue RQ	0.270
TOTAL			100%

PANTONE® 291 C

1	P7218	AST PC Atomix Opaque Mix Base	78.470
2	P7217	AST PC Atomix White	20.000
3	P7204	AST PC Atomix Blue B	0.180
4	P7213	AST PC Atomix Blue RQ	1.350
TOTAL			100%

PANTONE® 292 C

1	P7218	AST PC Atomix Opaque Mix Base	75.300
2	P7217	AST PC Atomix White	20.000
3	P7204	AST PC Atomix Blue B	0.600
4	P7213	AST PC Atomix Blue RQ	4.100
TOTAL			100%

PANTONE® 293 C

1	P7218	AST PC Atomix Opaque Mix Base	93.900
2	P7217	AST PC Atomix White	1.000
3	P7203	AST PC Atomix Blue 1500	2.800
4	P7204	AST PC Atomix Blue B	2.300
TOTAL			100%

PANTONE® 294 C

1	P7218	AST PC Atomix Opaque Mix Base	82.890
2	P7217	AST PC Atomix White	2.200
3	P7199	AST PC Atomix Black	0.160
4	P7206	AST PC Atomix Violet	0.350
5	P7204	AST PC Atomix Blue B	14.400
TOTAL			100%

PANTONE® 295 C

1	P7218	AST PC Atomix Opaque Mix Base	81.850
2	P7217	AST PC Atomix White	1.600
3	P7199	AST PC Atomix Black	0.550
4	P7203	AST PC Atomix Blue 1500	4.800
5	P7204	AST PC Atomix Blue B	11.200
TOTAL			100%

PANTONE® 296 C

1	P7218	AST PC Atomix Opaque Mix Base	88.800
2	P7199	AST PC Atomix Black	1.000
3	P7206	AST PC Atomix Violet	3.500
4	P7200	AST PC Atomix Green	6.700
TOTAL			100%

PANTONE® 2905 C

1	P7218	AST PC Atomix Opaque Mix Base	78.960
2	P7217	AST PC Atomix White	20.000
3	P7204	AST PC Atomix Blue B	0.320
4	P7213	AST PC Atomix Blue RQ	0.720
TOTAL			100%

PANTONE® 2915 C

1	P7218	AST PC Atomix Opaque Mix Base	79.000
2	P7217	AST PC Atomix White	20.000
3	P7206	AST PC Atomix Violet	0.050
4	P7204	AST PC Atomix Blue B	0.950
TOTAL			100%

PANTONE® 2925 C

1	P7218	AST PC Atomix Opaque Mix Base	76.640
2	P7217	AST PC Atomix White	20.000
3	P7206	AST PC Atomix Violet	0.160
4	P7204	AST PC Atomix Blue B	3.200
TOTAL			100%

PANTONE® 2935 C

1	P7218	AST PC Atomix Opaque Mix Base	96.000
2	P7203	AST PC Atomix Blue 1500	2.000
3	P7204	AST PC Atomix Blue B	2.000
TOTAL			100%

PANTONE® 2945 C

1	P7218	AST PC Atomix Opaque Mix Base	85.700
2	P7217	AST PC Atomix White	3.200
3	P7203	AST PC Atomix Blue 1500	0.300
4	P7204	AST PC Atomix Blue B	10.800
TOTAL			100%

PANTONE® 2955 C

1	P7218	AST PC Atomix Opaque Mix Base	82.040
2	P7217	AST PC Atomix White	2.400
3	P7199	AST PC Atomix Black	0.440
4	P7204	AST PC Atomix Blue B	14.800
5	P7200	AST PC Atomix Green	0.320
TOTAL			100%

PANTONE® 2965 C

1	P7218	AST PC Atomix Opaque Mix Base	80.040
2	P7217	AST PC Atomix White	2.800
3	P7199	AST PC Atomix Black	2.200
4	P7204	AST PC Atomix Blue B	14.800
5	P7200	AST PC Atomix Green	0.160
TOTAL			100%

PANTONE® 297 C

1	P7218	AST PC Atomix Opaque Mix Base	79.500
2	P7217	AST PC Atomix White	20.000
3	P7204	AST PC Atomix Blue B	0.500
TOTAL			100%

PANTONE® 298 C

1	P7218	AST PC Atomix Opaque Mix Base	92.460
2	P7217	AST PC Atomix White	7.130
3	P7204	AST PC Atomix Blue B	0.410
TOTAL			100%

PANTONE® 299 C

1	P7218	AST PC Atomix Opaque Mix Base	76.600
2	P7217	AST PC Atomix White	20.000
3	P7204	AST PC Atomix Blue B	3.400
TOTAL			100%

PANTONE® 300 C

1	P7218	AST PC Atomix Opaque Mix Base	94.640
2	P7217	AST PC Atomix White	0.800
3	P7203	AST PC Atomix Blue 1500	0.160
4	P7204	AST PC Atomix Blue B	4.400
TOTAL			100%

PANTONE® 301 C

1	P7218	AST PC Atomix Opaque Mix Base	83.600
2	P7217	AST PC Atomix White	2.800
3	P7204	AST PC Atomix Blue B	12.800
4	P7200	AST PC Atomix Green	0.800
TOTAL			100%

PANTONE® 302 C

1	P7218	AST PC Atomix Opaque Mix Base	80.400
2	P7217	AST PC Atomix White	2.400
3	P7199	AST PC Atomix Black	0.800
4	P7204	AST PC Atomix Blue B	14.400
5	P7200	AST PC Atomix Green	2.000
TOTAL			100%

PANTONE® 303 C

1	P7218	AST PC Atomix Opaque Mix Base	81.380
2	P7217	AST PC Atomix White	2.200
3	P7199	AST PC Atomix Black	1.820
4	P7204	AST PC Atomix Blue B	13.000
5	P7200	AST PC Atomix Green	1.600
TOTAL			100%

PANTONE® 2975 C

1	P7218	AST PC Atomix Opaque Mix Base	80.610
2	P7217	AST PC Atomix White	19.000
3	P7204	AST PC Atomix Blue B	0.350
4	P7200	AST PC Atomix Green	0.040
TOTAL			100%

PANTONE® 2985 C

1	P7218	AST PC Atomix Opaque Mix Base	78.720
2	P7217	AST PC Atomix White	20.000
3	P7204	AST PC Atomix Blue B	1.200
4	P7200	AST PC Atomix Green	0.080
TOTAL			100%

PANTONE® 2995 C

1	P7218	AST PC Atomix Opaque Mix Base	93.700
2	P7217	AST PC Atomix White	4.900
3	P8410	AST PC Atomix Fluo Yellow DTA FF	0.100
4	P7204	AST PC Atomix Blue B	1.300
TOTAL			100%

PANTONE® 3005 C

1	P7218	AST PC Atomix Opaque Mix Base	97.660
2	P8410	AST PC Atomix Fluo Yellow DTA FF	0.140
3	P7204	AST PC Atomix Blue B	2.200
TOTAL			100%

PANTONE® 3015 C

1	P7218	AST PC Atomix Opaque Mix Base	95.520
2	P8410	AST PC Atomix Fluo Yellow DTA FF	0.480
3	P7204	AST PC Atomix Blue B	4.000
TOTAL			100%

PANTONE® 3025 C

1	P7218	AST PC Atomix Opaque Mix Base	82.200
2	P7217	AST PC Atomix White	2.800
3	P7204	AST PC Atomix Blue B	11.200
4	P7200	AST PC Atomix Green	3.800
TOTAL			100%

PANTONE® 3035 C

1	P7218	AST PC Atomix Opaque Mix Base	82.080
2	P7217	AST PC Atomix White	2.800
3	P7199	AST PC Atomix Black	0.920
4	P7204	AST PC Atomix Blue B	10.000
5	P7200	AST PC Atomix Green	4.200
TOTAL			100%

PANTONE® 304 C

1	P7218	AST PC Atomix Opaque Mix Base	79.600
2	P7217	AST PC Atomix White	20.000
3	P7204	AST PC Atomix Blue B	0.200
4	P7200	AST PC Atomix Green	0.200
TOTAL			100%

PANTONE® 305 C

1	P7218	AST PC Atomix Opaque Mix Base	79.010
2	P7217	AST PC Atomix White	20.000
3	P7204	AST PC Atomix Blue B	0.750
4	P7200	AST PC Atomix Green	0.240
TOTAL			100%

PANTONE® 306 C

1	P7218	AST PC Atomix Opaque Mix Base	77.800
2	P7217	AST PC Atomix White	20.000
3	P7204	AST PC Atomix Blue B	1.820
4	P7200	AST PC Atomix Green	0.380
TOTAL			100%

PANTONE® Process Blue C

1	P7218	AST PC Atomix Opaque Mix Base	98.430
2	P8410	AST PC Atomix Fluo Yellow DTA FF	0.220
3	P7204	AST PC Atomix Blue B	1.350
TOTAL			100%

PANTONE® 307 C

1	P7218	AST PC Atomix Opaque Mix Base	96.700
2	P8410	AST PC Atomix Fluo Yellow DTA FF	0.600
3	P7204	AST PC Atomix Blue B	2.700
TOTAL			100%

PANTONE® 308 C

1	P7218	AST PC Atomix Opaque Mix Base	89.600
2	P7217	AST PC Atomix White	1.200
3	P7204	AST PC Atomix Blue B	6.800
4	P7200	AST PC Atomix Green	2.400
TOTAL			100%

PANTONE® 309 C

1	P7218	AST PC Atomix Opaque Mix Base	82.900
2	P7217	AST PC Atomix White	2.800
3	P7199	AST PC Atomix Black	1.100
4	P7204	AST PC Atomix Blue B	8.000
5	P7200	AST PC Atomix Green	5.200
TOTAL			100%

PANTONE® 310 C

1	P7218	AST PC Atomix Opaque Mix Base	88.640
2	P7217	AST PC Atomix White	10.800
3	P7204	AST PC Atomix Blue B	0.360
4	P7200	AST PC Atomix Green	0.200
TOTAL			100%

PANTONE® 311 C

1	P7218	AST PC Atomix Opaque Mix Base	91.080
2	P7217	AST PC Atomix White	8.000
3	P7204	AST PC Atomix Blue B	0.640
4	P7200	AST PC Atomix Green	0.280
TOTAL			100%

PANTONE® 312 C

1	P7218	AST PC Atomix Opaque Mix Base	97.050
2	P7217	AST PC Atomix White	1.200
3	P8410	AST PC Atomix Fluo Yellow DTA FF	0.550
4	P7204	AST PC Atomix Blue B	1.200
TOTAL			100%

PANTONE® 313 C

1	P7218	AST PC Atomix Opaque Mix Base	97.360
2	P8410	AST PC Atomix Fluo Yellow DTA FF	0.740
3	P7204	AST PC Atomix Blue B	1.900
TOTAL			100%

PANTONE® 314 C

1	P7218	AST PC Atomix Opaque Mix Base	96.200
2	P7217	AST PC Atomix White	0.500
3	P7204	AST PC Atomix Blue B	2.200
4	P7200	AST PC Atomix Green	1.100
TOTAL			100%

PANTONE® 315 C

1	P7218	AST PC Atomix Opaque Mix Base	89.100
2	P7217	AST PC Atomix White	1.900
3	P7204	AST PC Atomix Blue B	5.400
4	P7200	AST PC Atomix Green	3.600
TOTAL			100%

PANTONE® 316 C

1	P7218	AST PC Atomix Opaque Mix Base	85.700
2	P7199	AST PC Atomix Black	0.200
3	P7204	AST PC Atomix Blue B	7.050
4	P7200	AST PC Atomix Green	7.050
TOTAL			100%

PANTONE® 3105 C

1	P7218	AST PC Atomix Opaque Mix Base	84.980
2	P7217	AST PC Atomix White	14.000
3	P8410	AST PC Atomix Fluo Yellow DTA FF	0.500
4	P7204	AST PC Atomix Blue B	0.520
TOTAL			100%

PANTONE® 3115 C

1	P7218	AST PC Atomix Opaque Mix Base	86.050
2	P7217	AST PC Atomix White	11.500
3	P8410	AST PC Atomix Fluo Yellow DTA FF	1.200
4	P7204	AST PC Atomix Blue B	1.250
TOTAL			100%

PANTONE® 3125 C

1	P7218	AST PC Atomix Opaque Mix Base	97.020
2	P7217	AST PC Atomix White	1.200
3	P8410	AST PC Atomix Fluo Yellow DTA FF	0.780
4	P7204	AST PC Atomix Blue B	1.000
TOTAL			100%

PANTONE® 3135 C

1	P7218	AST PC Atomix Opaque Mix Base	95.470
2	P7217	AST PC Atomix White	0.500
3	P8410	AST PC Atomix Fluo Yellow DTA FF	1.630
4	P7204	AST PC Atomix Blue B	2.400
TOTAL			100%

PANTONE® 3145 C

1	P7218	AST PC Atomix Opaque Mix Base	95.500
2	P7204	AST PC Atomix Blue B	2.520
3	P7200	AST PC Atomix Green	1.980
TOTAL			100%

PANTONE® 3155 C

1	P7218	AST PC Atomix Opaque Mix Base	88.400
2	P7217	AST PC Atomix White	1.200
3	P7204	AST PC Atomix Blue B	5.200
4	P7200	AST PC Atomix Green	5.200
TOTAL			100%

PANTONE® 3165 C

1	P7218	AST PC Atomix Opaque Mix Base	85.500
2	P7204	AST PC Atomix Blue B	6.700
3	P7200	AST PC Atomix Green	7.800
TOTAL			100%

PANTONE® 317 C

1	P7218	AST PC Atomix Opaque Mix Base	84.780
2	P7217	AST PC Atomix White	14.800
3	P8410	AST PC Atomix Fluo Yellow DTA FF	0.300
4	P7204	AST PC Atomix Blue B	0.120
TOTAL			100%

PANTONE® 318 C

1	P7218	AST PC Atomix Opaque Mix Base	87.030
2	P7217	AST PC Atomix White	12.400
3	P8410	AST PC Atomix Fluo Yellow DTA FF	0.420
4	P7204	AST PC Atomix Blue B	0.150
TOTAL			100%

PANTONE® 319 C

1	P7218	AST PC Atomix Opaque Mix Base	87.170
2	P7217	AST PC Atomix White	10.500
3	P8410	AST PC Atomix Fluo Yellow DTA FF	1.450
4	P7204	AST PC Atomix Blue B	0.880
TOTAL			100%

PANTONE® 320 C

1	P7218	AST PC Atomix Opaque Mix Base	95.500
2	P7217	AST PC Atomix White	0.900
3	P8410	AST PC Atomix Fluo Yellow DTA FF	2.000
4	P7204	AST PC Atomix Blue B	1.600
TOTAL			100%

PANTONE® 321 C

1	P7218	AST PC Atomix Opaque Mix Base	92.300
2	P7217	AST PC Atomix White	0.800
3	P8410	AST PC Atomix Fluo Yellow DTA FF	3.900
4	P7204	AST PC Atomix Blue B	3.000
TOTAL			100%

PANTONE® 322 C

1	P7218	AST PC Atomix Opaque Mix Base	92.390
2	P7217	AST PC Atomix White	1.150
3	P7204	AST PC Atomix Blue B	2.560
4	P7200	AST PC Atomix Green	3.900
TOTAL			100%

PANTONE® 323 C

1	P7218	AST PC Atomix Opaque Mix Base	85.870
2	P7217	AST PC Atomix White	1.000
3	P7204	AST PC Atomix Blue B	4.500
4	P7200	AST PC Atomix Green	8.630
TOTAL			100%

PANTONE® 324 C

1	P7218	AST PC Atomix Opaque Mix Base	81.010
2	P7217	AST PC Atomix White	18.500
3	P7204	AST PC Atomix Blue B	0.090
4	P7200	AST PC Atomix Green	0.400
TOTAL			100%

PANTONE® 325 C

1	P7218	AST PC Atomix Opaque Mix Base	91.020
2	P7217	AST PC Atomix White	8.100
3	P7204	AST PC Atomix Blue B	0.200
4	P7200	AST PC Atomix Green	0.680
TOTAL			100%

PANTONE® 326 C

1	P7218	AST PC Atomix Opaque Mix Base	90.840
2	P7217	AST PC Atomix White	6.600
3	P7204	AST PC Atomix Blue B	0.460
4	P7200	AST PC Atomix Green	2.100
TOTAL			100%

PANTONE® 327 C

1	P7218	AST PC Atomix Opaque Mix Base	96.050
2	P7204	AST PC Atomix Blue B	0.500
3	P7200	AST PC Atomix Green	3.450
TOTAL			100%

PANTONE® 328 C

1	P7218	AST PC Atomix Opaque Mix Base	87.900
2	P7217	AST PC Atomix White	1.500
3	P7204	AST PC Atomix Blue B	1.400
4	P7200	AST PC Atomix Green	9.200
TOTAL			100%

PANTONE® 329 C

1	P7218	AST PC Atomix Opaque Mix Base	86.400
2	P7217	AST PC Atomix White	2.400
3	P7199	AST PC Atomix Black	0.200
4	P7204	AST PC Atomix Blue B	1.400
5	P7200	AST PC Atomix Green	9.600
TOTAL			100%

PANTONE® 330 C

1	P7218	AST PC Atomix Opaque Mix Base	84.600
2	P7217	AST PC Atomix White	2.400
3	P7199	AST PC Atomix Black	1.000
4	P7200	AST PC Atomix Green	12.000
TOTAL			100%

PANTONE® 3242 C

1	P7218	AST PC Atomix Opaque Mix Base	83.290
2	P7217	AST PC Atomix White	15.650
3	P8410	AST PC Atomix Fluo Yellow DTA FF	0.560
4	P7204	AST PC Atomix Blue B	0.500
TOTAL			100%

PANTONE® 3252 C

1	P7218	AST PC Atomix Opaque Mix Base	94.180
2	P7217	AST PC Atomix White	5.000
3	P7204	AST PC Atomix Blue B	0.140
4	P7200	AST PC Atomix Green	0.680
TOTAL			100%

PANTONE® 3262 C

1	P7218	AST PC Atomix Opaque Mix Base	93.850
2	P7217	AST PC Atomix White	4.000
3	P7204	AST PC Atomix Blue B	0.300
4	P7200	AST PC Atomix Green	1.850
TOTAL			100%

PANTONE® 3272 C

1	P7218	AST PC Atomix Opaque Mix Base	95.550
2	P8410	AST PC Atomix Fluo Yellow DTA FF	2.850
3	P7204	AST PC Atomix Blue B	1.600
TOTAL			100%

PANTONE® 3282 C

1	P7218	AST PC Atomix Opaque Mix Base	94.000
2	P7217	AST PC Atomix White	0.800
3	P7204	AST PC Atomix Blue B	0.800
4	P7200	AST PC Atomix Green	4.400
TOTAL			100%

PANTONE® 3292 C

1	P7218	AST PC Atomix Opaque Mix Base	85.540
2	P7217	AST PC Atomix White	2.210
3	P7199	AST PC Atomix Black	0.440
4	P7204	AST PC Atomix Blue B	0.740
5	P7200	AST PC Atomix Green	11.070
TOTAL			100%

PANTONE® 3302 C

1	P7218	AST PC Atomix Opaque Mix Base	84.400
2	P7217	AST PC Atomix White	2.400
3	P7199	AST PC Atomix Black	1.200
4	P7200	AST PC Atomix Green	12.000
TOTAL			100%

PANTONE® 3245 C

1	P7218	AST PC Atomix Opaque Mix Base	79.880
2	P7217	AST PC Atomix White	18.000
3	P8410	AST PC Atomix Fluo Yellow DTA FF	1.700
4	P7199	AST PC Atomix Black	0.020
5	P7204	AST PC Atomix Blue B	0.400
TOTAL			100%

PANTONE® 3255 C

1	P7218	AST PC Atomix Opaque Mix Base	76.200
2	P7217	AST PC Atomix White	17.500
3	P8410	AST PC Atomix Fluo Yellow DTA FF	5.200
4	P7204	AST PC Atomix Blue B	1.100
TOTAL			100%

PANTONE® 3265 C

1	P7218	AST PC Atomix Opaque Mix Base	93.740
2	P7217	AST PC Atomix White	4.500
3	P7204	AST PC Atomix Blue B	0.080
4	P7200	AST PC Atomix Green	1.680
TOTAL			100%

PANTONE® 3275 C

1	P7218	AST PC Atomix Opaque Mix Base	94.200
2	P7217	AST PC Atomix White	1.400
3	P7204	AST PC Atomix Blue B	2.800
4	P7200	AST PC Atomix Green	1.600
TOTAL			100%

PANTONE® 3285 C

1	P7218	AST PC Atomix Opaque Mix Base	86.760
2	P7217	AST PC Atomix White	4.400
3	P7204	AST PC Atomix Blue B	0.600
4	P7200	AST PC Atomix Green	8.240
TOTAL			100%

PANTONE® 3295 C

1	P7218	AST PC Atomix Opaque Mix Base	81.800
2	P7217	AST PC Atomix White	3.600
3	P7199	AST PC Atomix Black	0.220
4	P7204	AST PC Atomix Blue B	0.300
5	P7200	AST PC Atomix Green	14.080
TOTAL			100%

PANTONE® 3305 C

1	P7218	AST PC Atomix Opaque Mix Base	84.100
2	P7217	AST PC Atomix White	1.600
3	P7199	AST PC Atomix Black	1.400
4	P7200	AST PC Atomix Green	12.000
5	P7208	AST PC Atomix Lemon MX	0.900
TOTAL			100%

PANTONE® 3248 C

1	P7218	AST PC Atomix Opaque Mix Base	81.450
2	P7217	AST PC Atomix White	17.600
3	P7199	AST PC Atomix Black	0.030
4	P7204	AST PC Atomix Blue B	0.020
5	P7200	AST PC Atomix Green	0.900
TOTAL			100%

PANTONE® 3258 C

1	P7218	AST PC Atomix Opaque Mix Base	77.550
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.030
4	P7204	AST PC Atomix Blue B	0.020
5	P7200	AST PC Atomix Green	2.400
TOTAL			100%

PANTONE® 3268 C

1	P7218	AST PC Atomix Opaque Mix Base	73.490
2	P7217	AST PC Atomix White	18.000
3	P7204	AST PC Atomix Blue B	0.110
4	P7200	AST PC Atomix Green	8.400
TOTAL			100%

PANTONE® 3278 C

1	P7218	AST PC Atomix Opaque Mix Base	96.270
2	P7204	AST PC Atomix Blue B	0.230
3	P7200	AST PC Atomix Green	3.500
TOTAL			100%

PANTONE® 3288 C

1	P7218	AST PC Atomix Opaque Mix Base	88.400
2	P7217	AST PC Atomix White	2.000
3	P7204	AST PC Atomix Blue B	0.400
4	P7200	AST PC Atomix Green	9.200
TOTAL			100%

PANTONE® 3298 C

1	P7218	AST PC Atomix Opaque Mix Base	86.840
2	P7217	AST PC Atomix White	2.000
3	P7199	AST PC Atomix Black	0.280
4	P7204	AST PC Atomix Blue B	0.080
5	P7200	AST PC Atomix Green	10.800
TOTAL			100%

PANTONE® 3308 C

1	P7218	AST PC Atomix Opaque Mix Base	82.400
2	P7217	AST PC Atomix White	2.400
3	P7199	AST PC Atomix Black	2.000
4	P7200	AST PC Atomix Green	12.000
5	P7208	AST PC Atomix Lemon MX	1.200
TOTAL			100%

PANTONE® 331 C

1	P7218	AST PC Atomix Opaque Mix Base	79.120
2	P7217	AST PC Atomix White	19.500
3	P8410	AST PC Atomix Fluo Yellow DTA FF	1.200
4	P7199	AST PC Atomix Black	0.020
5	P7204	AST PC Atomix Blue B	0.160
TOTAL			100%

PANTONE® 332 C

1	P7218	AST PC Atomix Opaque Mix Base	83.200
2	P7217	AST PC Atomix White	15.000
3	P8410	AST PC Atomix Fluo Yellow DTA FF	1.500
4	P7204	AST PC Atomix Blue B	0.300
TOTAL			100%

PANTONE® 333 C

1	P7218	AST PC Atomix Opaque Mix Base	77.650
2	P7217	AST PC Atomix White	20.000
3	P8410	AST PC Atomix Fluo Yellow DTA FF	0.250
4	P7200	AST PC Atomix Green	2.100
TOTAL			100%

PANTONE® Green C

1	P7218	AST PC Atomix Opaque Mix Base	96.900
2	P7217	AST PC Atomix White	0.300
3	P8410	AST PC Atomix Fluo Yellow DTA FF	0.250
4	P7200	AST PC Atomix Green	2.550
TOTAL			100%

PANTONE® 334 C

1	P7218	AST PC Atomix Opaque Mix Base	94.100
2	P7217	AST PC Atomix White	0.800
3	P7200	AST PC Atomix Green	5.000
4	P7208	AST PC Atomix Lemon MX	0.100
TOTAL			100%

PANTONE® 335 C

1	P7218	AST PC Atomix Opaque Mix Base	84.880
2	P7217	AST PC Atomix White	2.300
3	P7199	AST PC Atomix Black	0.170
4	P7200	AST PC Atomix Green	12.000
5	P7208	AST PC Atomix Lemon MX	0.650
TOTAL			100%

PANTONE® 336 C

1	P7218	AST PC Atomix Opaque Mix Base	84.720
2	P7217	AST PC Atomix White	2.000
3	P7199	AST PC Atomix Black	0.480
4	P7200	AST PC Atomix Green	12.000
5	P7208	AST PC Atomix Lemon MX	0.800
TOTAL			100%

PANTONE® 337 C

1	P7218	AST PC Atomix Opaque Mix Base	79.780
2	P7217	AST PC Atomix White	19.200
3	P7199	AST PC Atomix Black	0.040
4	P7200	AST PC Atomix Green	0.900
5	P7208	AST PC Atomix Lemon MX	0.080
TOTAL			100%

PANTONE® 338 C

1	P7218	AST PC Atomix Opaque Mix Base	78.040
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.060
4	P7200	AST PC Atomix Green	1.800
5	P7208	AST PC Atomix Lemon MX	0.100
TOTAL			100%

PANTONE® 339 C

1	P7218	AST PC Atomix Opaque Mix Base	86.420
2	P7217	AST PC Atomix White	9.000
3	P7199	AST PC Atomix Black	0.080
4	P7200	AST PC Atomix Green	4.200
5	P7208	AST PC Atomix Lemon MX	0.300
TOTAL			100%

PANTONE® 340 C

1	P7218	AST PC Atomix Opaque Mix Base	87.800
2	P7217	AST PC Atomix White	3.900
3	P7200	AST PC Atomix Green	7.800
4	P7208	AST PC Atomix Lemon MX	0.500
TOTAL			100%

PANTONE® 341 C

1	P7218	AST PC Atomix Opaque Mix Base	84.630
2	P7217	AST PC Atomix White	3.000
3	P7199	AST PC Atomix Black	0.170
4	P7200	AST PC Atomix Green	11.200
5	P7208	AST PC Atomix Lemon MX	1.000
TOTAL			100%

PANTONE® 342 C

1	P7218	AST PC Atomix Opaque Mix Base	84.740
2	P7217	AST PC Atomix White	2.000
3	P7199	AST PC Atomix Black	0.360
4	P7200	AST PC Atomix Green	12.000
5	P7208	AST PC Atomix Lemon MX	0.900
TOTAL			100%

PANTONE® 343 C

1	P7218	AST PC Atomix Opaque Mix Base	82.880
2	P7217	AST PC Atomix White	2.000
3	P7199	AST PC Atomix Black	1.120
4	P7200	AST PC Atomix Green	12.000
5	P7208	AST PC Atomix Lemon MX	2.000
TOTAL			100%

PANTONE® 3375 C

1	P7218	AST PC Atomix Opaque Mix Base	99.320
2	P8410	AST PC Atomix Fluo Yellow DTA FF	0.300
3	P7213	AST PC Atomix Blue RQ	0.200
4	P7200	AST PC Atomix Green	0.180
TOTAL			100%

PANTONE® 3385 C

1	P7218	AST PC Atomix Opaque Mix Base	76.890
2	P7217	AST PC Atomix White	15.200
3	P8410	AST PC Atomix Fluo Yellow DTA FF	7.000
4	P7199	AST PC Atomix Black	0.010
5	P7204	AST PC Atomix Blue B	0.900
TOTAL			100%

PANTONE® 3395 C

1	P7218	AST PC Atomix Opaque Mix Base	88.880
2	P7217	AST PC Atomix White	4.000
3	P8410	AST PC Atomix Fluo Yellow DTA FF	4.700
4	P7199	AST PC Atomix Black	0.030
5	P7200	AST PC Atomix Green	2.390
TOTAL			100%

PANTONE® 3405 C

1	P7218	AST PC Atomix Opaque Mix Base	81.200
2	P7217	AST PC Atomix White	2.000
3	P7200	AST PC Atomix Green	5.200
4	P7208	AST PC Atomix Lemon MX	11.600
TOTAL			100%

PANTONE® 3415 C

1	P7218	AST PC Atomix Opaque Mix Base	84.900
2	P7217	AST PC Atomix White	2.400
3	P7199	AST PC Atomix Black	0.200
4	P7200	AST PC Atomix Green	10.300
5	P7208	AST PC Atomix Lemon MX	2.200
TOTAL			100%

PANTONE® 3425 C

1	P7218	AST PC Atomix Opaque Mix Base	81.650
2	P7217	AST PC Atomix White	1.950
3	P7199	AST PC Atomix Black	0.600
4	P7200	AST PC Atomix Green	12.200
5	P7208	AST PC Atomix Lemon MX	3.600
TOTAL			100%

PANTONE® 3435 C

1	P7218	AST PC Atomix Opaque Mix Base	81.400
2	P7217	AST PC Atomix White	1.000
3	P7199	AST PC Atomix Black	1.500
4	P7200	AST PC Atomix Green	12.100
5	P7208	AST PC Atomix Lemon MX	4.000
TOTAL			100%

PANTONE® 344 C

1	P7218	AST PC Atomix Opaque Mix Base	83.490
2	P7217	AST PC Atomix White	16.000
3	P7199	AST PC Atomix Black	0.050
4	P7200	AST PC Atomix Green	0.350
5	P7208	AST PC Atomix Lemon MX	0.110
TOTAL			100%

PANTONE® 345 C

1	P7218	AST PC Atomix Opaque Mix Base	83.420
2	P7217	AST PC Atomix White	15.500
3	P7199	AST PC Atomix Black	0.040
4	P7200	AST PC Atomix Green	0.800
5	P7208	AST PC Atomix Lemon MX	0.240
TOTAL			100%

PANTONE® 346 C

1	P7218	AST PC Atomix Opaque Mix Base	81.910
2	P7217	AST PC Atomix White	15.800
3	P7199	AST PC Atomix Black	0.050
4	P7200	AST PC Atomix Green	1.600
5	P7208	AST PC Atomix Lemon MX	0.640
TOTAL			100%

PANTONE® 347 C

1	P7218	AST PC Atomix Opaque Mix Base	90.600
2	P7217	AST PC Atomix White	2.600
3	P7200	AST PC Atomix Green	4.900
4	P7208	AST PC Atomix Lemon MX	1.900
TOTAL			100%

PANTONE® 348 C

1	P7218	AST PC Atomix Opaque Mix Base	88.960
2	P7217	AST PC Atomix White	1.800
3	P7199	AST PC Atomix Black	0.040
4	P7200	AST PC Atomix Green	6.500
5	P7208	AST PC Atomix Lemon MX	2.700
TOTAL			100%

PANTONE® 349 C

1	P7218	AST PC Atomix Opaque Mix Base	81.650
2	P7217	AST PC Atomix White	1.900
3	P7199	AST PC Atomix Black	0.550
4	P7200	AST PC Atomix Green	10.000
5	P7208	AST PC Atomix Lemon MX	5.900
TOTAL			100%

PANTONE® 350 C

1	P7218	AST PC Atomix Opaque Mix Base	81.400
2	P7217	AST PC Atomix White	1.200
3	P7199	AST PC Atomix Black	2.100
4	P7200	AST PC Atomix Green	6.800
5	P7208	AST PC Atomix Lemon MX	8.500
TOTAL			100%

PANTONE® 351 C

1	P7218	AST PC Atomix Opaque Mix Base	79.140
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.010
4	P7200	AST PC Atomix Green	0.520
5	P7208	AST PC Atomix Lemon MX	0.330
TOTAL			100%

PANTONE® 352 C

1	P7218	AST PC Atomix Opaque Mix Base	83.260
2	P7217	AST PC Atomix White	16.000
3	P7200	AST PC Atomix Green	0.500
4	P7208	AST PC Atomix Lemon MX	0.240
TOTAL			100%

PANTONE® 353 C

1	P7218	AST PC Atomix Opaque Mix Base	78.380
2	P7217	AST PC Atomix White	20.000
3	P7200	AST PC Atomix Green	1.020
4	P7208	AST PC Atomix Lemon MX	0.600
TOTAL			100%

PANTONE® 354 C

1	P7218	AST PC Atomix Opaque Mix Base	80.920
2	P7217	AST PC Atomix White	2.400
3	P8410	AST PC Atomix Fluo Yellow DTA FF	11.070
4	P7200	AST PC Atomix Green	3.530
5	P7208	AST PC Atomix Lemon MX	2.080
TOTAL			100%

PANTONE® 355 C

1	P7218	AST PC Atomix Opaque Mix Base	88.300
2	P7217	AST PC Atomix White	3.500
3	P7200	AST PC Atomix Green	4.800
4	P7208	AST PC Atomix Lemon MX	3.400
TOTAL			100%

PANTONE® 356 C

1	P7218	AST PC Atomix Opaque Mix Base	85.730
2	P7217	AST PC Atomix White	2.800
3	P7199	AST PC Atomix Black	0.270
4	P7200	AST PC Atomix Green	6.000
5	P7208	AST PC Atomix Lemon MX	5.200
TOTAL			100%

PANTONE® 357 C

1	P7218	AST PC Atomix Opaque Mix Base	82.750
2	P7217	AST PC Atomix White	2.100
3	P7199	AST PC Atomix Black	1.700
4	P7200	AST PC Atomix Green	6.200
5	P7208	AST PC Atomix Lemon MX	7.250
TOTAL			100%

PANTONE® 358 C

1	P7218	AST PC Atomix Opaque Mix Base	78.580
2	P7217	AST PC Atomix White	20.000
3	P7200	AST PC Atomix Green	0.500
4	P8258	AST PC Atomix Yellow II	0.480
5	P7208	AST PC Atomix Lemon MX	0.440
TOTAL			100%

PANTONE® 359 C

1	P7218	AST PC Atomix Opaque Mix Base	77.900
2	P7217	AST PC Atomix White	20.000
3	P7200	AST PC Atomix Green	0.780
4	P8258	AST PC Atomix Yellow II	0.680
5	P7208	AST PC Atomix Lemon MX	0.640
TOTAL			100%

PANTONE® 360 C

1	P7218	AST PC Atomix Opaque Mix Base	75.420
2	P7217	AST PC Atomix White	14.000
3	P7200	AST PC Atomix Green	2.520
4	P8258	AST PC Atomix Yellow II	0.260
5	P7208	AST PC Atomix Lemon MX	7.800
TOTAL			100%

PANTONE® 361 C

1	P7218	AST PC Atomix Opaque Mix Base	77.720
2	P7217	AST PC Atomix White	8.000
3	P7200	AST PC Atomix Green	3.360
4	P8258	AST PC Atomix Yellow II	0.420
5	P7208	AST PC Atomix Lemon MX	10.500
TOTAL			100%

PANTONE® 362 C

1	P7218	AST PC Atomix Opaque Mix Base	79.550
2	P7217	AST PC Atomix White	4.000
3	P7200	AST PC Atomix Green	3.400
4	P8258	AST PC Atomix Yellow II	2.250
5	P7208	AST PC Atomix Lemon MX	10.800
TOTAL			100%

PANTONE® 363 C

1	P7218	AST PC Atomix Opaque Mix Base	73.450
2	P7217	AST PC Atomix White	3.160
3	P7199	AST PC Atomix Black	0.050
4	P7200	AST PC Atomix Green	3.620
5	P8258	AST PC Atomix Yellow II	5.610
6	P7208	AST PC Atomix Lemon MX	14.110
TOTAL			100%

PANTONE® 364 C

1	P7218	AST PC Atomix Opaque Mix Base	74.400
2	P7217	AST PC Atomix White	4.000
3	P7200	AST PC Atomix Green	4.850
4	P8258	AST PC Atomix Yellow II	16.750
TOTAL			100%

PANTONE® 365 C

1	P7218	AST PC Atomix Opaque Mix Base	79.590
2	P7217	AST PC Atomix White	20.000
3	P8410	AST PC Atomix Fluo Yellow DTA FF	0.250
4	P7203	AST PC Atomix Blue 1500	0.160
TOTAL			100%

PANTONE® 366 C

1	P7218	AST PC Atomix Opaque Mix Base	82.640
2	P7217	AST PC Atomix White	16.000
3	P7200	AST PC Atomix Green	0.240
4	P8258	AST PC Atomix Yellow II	0.120
5	P7208	AST PC Atomix Lemon MX	1.000
TOTAL			100%

PANTONE® 367 C

1	P7218	AST PC Atomix Opaque Mix Base	83.920
2	P7217	AST PC Atomix White	12.000
3	P7200	AST PC Atomix Green	0.560
4	P8258	AST PC Atomix Yellow II	0.320
5	P7208	AST PC Atomix Lemon MX	3.200
TOTAL			100%

PANTONE® 368 C

1	P7218	AST PC Atomix Opaque Mix Base	89.080
2	P7217	AST PC Atomix White	4.100
3	P7200	AST PC Atomix Green	1.050
4	P8258	AST PC Atomix Yellow II	0.520
5	P7208	AST PC Atomix Lemon MX	5.250
TOTAL			100%

PANTONE® 369 C

1	P7218	AST PC Atomix Opaque Mix Base	88.150
2	P7217	AST PC Atomix White	3.200
3	P7200	AST PC Atomix Green	1.300
4	P8258	AST PC Atomix Yellow II	2.550
5	P7208	AST PC Atomix Lemon MX	4.800
TOTAL			100%

PANTONE® 370 C

1	P7218	AST PC Atomix Opaque Mix Base	86.800
2	P7217	AST PC Atomix White	1.500
3	P7200	AST PC Atomix Green	1.300
4	P8258	AST PC Atomix Yellow II	10.400
TOTAL			100%

PANTONE® 371 C

1	P7218	AST PC Atomix Opaque Mix Base	85.090
2	P7217	AST PC Atomix White	1.600
3	P7199	AST PC Atomix Black	0.480
4	P7200	AST PC Atomix Green	1.630
5	P8258	AST PC Atomix Yellow II	11.200
TOTAL			100%

PANTONE® 372 C

1	P7218	AST PC Atomix Opaque Mix Base	80.240
2	P7217	AST PC Atomix White	19.000
3	P7200	AST PC Atomix Green	0.080
4	P7208	AST PC Atomix Lemon MX	0.680
TOTAL			100%

PANTONE® 373 C

1	P7218	AST PC Atomix Opaque Mix Base	80.980
2	P7217	AST PC Atomix White	18.000
3	P7200	AST PC Atomix Green	0.120
4	P7208	AST PC Atomix Lemon MX	0.900
TOTAL			100%

PANTONE® 374 C

1	P7218	AST PC Atomix Opaque Mix Base	80.900
2	P7217	AST PC Atomix White	17.100
3	P7200	AST PC Atomix Green	0.200
4	P7208	AST PC Atomix Lemon MX	1.800
TOTAL			100%

PANTONE® 375 C

1	P7218	AST PC Atomix Opaque Mix Base	83.700
2	P7217	AST PC Atomix White	9.000
3	P7200	AST PC Atomix Green	0.700
4	P7208	AST PC Atomix Lemon MX	6.600
TOTAL			100%

PANTONE® 376 C

1	P7218	AST PC Atomix Opaque Mix Base	78.290
2	P7217	AST PC Atomix White	4.040
3	P7200	AST PC Atomix Green	0.930
4	P8258	AST PC Atomix Yellow II	0.830
5	P7208	AST PC Atomix Lemon MX	15.910
TOTAL			100%

PANTONE® 377 C

1	P7218	AST PC Atomix Opaque Mix Base	86.350
2	P7217	AST PC Atomix White	2.000
3	P7200	AST PC Atomix Green	1.050
4	P8258	AST PC Atomix Yellow II	10.600
TOTAL			100%

PANTONE® 378 C

1	P7218	AST PC Atomix Opaque Mix Base	85.680
2	P7217	AST PC Atomix White	1.600
3	P7199	AST PC Atomix Black	0.520
4	P7200	AST PC Atomix Green	1.000
5	P8258	AST PC Atomix Yellow II	11.200
TOTAL			100%

PANTONE® 379 C

1	P7218	AST PC Atomix Opaque Mix Base	78.140
2	P7217	AST PC Atomix White	20.000
3	P7200	AST PC Atomix Green	0.060
4	P7208	AST PC Atomix Lemon MX	1.800
TOTAL			100%

PANTONE® 380 C

1	P7218	AST PC Atomix Opaque Mix Base	75.450
2	P7217	AST PC Atomix White	20.000
3	P7200	AST PC Atomix Green	0.120
4	P7208	AST PC Atomix Lemon MX	4.430
TOTAL			100%

PANTONE® 381 C

1	P7218	AST PC Atomix Opaque Mix Base	71.360
2	P7217	AST PC Atomix White	19.200
3	P7200	AST PC Atomix Green	0.240
4	P7208	AST PC Atomix Lemon MX	9.200
TOTAL			100%

PANTONE® 382 C

1	P7218	AST PC Atomix Opaque Mix Base	75.420
2	P7217	AST PC Atomix White	12.000
3	P7200	AST PC Atomix Green	0.280
4	P7208	AST PC Atomix Lemon MX	12.300
TOTAL			100%

PANTONE® 383 C

1	P7218	AST PC Atomix Opaque Mix Base	84.770
2	P7217	AST PC Atomix White	4.000
3	P7200	AST PC Atomix Green	0.530
4	P8258	AST PC Atomix Yellow II	7.400
5	P7208	AST PC Atomix Lemon MX	3.300
TOTAL			100%

PANTONE® 384 C

1	P7218	AST PC Atomix Opaque Mix Base	80.060
2	P7217	AST PC Atomix White	4.000
3	P7199	AST PC Atomix Black	0.130
4	P7200	AST PC Atomix Green	0.610
5	P8258	AST PC Atomix Yellow II	11.200
6	P7208	AST PC Atomix Lemon MX	4.000
TOTAL			100%

PANTONE® 385 C

1	P7218	AST PC Atomix Opaque Mix Base	88.400
2	P7199	AST PC Atomix Black	0.250
3	P7200	AST PC Atomix Green	0.350
4	P8258	AST PC Atomix Yellow II	11.000
TOTAL			100%

PANTONE® 386 C

1	P7218	AST PC Atomix Opaque Mix Base	78.200
2	P7217	AST PC Atomix White	20.000
3	P7200	AST PC Atomix Green	0.050
4	P7208	AST PC Atomix Lemon MX	1.750
TOTAL			100%

PANTONE® 387 C

1	P7218	AST PC Atomix Opaque Mix Base	75.210
2	P7217	AST PC Atomix White	20.000
3	P7200	AST PC Atomix Green	0.090
4	P7208	AST PC Atomix Lemon MX	4.700
TOTAL			100%

PANTONE® 388 C

1	P7218	AST PC Atomix Opaque Mix Base	75.790
2	P7217	AST PC Atomix White	19.000
3	P7200	AST PC Atomix Green	0.110
4	P7208	AST PC Atomix Lemon MX	5.100
TOTAL			100%

PANTONE® 389 C

1	P7218	AST PC Atomix Opaque Mix Base	75.230
2	P7217	AST PC Atomix White	15.000
3	P7200	AST PC Atomix Green	0.210
4	P7208	AST PC Atomix Lemon MX	9.560
TOTAL			100%

PANTONE® 390 C

1	P7218	AST PC Atomix Opaque Mix Base	75.450
2	P7217	AST PC Atomix White	10.000
3	P7200	AST PC Atomix Green	0.250
4	P8258	AST PC Atomix Yellow II	1.300
5	P7208	AST PC Atomix Lemon MX	13.000
TOTAL			100%

PANTONE® 391 C

1	P7218	AST PC Atomix Opaque Mix Base	79.530
2	P7217	AST PC Atomix White	5.500
3	P7199	AST PC Atomix Black	0.120
4	P7200	AST PC Atomix Green	0.550
5	P8258	AST PC Atomix Yellow II	14.300
TOTAL			100%

PANTONE® 392 C

1	P7218	AST PC Atomix Opaque Mix Base	79.300
2	P7217	AST PC Atomix White	3.400
3	P7199	AST PC Atomix Black	0.300
4	P7200	AST PC Atomix Green	0.600
5	P8258	AST PC Atomix Yellow II	16.400
TOTAL			100%

PANTONE® 393 C

1	P7218	AST PC Atomix Opaque Mix Base	83.190
2	P7217	AST PC Atomix White	10.000
3	P8410	AST PC Atomix Fluo Yellow DTA FF	6.300
4	P7199	AST PC Atomix Black	0.010
5	P8258	AST PC Atomix Yellow II	0.500
TOTAL			100%

PANTONE® 394 C

1	P7218	AST PC Atomix Opaque Mix Base	75.580
2	P7217	AST PC Atomix White	15.000
3	P8410	AST PC Atomix Fluo Yellow DTA FF	5.000
4	P7200	AST PC Atomix Green	0.020
5	P7208	AST PC Atomix Lemon MX	4.400
TOTAL			100%

PANTONE® 395 C

1	P7218	AST PC Atomix Opaque Mix Base	78.510
2	P7217	AST PC Atomix White	12.000
3	P8410	AST PC Atomix Fluo Yellow DTA FF	4.500
4	P7200	AST PC Atomix Green	0.030
5	P7208	AST PC Atomix Lemon MX	4.960
TOTAL			100%

PANTONE® 396 C

1	P7218	AST PC Atomix Opaque Mix Base	88.740
2	P7217	AST PC Atomix White	1.000
3	P8410	AST PC Atomix Fluo Yellow DTA FF	1.600
4	P7200	AST PC Atomix Green	0.060
5	P7208	AST PC Atomix Lemon MX	8.600
TOTAL			100%

PANTONE® 397 C

1	P7218	AST PC Atomix Opaque Mix Base	77.520
2	P7217	AST PC Atomix White	3.680
3	P7200	AST PC Atomix Green	0.280
4	P8258	AST PC Atomix Yellow II	6.120
5	P7208	AST PC Atomix Lemon MX	12.400
TOTAL			100%

PANTONE® 398 C

1	P7218	AST PC Atomix Opaque Mix Base	75.530
2	P7217	AST PC Atomix White	4.500
3	P7199	AST PC Atomix Black	0.020
4	P7200	AST PC Atomix Green	0.350
5	P8258	AST PC Atomix Yellow II	16.800
6	P7208	AST PC Atomix Lemon MX	2.800
TOTAL			100%

PANTONE® 399 C

1	P7218	AST PC Atomix Opaque Mix Base	75.980
2	P7217	AST PC Atomix White	3.500
3	P7199	AST PC Atomix Black	0.080
4	P7200	AST PC Atomix Green	0.440
5	P8258	AST PC Atomix Yellow II	20.000
TOTAL			100%

PANTONE® 3935 C

1	P7218	AST PC Atomix Opaque Mix Base	86.350
2	P7217	AST PC Atomix White	8.000
3	P8410	AST PC Atomix Fluo Yellow DTA FF	4.300
4	P8258	AST PC Atomix Yellow II	0.150
5	P7208	AST PC Atomix Lemon MX	1.200
TOTAL			100%

PANTONE® 3945 C

1	P7218	AST PC Atomix Opaque Mix Base	78.980
2	P7217	AST PC Atomix White	3.000
3	P8410	AST PC Atomix Fluo Yellow DTA FF	14.900
4	P8258	AST PC Atomix Yellow II	0.320
5	P7208	AST PC Atomix Lemon MX	2.800
TOTAL			100%

PANTONE® 3955 C

1	P7218	AST PC Atomix Opaque Mix Base	76.720
2	P7217	AST PC Atomix White	3.200
3	P8410	AST PC Atomix Fluo Yellow DTA FF	12.220
4	P7200	AST PC Atomix Green	0.020
5	P8258	AST PC Atomix Yellow II	0.400
6	P7208	AST PC Atomix Lemon MX	7.440
TOTAL			100%

PANTONE® 3965 C

1	P7218	AST PC Atomix Opaque Mix Base	76.970
2	P7217	AST PC Atomix White	3.200
3	P8410	AST PC Atomix Fluo Yellow DTA FF	12.000
4	P7200	AST PC Atomix Green	0.030
5	P8258	AST PC Atomix Yellow II	0.600
6	P7208	AST PC Atomix Lemon MX	7.200
TOTAL			100%

PANTONE® 3975 C

1	P7218	AST PC Atomix Opaque Mix Base	70.000
2	P7217	AST PC Atomix White	4.000
3	P7199	AST PC Atomix Black	0.050
4	P7200	AST PC Atomix Green	0.320
5	P8258	AST PC Atomix Yellow II	13.630
6	P7208	AST PC Atomix Lemon MX	12.000
TOTAL			100%

PANTONE® 3985 C

1	P7218	AST PC Atomix Opaque Mix Base	70.000
2	P7217	AST PC Atomix White	4.000
3	P7199	AST PC Atomix Black	0.300
4	P7200	AST PC Atomix Green	0.320
5	P8258	AST PC Atomix Yellow II	17.380
6	P7208	AST PC Atomix Lemon MX	8.000
TOTAL			100%

PANTONE® 3995 C

1	P7218	AST PC Atomix Opaque Mix Base	75.700
2	P7217	AST PC Atomix White	4.000
3	P7199	AST PC Atomix Black	1.000
4	P7200	AST PC Atomix Green	0.300
5	P8258	AST PC Atomix Yellow II	19.000
TOTAL			100%

PANTONE® 400 C

1	P7218	AST PC Atomix Opaque Mix Base	79.300
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.360
4	P7211	AST PC Atomix Magenta MX	0.060
5	P8258	AST PC Atomix Yellow II	0.280
TOTAL			100%

PANTONE® 401 C

1	P7218	AST PC Atomix Opaque Mix Base	78.850
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.600
4	P7211	AST PC Atomix Magenta MX	0.130
5	P8258	AST PC Atomix Yellow II	0.420
TOTAL			100%

PANTONE® 402 C

1	P7218	AST PC Atomix Opaque Mix Base	78.250
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.810
4	P7211	AST PC Atomix Magenta MX	0.240
5	P8258	AST PC Atomix Yellow II	0.700
TOTAL			100%

PANTONE® 403 C

1	P7218	AST PC Atomix Opaque Mix Base	76.250
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	1.600
4	P7211	AST PC Atomix Magenta MX	0.450
5	P8258	AST PC Atomix Yellow II	1.700
TOTAL			100%

PANTONE® 404 C

1	P7218	AST PC Atomix Opaque Mix Base	72.360
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	3.040
4	P7211	AST PC Atomix Magenta MX	1.200
5	P8258	AST PC Atomix Yellow II	3.400
TOTAL			100%

PANTONE® 405 C

1	P7218	AST PC Atomix Opaque Mix Base	72.650
2	P7217	AST PC Atomix White	15.500
3	P7199	AST PC Atomix Black	4.500
4	P7211	AST PC Atomix Magenta MX	1.650
5	P8258	AST PC Atomix Yellow II	5.700
TOTAL			100%

PANTONE® Black C

1	P7218	AST PC Atomix Opaque Mix Base	86.600
2	P7199	AST PC Atomix Black	5.670
3	P7211	AST PC Atomix Magenta MX	2.880
4	P8258	AST PC Atomix Yellow II	4.850
TOTAL			100%

PANTONE® 406 C

1	P7218	AST PC Atomix Opaque Mix Base	79.300
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.330
4	P7211	AST PC Atomix Magenta MX	0.100
5	P8258	AST PC Atomix Yellow II	0.270
TOTAL			100%

PANTONE® 407 C

1	P7218	AST PC Atomix Opaque Mix Base	78.780
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.530
4	P7211	AST PC Atomix Magenta MX	0.240
5	P8258	AST PC Atomix Yellow II	0.450
TOTAL			100%

PANTONE® 408 C

1	P7218	AST PC Atomix Opaque Mix Base	77.620
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	1.020
4	P7211	AST PC Atomix Magenta MX	0.460
5	P8258	AST PC Atomix Yellow II	0.900
TOTAL			100%

PANTONE® 409 C

1	P7218	AST PC Atomix Opaque Mix Base	74.550
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	2.050
4	P7211	AST PC Atomix Magenta MX	1.300
5	P8258	AST PC Atomix Yellow II	2.100
TOTAL			100%

PANTONE® 410 C

1	P7218	AST PC Atomix Opaque Mix Base	71.150
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	3.400
4	P7207	AST PC Atomix Red MX	1.850
5	P8258	AST PC Atomix Yellow II	3.600
TOTAL			100%

PANTONE® 411 C

1	P7218	AST PC Atomix Opaque Mix Base	77.200
2	P7217	AST PC Atomix White	10.000
3	P7199	AST PC Atomix Black	4.000
4	P7211	AST PC Atomix Magenta MX	3.200
5	P8258	AST PC Atomix Yellow II	5.600
TOTAL			100%

PANTONE® 412 C

1	P7218	AST PC Atomix Opaque Mix Base	77.960
2	P7217	AST PC Atomix White	4.000
3	P7199	AST PC Atomix Black	6.600
4	P7211	AST PC Atomix Magenta MX	4.160
5	P8258	AST PC Atomix Yellow II	7.280
TOTAL			100%

PANTONE® 413 C

1	P7218	AST PC Atomix Opaque Mix Base	78.570
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.320
4	P7213	AST PC Atomix Blue RQ	0.760
5	P8258	AST PC Atomix Yellow II	0.350
TOTAL			100%

PANTONE® 414 C

1	P7218	AST PC Atomix Opaque Mix Base	77.990
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.650
4	P7213	AST PC Atomix Blue RQ	0.840
5	P8258	AST PC Atomix Yellow II	0.520
TOTAL			100%

PANTONE® 415 C

1	P7218	AST PC Atomix Opaque Mix Base	77.040
2	P7217	AST PC Atomix White	19.500
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	0.400
4	P7199	AST PC Atomix Black	1.150
5	P7213	AST PC Atomix Blue RQ	1.200
6	P8258	AST PC Atomix Yellow II	0.710
TOTAL			100%

PANTONE® 416 C

1	P7218	AST PC Atomix Opaque Mix Base	75.500
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	2.100
4	P7213	AST PC Atomix Blue RQ	1.000
5	P8258	AST PC Atomix Yellow II	1.400
TOTAL			100%

PANTONE® 417 C

1	P7218	AST PC Atomix Opaque Mix Base	73.030
2	P7217	AST PC Atomix White	18.000
3	P7199	AST PC Atomix Black	4.350
4	P7213	AST PC Atomix Blue RQ	1.350
5	P8258	AST PC Atomix Yellow II	3.270
TOTAL			100%

PANTONE® 418 C

1	P7218	AST PC Atomix Opaque Mix Base	75.270
2	P7217	AST PC Atomix White	12.000
3	P7199	AST PC Atomix Black	5.610
4	P7213	AST PC Atomix Blue RQ	1.840
5	P8258	AST PC Atomix Yellow II	5.280
TOTAL			100%

PANTONE® 419 C

1	P7218	AST PC Atomix Opaque Mix Base	71.500
2	P7217	AST PC Atomix White	2.500
3	P7199	AST PC Atomix Black	18.000
4	P7200	AST PC Atomix Green	2.000
5	P8258	AST PC Atomix Yellow II	6.000
TOTAL			100%

PANTONE® 420 C

1	P7218	AST PC Atomix Opaque Mix Base	79.610
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.170
4	P7213	AST PC Atomix Blue RQ	0.170
5	P8258	AST PC Atomix Yellow II	0.050
TOTAL			100%

PANTONE® 421 C

1	P7218	AST PC Atomix Opaque Mix Base	78.870
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.490
4	P7213	AST PC Atomix Blue RQ	0.490
5	P8258	AST PC Atomix Yellow II	0.150
TOTAL			100%

PANTONE® 422 C

1	P7218	AST PC Atomix Opaque Mix Base	78.240
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.800
4	P7213	AST PC Atomix Blue RQ	0.800
5	P8258	AST PC Atomix Yellow II	0.160
TOTAL			100%

PANTONE® 423 C

1	P7218	AST PC Atomix Opaque Mix Base	76.800
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	1.500
4	P7213	AST PC Atomix Blue RQ	1.450
5	P8258	AST PC Atomix Yellow II	0.250
TOTAL			100%

PANTONE® 424 C

1	P7218	AST PC Atomix Opaque Mix Base	73.100
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	3.400
4	P7213	AST PC Atomix Blue RQ	3.050
5	P8258	AST PC Atomix Yellow II	0.450
TOTAL			100%

PANTONE® 425 C

1	P7218	AST PC Atomix Opaque Mix Base	72.400
2	P7217	AST PC Atomix White	17.700
3	P7199	AST PC Atomix Black	5.700
4	P7213	AST PC Atomix Blue RQ	3.600
5	P8258	AST PC Atomix Yellow II	0.600
TOTAL			100%

PANTONE® 426 C

1	P7218	AST PC Atomix Opaque Mix Base	75.600
2	P7217	AST PC Atomix White	2.000
3	P7199	AST PC Atomix Black	16.700
4	P7213	AST PC Atomix Blue RQ	5.700
TOTAL			100%

PANTONE® 427 C

1	P7218	AST PC Atomix Opaque Mix Base	81.290
2	P7217	AST PC Atomix White	18.000
3	P8410	AST PC Atomix Fluo Yellow DTA FF	0.060
4	P7199	AST PC Atomix Black	0.100
5	P7213	AST PC Atomix Blue RQ	0.550
TOTAL			100%

PANTONE® 428 C

1	P7218	AST PC Atomix Opaque Mix Base	82.260
2	P7217	AST PC Atomix White	17.000
3	P8410	AST PC Atomix Fluo Yellow DTA FF	0.020
4	P7199	AST PC Atomix Black	0.120
5	P7213	AST PC Atomix Blue RQ	0.600
TOTAL			100%

PANTONE® 429 C

1	P7218	AST PC Atomix Opaque Mix Base	88.800
2	P7217	AST PC Atomix White	9.400
3	P8410	AST PC Atomix Fluo Yellow DTA FF	0.250
4	P7199	AST PC Atomix Black	0.350
5	P7213	AST PC Atomix Blue RQ	1.200
TOTAL			100%

PANTONE® 430 C

1	P7218	AST PC Atomix Opaque Mix Base	78.690
2	P7217	AST PC Atomix White	14.500
3	P8410	AST PC Atomix Fluo Yellow DTA FF	0.510
4	P7199	AST PC Atomix Black	1.300
5	P7213	AST PC Atomix Blue RQ	5.000
TOTAL			100%

PANTONE® 431 C

1	P7218	AST PC Atomix Opaque Mix Base	84.600
2	P7217	AST PC Atomix White	8.400
3	P7199	AST PC Atomix Black	1.600
4	P7204	AST PC Atomix Blue B	0.200
5	P7213	AST PC Atomix Blue RQ	5.200
TOTAL			100%

PANTONE® 432 C

1	P7218	AST PC Atomix Opaque Mix Base	93.200
2	P7217	AST PC Atomix White	3.000
3	P7199	AST PC Atomix Black	2.600
4	P7203	AST PC Atomix Blue 1500	1.200
TOTAL			100%

PANTONE® 433 C

1	P7218	AST PC Atomix Opaque Mix Base	74.900
2	P7217	AST PC Atomix White	1.800
3	P7199	AST PC Atomix Black	16.700
4	P7203	AST PC Atomix Blue 1500	4.600
5	P7200	AST PC Atomix Green	2.000
TOTAL			100%

PANTONE® 434 C

1	P7218	AST PC Atomix Opaque Mix Base	79.080
2	P7217	AST PC Atomix White	20.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	0.720
4	P7199	AST PC Atomix Black	0.160
5	P8258	AST PC Atomix Yellow II	0.040
TOTAL			100%

PANTONE® 435 C

1	P7218	AST PC Atomix Opaque Mix Base	79.490
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.270
4	P7207	AST PC Atomix Red MX	0.170
5	P8258	AST PC Atomix Yellow II	0.070
TOTAL			100%

PANTONE® 436 C

1	P7218	AST PC Atomix Opaque Mix Base	79.100
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.460
4	P7207	AST PC Atomix Red MX	0.340
5	P8258	AST PC Atomix Yellow II	0.100
TOTAL			100%

PANTONE® 437 C

1	P7218	AST PC Atomix Opaque Mix Base	81.450
2	P7217	AST PC Atomix White	14.000
3	P7199	AST PC Atomix Black	1.800
4	P7207	AST PC Atomix Red MX	1.980
5	P8258	AST PC Atomix Yellow II	0.770
TOTAL			100%

PANTONE® 438 C

1	P7218	AST PC Atomix Opaque Mix Base	85.150
2	P7217	AST PC Atomix White	5.800
3	P7199	AST PC Atomix Black	1.550
4	P7200	AST PC Atomix Green	1.200
5	P7207	AST PC Atomix Red MX	4.400
6	P8258	AST PC Atomix Yellow II	1.900
TOTAL			100%

PANTONE® 439 C

1	P7218	AST PC Atomix Opaque Mix Base	70.560
2	P7217	AST PC Atomix White	8.000
3	P7199	AST PC Atomix Black	6.600
4	P7207	AST PC Atomix Red MX	9.520
5	P8258	AST PC Atomix Yellow II	5.320
TOTAL			100%

PANTONE® 440 C

1	P7218	AST PC Atomix Opaque Mix Base	72.000
2	P7217	AST PC Atomix White	4.000
3	P7199	AST PC Atomix Black	10.800
4	P7207	AST PC Atomix Red MX	8.500
5	P8258	AST PC Atomix Yellow II	4.700
TOTAL			100%

PANTONE® 441 C

1	P7218	AST PC Atomix Opaque Mix Base	79.730
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.120
4	P7200	AST PC Atomix Green	0.120
5	P8258	AST PC Atomix Yellow II	0.030
TOTAL			100%

PANTONE® 442 C

1	P7218	AST PC Atomix Opaque Mix Base	81.660
2	P7217	AST PC Atomix White	17.700
3	P7199	AST PC Atomix Black	0.420
4	P7204	AST PC Atomix Blue B	0.140
5	P7208	AST PC Atomix Lemon MX	0.080
TOTAL			100%

PANTONE® 443 C

1	P7218	AST PC Atomix Opaque Mix Base	78.750
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.800
4	P7203	AST PC Atomix Blue 1500	0.190
5	P8258	AST PC Atomix Yellow II	0.260
TOTAL			100%

PANTONE® 444 C

1	P7218	AST PC Atomix Opaque Mix Base	77.350
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	1.750
4	P7203	AST PC Atomix Blue 1500	0.380
5	P8258	AST PC Atomix Yellow II	0.520
TOTAL			100%

PANTONE® 445 C

1	P7218	AST PC Atomix Opaque Mix Base	72.500
2	P7217	AST PC Atomix White	17.000
3	P7199	AST PC Atomix Black	6.700
4	P7203	AST PC Atomix Blue 1500	1.150
5	P8258	AST PC Atomix Yellow II	2.650
TOTAL			100%

PANTONE® 446 C

1	P7218	AST PC Atomix Opaque Mix Base	72.600
2	P7217	AST PC Atomix White	12.000
3	P7199	AST PC Atomix Black	8.500
4	P7203	AST PC Atomix Blue 1500	1.500
5	P8258	AST PC Atomix Yellow II	5.400
TOTAL			100%

PANTONE® 447 C

1	P7218	AST PC Atomix Opaque Mix Base	75.200
2	P7217	AST PC Atomix White	7.000
3	P7199	AST PC Atomix Black	9.360
4	P7203	AST PC Atomix Blue 1500	1.620
5	P8258	AST PC Atomix Yellow II	6.820
TOTAL			100%

PANTONE® Warm Gray 7 C

1	P7218	AST PC Atomix Opaque Mix Base	76.960
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	1.300
4	P7207	AST PC Atomix Red MX	0.540
5	P8258	AST PC Atomix Yellow II	1.200
TOTAL			100%

PANTONE® Warm Gray 1 C

1	P7218	AST PC Atomix Opaque Mix Base	85.980
2	P7217	AST PC Atomix White	13.700
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	0.150
4	P7199	AST PC Atomix Black	0.110
5	P8258	AST PC Atomix Yellow II	0.060
TOTAL			100%

PANTONE® Warm Gray 8 C

1	P7218	AST PC Atomix Opaque Mix Base	75.960
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	1.690
4	P7207	AST PC Atomix Red MX	0.730
5	P8258	AST PC Atomix Yellow II	1.620
TOTAL			100%

PANTONE® Warm Gray 2 C

1	P7218	AST PC Atomix Opaque Mix Base	79.380
2	P7217	AST PC Atomix White	20.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	0.300
4	P7199	AST PC Atomix Black	0.170
5	P8258	AST PC Atomix Yellow II	0.150
TOTAL			100%

PANTONE® Warm Gray 9 C

1	P7218	AST PC Atomix Opaque Mix Base	74.600
2	P7217	AST PC Atomix White	19.000
3	P7199	AST PC Atomix Black	2.600
4	P7207	AST PC Atomix Red MX	1.100
5	P8258	AST PC Atomix Yellow II	2.700
TOTAL			100%

PANTONE® Warm Gray 3 C

1	P7218	AST PC Atomix Opaque Mix Base	79.470
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.290
4	P7207	AST PC Atomix Red MX	0.040
5	P8258	AST PC Atomix Yellow II	0.200
TOTAL			100%

PANTONE® Warm Gray 10 C

1	P7218	AST PC Atomix Opaque Mix Base	79.350
2	P7217	AST PC Atomix White	14.000
3	P7199	AST PC Atomix Black	2.500
4	P7207	AST PC Atomix Red MX	1.150
5	P8258	AST PC Atomix Yellow II	3.000
TOTAL			100%

PANTONE® Warm Gray 4 C

1	P7218	AST PC Atomix Opaque Mix Base	79.240
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.400
4	P7207	AST PC Atomix Red MX	0.080
5	P8258	AST PC Atomix Yellow II	0.280
TOTAL			100%

PANTONE® Warm Gray 11 C

1	P7218	AST PC Atomix Opaque Mix Base	71.200
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	2.900
4	P7207	AST PC Atomix Red MX	2.100
5	P8258	AST PC Atomix Yellow II	3.800
TOTAL			100%

PANTONE® Warm Gray 5 C

1	P7218	AST PC Atomix Opaque Mix Base	79.790
2	P7217	AST PC Atomix White	19.000
3	P7199	AST PC Atomix Black	0.600
4	P7207	AST PC Atomix Red MX	0.160
5	P8258	AST PC Atomix Yellow II	0.450
TOTAL			100%

PANTONE® Cool Gray 1 C

1	P7218	AST PC Atomix Opaque Mix Base	81.800
2	P7217	AST PC Atomix White	18.000
3	P8410	AST PC Atomix Fluo Yellow DTA FF	0.040
4	P7199	AST PC Atomix Black	0.060
5	P7213	AST PC Atomix Blue RQ	0.100
TOTAL			100%

PANTONE® Warm Gray 6 C

1	P7218	AST PC Atomix Opaque Mix Base	77.750
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.990
4	P7207	AST PC Atomix Red MX	0.360
5	P8258	AST PC Atomix Yellow II	0.900
TOTAL			100%

PANTONE® Cool Gray 2 C

1	P7218	AST PC Atomix Opaque Mix Base	79.770
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.120
4	P7213	AST PC Atomix Blue RQ	0.070
5	P8258	AST PC Atomix Yellow II	0.040
TOTAL			100%

PANTONE® Cool Gray 3 C

1	P7218	AST PC Atomix Opaque Mix Base	79.540
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.230
4	P7213	AST PC Atomix Blue RQ	0.180
5	P8258	AST PC Atomix Yellow II	0.050
TOTAL			100%

PANTONE® Cool Gray 4 C

1	P7218	AST PC Atomix Opaque Mix Base	79.280
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.300
4	P7213	AST PC Atomix Blue RQ	0.350
5	P8258	AST PC Atomix Yellow II	0.070
TOTAL			100%

PANTONE® Cool Gray 5 C

1	P7218	AST PC Atomix Opaque Mix Base	78.820
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.540
4	P7213	AST PC Atomix Blue RQ	0.530
5	P8258	AST PC Atomix Yellow II	0.110
TOTAL			100%

PANTONE® Cool Gray 6 C

1	P7218	AST PC Atomix Opaque Mix Base	78.300
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.760
4	P7213	AST PC Atomix Blue RQ	0.820
5	P8258	AST PC Atomix Yellow II	0.120
TOTAL			100%

PANTONE® Cool Gray 7 C

1	P7218	AST PC Atomix Opaque Mix Base	77.430
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	1.240
4	P7213	AST PC Atomix Blue RQ	1.180
5	P8258	AST PC Atomix Yellow II	0.150
TOTAL			100%

PANTONE® Cool Gray 8 C

1	P7218	AST PC Atomix Opaque Mix Base	76.560
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	1.900
4	P7213	AST PC Atomix Blue RQ	1.400
5	P8258	AST PC Atomix Yellow II	0.140
TOTAL			100%

PANTONE® Cool Gray 9 C

1	P7218	AST PC Atomix Opaque Mix Base	75.150
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	3.400
4	P7213	AST PC Atomix Blue RQ	1.300
5	P8258	AST PC Atomix Yellow II	0.150
TOTAL			100%

PANTONE® Cool Gray 10 C

1	P7218	AST PC Atomix Opaque Mix Base	72.070
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	5.720
4	P7213	AST PC Atomix Blue RQ	1.560
5	P8258	AST PC Atomix Yellow II	0.650
TOTAL			100%

PANTONE® Cool Gray 11 C

1	P7218	AST PC Atomix Opaque Mix Base	76.300
2	P7217	AST PC Atomix White	16.000
3	P7199	AST PC Atomix Black	5.200
4	P7213	AST PC Atomix Blue RQ	1.900
5	P8258	AST PC Atomix Yellow II	0.600
TOTAL			100%

PANTONE® Black 2 C

1	P7218	AST PC Atomix Opaque Mix Base	82.200
2	P7199	AST PC Atomix Black	8.400
3	P7207	AST PC Atomix Red MX	1.000
4	P8258	AST PC Atomix Yellow II	8.400
TOTAL			100%

PANTONE® Black 3 C

1	P7218	AST PC Atomix Opaque Mix Base	81.600
2	P7199	AST PC Atomix Black	7.600
3	P7200	AST PC Atomix Green	7.200
4	P8258	AST PC Atomix Yellow II	3.600
TOTAL			100%

PANTONE® Black 4 C

1	P7218	AST PC Atomix Opaque Mix Base	82.300
2	P7199	AST PC Atomix Black	5.400
3	P7207	AST PC Atomix Red MX	2.700
4	P8258	AST PC Atomix Yellow II	9.600
TOTAL			100%

PANTONE® Black 5 C

1	P7218	AST PC Atomix Opaque Mix Base	82.000
2	P7199	AST PC Atomix Black	4.500
3	P7211	AST PC Atomix Magenta MX	11.000
4	P8258	AST PC Atomix Yellow II	2.500
TOTAL			100%

PANTONE® Black 6 C

1	P7218	AST PC Atomix Opaque Mix Base	70.000
2	P7199	AST PC Atomix Black	14.000
3	P7203	AST PC Atomix Blue 1500	16.000
TOTAL			100%

PANTONE® Black 7 C

1	P7218	AST PC Atomix Opaque Mix Base	83.000
2	P7217	AST PC Atomix White	3.000
3	P7199	AST PC Atomix Black	7.900
4	P7207	AST PC Atomix Red MX	1.450
5	P8258	AST PC Atomix Yellow II	4.650
TOTAL			100%

PANTONE® 448 C

1	P7218	AST PC Atomix Opaque Mix Base	72.480
2	P7217	AST PC Atomix White	1.000
3	P7199	AST PC Atomix Black	2.640
4	P7211	AST PC Atomix Magenta MX	3.180
5	P7208	AST PC Atomix Lemon MX	20.700
TOTAL			100%

PANTONE® 4485 C

1	P7218	AST PC Atomix Opaque Mix Base	71.160
2	P7217	AST PC Atomix White	2.600
3	P7199	AST PC Atomix Black	1.140
4	P7211	AST PC Atomix Magenta MX	2.100
5	P7208	AST PC Atomix Lemon MX	23.000
TOTAL			100%

PANTONE® 449 C

1	P7218	AST PC Atomix Opaque Mix Base	72.700
2	P7217	AST PC Atomix White	2.500
3	P7199	AST PC Atomix Black	2.200
4	P7211	AST PC Atomix Magenta MX	1.900
5	P7208	AST PC Atomix Lemon MX	20.700
TOTAL			100%

PANTONE® 4495 C

1	P7218	AST PC Atomix Opaque Mix Base	77.340
2	P7217	AST PC Atomix White	6.000
3	P7199	AST PC Atomix Black	0.850
4	P7211	AST PC Atomix Magenta MX	0.810
5	P7208	AST PC Atomix Lemon MX	15.000
TOTAL			100%

PANTONE® 450 C

1	P7218	AST PC Atomix Opaque Mix Base	75.700
2	P7217	AST PC Atomix White	3.000
3	P7199	AST PC Atomix Black	1.900
4	P7211	AST PC Atomix Magenta MX	1.400
5	P7208	AST PC Atomix Lemon MX	18.000
TOTAL			100%

PANTONE® 4505 C

1	P7218	AST PC Atomix Opaque Mix Base	77.010
2	P7217	AST PC Atomix White	12.200
3	P7199	AST PC Atomix Black	0.740
4	P7211	AST PC Atomix Magenta MX	0.650
5	P7208	AST PC Atomix Lemon MX	9.400
TOTAL			100%

PANTONE® 451 C

1	P7218	AST PC Atomix Opaque Mix Base	72.870
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	1.400
4	P8258	AST PC Atomix Yellow II	2.280
5	P7208	AST PC Atomix Lemon MX	3.450
TOTAL			100%

PANTONE® 4515 C

1	P7218	AST PC Atomix Opaque Mix Base	73.490
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.550
4	P7211	AST PC Atomix Magenta MX	0.360
5	P7208	AST PC Atomix Lemon MX	5.600
TOTAL			100%

PANTONE® 452 C

1	P7218	AST PC Atomix Opaque Mix Base	77.300
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.650
4	P8258	AST PC Atomix Yellow II	1.000
5	P7208	AST PC Atomix Lemon MX	1.050
TOTAL			100%

PANTONE® 4525 C

1	P7218	AST PC Atomix Opaque Mix Base	77.750
2	P7217	AST PC Atomix White	19.700
3	P7199	AST PC Atomix Black	0.250
4	P7211	AST PC Atomix Magenta MX	0.150
5	P7208	AST PC Atomix Lemon MX	2.150
TOTAL			100%

PANTONE® 453 C

1	P7218	AST PC Atomix Opaque Mix Base	78.740
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.400
4	P8258	AST PC Atomix Yellow II	0.560
5	P7208	AST PC Atomix Lemon MX	0.300
TOTAL			100%

PANTONE® 4535 C

1	P7218	AST PC Atomix Opaque Mix Base	78.770
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.150
4	P7211	AST PC Atomix Magenta MX	0.080
5	P7208	AST PC Atomix Lemon MX	1.000
TOTAL			100%

PANTONE® 454 C

1	P7218	AST PC Atomix Opaque Mix Base	79.420
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.200
4	P8258	AST PC Atomix Yellow II	0.260
5	P7208	AST PC Atomix Lemon MX	0.120
TOTAL			100%

PANTONE® 4545 C

1	P7218	AST PC Atomix Opaque Mix Base	79.100
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.140
4	P7211	AST PC Atomix Magenta MX	0.060
5	P7208	AST PC Atomix Lemon MX	0.700
TOTAL			100%

PANTONE® 455 C

1	P7218	AST PC Atomix Opaque Mix Base	84.500
2	P7217	AST PC Atomix White	2.000
3	P7199	AST PC Atomix Black	1.000
4	P8258	AST PC Atomix Yellow II	11.000
5	P7208	AST PC Atomix Lemon MX	1.500
TOTAL			100%

PANTONE® 462 C

1	P7218	AST PC Atomix Opaque Mix Base	70.000
2	P7217	AST PC Atomix White	2.000
3	P7199	AST PC Atomix Black	1.600
4	P7211	AST PC Atomix Magenta MX	3.800
5	P7208	AST PC Atomix Lemon MX	22.600
TOTAL			100%

PANTONE® 456 C

1	P7218	AST PC Atomix Opaque Mix Base	74.700
2	P7217	AST PC Atomix White	5.000
3	P7199	AST PC Atomix Black	0.550
4	P8258	AST PC Atomix Yellow II	10.500
5	P7208	AST PC Atomix Lemon MX	9.250
TOTAL			100%

PANTONE® 463 C

1	P7218	AST PC Atomix Opaque Mix Base	74.250
2	P7217	AST PC Atomix White	0.800
3	P7199	AST PC Atomix Black	0.890
4	P7207	AST PC Atomix Red MX	2.500
5	P7208	AST PC Atomix Lemon MX	21.560
TOTAL			100%

PANTONE® 457 C

1	P7218	AST PC Atomix Opaque Mix Base	74.220
2	P7217	AST PC Atomix White	7.450
3	P7199	AST PC Atomix Black	0.370
4	P8258	AST PC Atomix Yellow II	8.760
5	P7208	AST PC Atomix Lemon MX	9.200
TOTAL			100%

PANTONE® 464 C

1	P7218	AST PC Atomix Opaque Mix Base	75.610
2	P7217	AST PC Atomix White	2.000
3	P7199	AST PC Atomix Black	0.600
4	P7207	AST PC Atomix Red MX	1.890
5	P7208	AST PC Atomix Lemon MX	19.900
TOTAL			100%

PANTONE® 458 C

1	P7218	AST PC Atomix Opaque Mix Base	73.390
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.190
4	P8258	AST PC Atomix Yellow II	1.740
5	P7208	AST PC Atomix Lemon MX	4.680
TOTAL			100%

PANTONE® 465 C

1	P7218	AST PC Atomix Opaque Mix Base	78.860
2	P7217	AST PC Atomix White	13.600
3	P7199	AST PC Atomix Black	0.500
4	P7211	AST PC Atomix Magenta MX	0.760
5	P7208	AST PC Atomix Lemon MX	6.280
TOTAL			100%

PANTONE® 459 C

1	P7218	AST PC Atomix Opaque Mix Base	75.250
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.150
4	P8258	AST PC Atomix Yellow II	0.900
5	P7208	AST PC Atomix Lemon MX	3.700
TOTAL			100%

PANTONE® 466 C

1	P7218	AST PC Atomix Opaque Mix Base	75.540
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.310
4	P7211	AST PC Atomix Magenta MX	0.450
5	P7208	AST PC Atomix Lemon MX	3.700
TOTAL			100%

PANTONE® 460 C

1	P7218	AST PC Atomix Opaque Mix Base	77.700
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.100
4	P8258	AST PC Atomix Yellow II	0.600
5	P7208	AST PC Atomix Lemon MX	1.600
TOTAL			100%

PANTONE® 467 C

1	P7218	AST PC Atomix Opaque Mix Base	77.660
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.220
4	P7211	AST PC Atomix Magenta MX	0.220
5	P7208	AST PC Atomix Lemon MX	1.900
TOTAL			100%

PANTONE® 461 C

1	P7218	AST PC Atomix Opaque Mix Base	78.760
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.030
4	P7213	AST PC Atomix Blue RQ	0.200
5	P8258	AST PC Atomix Yellow II	0.560
6	P7208	AST PC Atomix Lemon MX	0.450
TOTAL			100%

PANTONE® 468 C

1	P7218	AST PC Atomix Opaque Mix Base	78.740
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.140
4	P7211	AST PC Atomix Magenta MX	0.120
5	P7208	AST PC Atomix Lemon MX	1.000
TOTAL			100%

PANTONE® 4625 C

1	P7218	AST PC Atomix Opaque Mix Base	70.400
2	P7217	AST PC Atomix White	1.200
3	P7199	AST PC Atomix Black	2.600
4	P7207	AST PC Atomix Red MX	8.900
5	P7208	AST PC Atomix Lemon MX	16.900
TOTAL			100%

PANTONE® 469 C

1	P7218	AST PC Atomix Opaque Mix Base	81.900
2	P7217	AST PC Atomix White	1.000
3	P7199	AST PC Atomix Black	0.700
4	P7207	AST PC Atomix Red MX	1.400
5	P8258	AST PC Atomix Yellow II	15.000
TOTAL			100%

PANTONE® 4635 C

1	P7218	AST PC Atomix Opaque Mix Base	76.900
2	P7217	AST PC Atomix White	9.000
3	P7199	AST PC Atomix Black	0.600
4	P7207	AST PC Atomix Red MX	2.800
5	P7208	AST PC Atomix Lemon MX	10.700
TOTAL			100%

PANTONE® 470 C

1	P7218	AST PC Atomix Opaque Mix Base	83.240
2	P7217	AST PC Atomix White	3.000
3	P7199	AST PC Atomix Black	0.260
4	P7207	AST PC Atomix Red MX	1.200
5	P8258	AST PC Atomix Yellow II	12.300
TOTAL			100%

PANTONE® 4645 C

1	P7218	AST PC Atomix Opaque Mix Base	73.000
2	P7217	AST PC Atomix White	18.000
3	P7199	AST PC Atomix Black	0.500
4	P7207	AST PC Atomix Red MX	2.000
5	P7208	AST PC Atomix Lemon MX	6.500
TOTAL			100%

PANTONE® 471 C

1	P7218	AST PC Atomix Opaque Mix Base	79.900
2	P7217	AST PC Atomix White	6.000
3	P7199	AST PC Atomix Black	0.150
4	P7207	AST PC Atomix Red MX	1.250
5	P8258	AST PC Atomix Yellow II	12.700
TOTAL			100%

PANTONE® 4655 C

1	P7218	AST PC Atomix Opaque Mix Base	74.440
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.400
4	P7207	AST PC Atomix Red MX	1.160
5	P8258	AST PC Atomix Yellow II	4.000
TOTAL			100%

PANTONE® 472 C

1	P7218	AST PC Atomix Opaque Mix Base	75.090
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.060
4	P7211	AST PC Atomix Magenta MX	0.750
5	P8258	AST PC Atomix Yellow II	4.100
TOTAL			100%

PANTONE® 4665 C

1	P7218	AST PC Atomix Opaque Mix Base	77.400
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.200
4	P7207	AST PC Atomix Red MX	0.700
5	P7208	AST PC Atomix Lemon MX	1.700
TOTAL			100%

PANTONE® 473 C

1	P7218	AST PC Atomix Opaque Mix Base	78.580
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.040
4	P7211	AST PC Atomix Magenta MX	0.280
5	P8258	AST PC Atomix Yellow II	1.100
TOTAL			100%

PANTONE® 4675 C

1	P7218	AST PC Atomix Opaque Mix Base	78.580
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.150
4	P7207	AST PC Atomix Red MX	0.370
5	P7208	AST PC Atomix Lemon MX	0.900
TOTAL			100%

PANTONE® 474 C

1	P7218	AST PC Atomix Opaque Mix Base	78.770
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.040
4	P7211	AST PC Atomix Magenta MX	0.250
5	P8258	AST PC Atomix Yellow II	0.940
TOTAL			100%

PANTONE® 4685 C

1	P7218	AST PC Atomix Opaque Mix Base	79.170
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.090
4	P7207	AST PC Atomix Red MX	0.200
5	P7208	AST PC Atomix Lemon MX	0.540
TOTAL			100%

PANTONE® 475 C

1	P7218	AST PC Atomix Opaque Mix Base	79.150
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.040
4	P7211	AST PC Atomix Magenta MX	0.160
5	P8258	AST PC Atomix Yellow II	0.650
TOTAL			100%

PANTONE® 4695 C

1	P7218	AST PC Atomix Opaque Mix Base	72.550
2	P7217	AST PC Atomix White	1.000
3	P7199	AST PC Atomix Black	1.650
4	P7207	AST PC Atomix Red MX	8.800
5	P7208	AST PC Atomix Lemon MX	16.000
TOTAL			100%

PANTONE® 4705 C

1	P7218	AST PC Atomix Opaque Mix Base	76.900
2	P7217	AST PC Atomix White	5.000
3	P7199	AST PC Atomix Black	1.100
4	P7207	AST PC Atomix Red MX	4.500
5	P7208	AST PC Atomix Lemon MX	12.500
TOTAL			100%

PANTONE® 4715 C

1	P7218	AST PC Atomix Opaque Mix Base	81.450
2	P7217	AST PC Atomix White	12.500
3	P7199	AST PC Atomix Black	0.700
4	P7207	AST PC Atomix Red MX	1.850
5	P7208	AST PC Atomix Lemon MX	3.500
TOTAL			100%

PANTONE® 4725 C

1	P7218	AST PC Atomix Opaque Mix Base	83.030
2	P7217	AST PC Atomix White	14.000
3	P7199	AST PC Atomix Black	0.420
4	P7207	AST PC Atomix Red MX	0.950
5	P7208	AST PC Atomix Lemon MX	1.600
TOTAL			100%

PANTONE® 4735 C

1	P7218	AST PC Atomix Opaque Mix Base	78.390
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.240
4	P7207	AST PC Atomix Red MX	0.520
5	P7208	AST PC Atomix Lemon MX	0.850
TOTAL			100%

PANTONE® 4745 C

1	P7218	AST PC Atomix Opaque Mix Base	78.620
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.230
4	P7207	AST PC Atomix Red MX	0.400
5	P7208	AST PC Atomix Lemon MX	0.750
TOTAL			100%

PANTONE® 4755 C

1	P7218	AST PC Atomix Opaque Mix Base	79.220
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.140
4	P7207	AST PC Atomix Red MX	0.240
5	P7208	AST PC Atomix Lemon MX	0.400
TOTAL			100%

PANTONE® 476 C

1	P7218	AST PC Atomix Opaque Mix Base	76.350
2	P7199	AST PC Atomix Black	2.150
3	P7207	AST PC Atomix Red MX	7.000
4	P7208	AST PC Atomix Lemon MX	14.500
TOTAL			100%

PANTONE® 477 C

1	P7218	AST PC Atomix Opaque Mix Base	76.350
2	P7217	AST PC Atomix White	1.000
3	P7199	AST PC Atomix Black	1.100
4	P7207	AST PC Atomix Red MX	5.850
5	P7208	AST PC Atomix Lemon MX	15.700
TOTAL			100%

PANTONE® 478 C

1	P7218	AST PC Atomix Opaque Mix Base	83.550
2	P7217	AST PC Atomix White	1.000
3	P7199	AST PC Atomix Black	0.650
4	P7207	AST PC Atomix Red MX	3.800
5	P7208	AST PC Atomix Lemon MX	11.000
TOTAL			100%

PANTONE® 479 C

1	P7218	AST PC Atomix Opaque Mix Base	73.930
2	P7217	AST PC Atomix White	18.000
3	P7199	AST PC Atomix Black	0.650
4	P7207	AST PC Atomix Red MX	2.020
5	P7208	AST PC Atomix Lemon MX	5.400
TOTAL			100%

PANTONE® 480 C

1	P7218	AST PC Atomix Opaque Mix Base	78.380
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.240
4	P7207	AST PC Atomix Red MX	0.420
5	P7208	AST PC Atomix Lemon MX	0.960
TOTAL			100%

PANTONE® 481 C

1	P7218	AST PC Atomix Opaque Mix Base	79.120
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.150
4	P7207	AST PC Atomix Red MX	0.230
5	P7208	AST PC Atomix Lemon MX	0.500
TOTAL			100%

PANTONE® 482 C

1	P7218	AST PC Atomix Opaque Mix Base	79.250
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.120
4	P7207	AST PC Atomix Red MX	0.180
5	P7208	AST PC Atomix Lemon MX	0.450
TOTAL			100%

PANTONE® 483 C

1	P7218	AST PC Atomix Opaque Mix Base	75.400
2	P7217	AST PC Atomix White	2.000
3	P7199	AST PC Atomix Black	1.200
4	P7207	AST PC Atomix Red MX	5.400
5	P8258	AST PC Atomix Yellow II	16.000
TOTAL			100%

PANTONE® 484 C

1	P7218	AST PC Atomix Opaque Mix Base	74.140
2	P7217	AST PC Atomix White	1.800
3	P8412	AST PC Atomix Fluo Orange DTA FF	7.720
4	P7199	AST PC Atomix Black	0.260
5	P7207	AST PC Atomix Red MX	4.200
6	P8258	AST PC Atomix Yellow II	11.880
TOTAL			100%

PANTONE® 485 C

1	P7218	AST PC Atomix Opaque Mix Base	76.800
2	P7217	AST PC Atomix White	1.100
3	P8412	AST PC Atomix Fluo Orange DTA FF	6.700
4	P7207	AST PC Atomix Red MX	2.800
5	P8258	AST PC Atomix Yellow II	12.600
TOTAL			100%

PANTONE® 486 C

1	P7218	AST PC Atomix Opaque Mix Base	78.420
2	P7217	AST PC Atomix White	16.860
3	P7213	AST PC Atomix Blue RQ	0.250
4	P7207	AST PC Atomix Red MX	1.430
5	P8258	AST PC Atomix Yellow II	3.040
TOTAL			100%

PANTONE® 487 C

1	P7218	AST PC Atomix Opaque Mix Base	76.750
2	P7217	AST PC Atomix White	20.000
3	P7213	AST PC Atomix Blue RQ	0.550
4	P7207	AST PC Atomix Red MX	0.900
5	P8258	AST PC Atomix Yellow II	1.800
TOTAL			100%

PANTONE® 488 C

1	P7218	AST PC Atomix Opaque Mix Base	77.950
2	P7217	AST PC Atomix White	20.000
3	P7213	AST PC Atomix Blue RQ	0.600
4	P7207	AST PC Atomix Red MX	0.500
5	P8258	AST PC Atomix Yellow II	0.950
TOTAL			100%

PANTONE® 489 C

1	P7218	AST PC Atomix Opaque Mix Base	78.630
2	P7217	AST PC Atomix White	20.000
3	P7213	AST PC Atomix Blue RQ	0.550
4	P7207	AST PC Atomix Red MX	0.250
5	P8258	AST PC Atomix Yellow II	0.570
TOTAL			100%

PANTONE® 490 C

1	P7218	AST PC Atomix Opaque Mix Base	82.400
2	P7217	AST PC Atomix White	1.910
3	P7199	AST PC Atomix Black	1.750
4	P7207	AST PC Atomix Red MX	10.760
5	P8258	AST PC Atomix Yellow II	3.180
TOTAL			100%

PANTONE® 491 C

1	P7218	AST PC Atomix Opaque Mix Base	86.840
2	P7217	AST PC Atomix White	2.400
3	P7199	AST PC Atomix Black	0.660
4	P7207	AST PC Atomix Red MX	8.300
5	P8258	AST PC Atomix Yellow II	1.800
TOTAL			100%

PANTONE® 492 C

1	P7218	AST PC Atomix Opaque Mix Base	87.430
2	P7217	AST PC Atomix White	3.610
3	P7199	AST PC Atomix Black	0.380
4	P7207	AST PC Atomix Red MX	7.210
5	P8258	AST PC Atomix Yellow II	1.370
TOTAL			100%

PANTONE® 493 C

1	P7218	AST PC Atomix Opaque Mix Base	80.390
2	P7217	AST PC Atomix White	16.700
3	P7213	AST PC Atomix Blue RQ	0.820
4	P7207	AST PC Atomix Red MX	1.900
5	P8258	AST PC Atomix Yellow II	0.190
TOTAL			100%

PANTONE® 494 C

1	P7218	AST PC Atomix Opaque Mix Base	80.100
2	P7217	AST PC Atomix White	18.000
3	P7213	AST PC Atomix Blue RQ	0.630
4	P7207	AST PC Atomix Red MX	1.100
5	P8258	AST PC Atomix Yellow II	0.170
TOTAL			100%

PANTONE® 495 C

1	P7218	AST PC Atomix Opaque Mix Base	78.750
2	P7217	AST PC Atomix White	20.000
3	P7213	AST PC Atomix Blue RQ	0.500
4	P7207	AST PC Atomix Red MX	0.600
5	P8258	AST PC Atomix Yellow II	0.150
TOTAL			100%

PANTONE® 496 C

1	P7218	AST PC Atomix Opaque Mix Base	79.120
2	P7217	AST PC Atomix White	20.000
3	P7213	AST PC Atomix Blue RQ	0.400
4	P7207	AST PC Atomix Red MX	0.350
5	P8258	AST PC Atomix Yellow II	0.130
TOTAL			100%

PANTONE® 497 C

1	P7218	AST PC Atomix Opaque Mix Base	83.800
2	P7217	AST PC Atomix White	4.000
3	P7199	AST PC Atomix Black	2.150
4	P7207	AST PC Atomix Red MX	6.300
5	P8258	AST PC Atomix Yellow II	3.750
TOTAL			100%

PANTONE® 498 C

1	P7218	AST PC Atomix Opaque Mix Base	85.350
2	P7217	AST PC Atomix White	4.000
3	P7199	AST PC Atomix Black	1.100
4	P7207	AST PC Atomix Red MX	5.900
5	P8258	AST PC Atomix Yellow II	3.650
TOTAL			100%

PANTONE® 499 C

1	P7218	AST PC Atomix Opaque Mix Base	85.900
2	P7217	AST PC Atomix White	4.440
3	P7199	AST PC Atomix Black	0.890
4	P7207	AST PC Atomix Red MX	5.360
5	P8258	AST PC Atomix Yellow II	3.410
TOTAL			100%

PANTONE® 500 C

1	P7218	AST PC Atomix Opaque Mix Base	91.230
2	P7217	AST PC Atomix White	7.500
3	P7199	AST PC Atomix Black	0.150
4	P7207	AST PC Atomix Red MX	0.900
5	P8258	AST PC Atomix Yellow II	0.220
TOTAL			100%

PANTONE® 501 C

1	P7218	AST PC Atomix Opaque Mix Base	82.390
2	P7217	AST PC Atomix White	16.600
3	P7199	AST PC Atomix Black	0.110
4	P7207	AST PC Atomix Red MX	0.700
5	P8258	AST PC Atomix Yellow II	0.200
TOTAL			100%

PANTONE® 502 C

1	P7218	AST PC Atomix Opaque Mix Base	79.380
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.080
4	P7207	AST PC Atomix Red MX	0.400
5	P8258	AST PC Atomix Yellow II	0.140
TOTAL			100%

PANTONE® 503 C

1	P7218	AST PC Atomix Opaque Mix Base	79.630
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.050
4	P7207	AST PC Atomix Red MX	0.220
5	P8258	AST PC Atomix Yellow II	0.100
TOTAL			100%

PANTONE® 4975 C

1	P7218	AST PC Atomix Opaque Mix Base	77.000
2	P7217	AST PC Atomix White	1.000
3	P7199	AST PC Atomix Black	3.300
4	P7211	AST PC Atomix Magenta MX	6.000
5	P7207	AST PC Atomix Red MX	8.300
6	P8258	AST PC Atomix Yellow II	4.400
TOTAL			100%

PANTONE® 4985 C

1	P7218	AST PC Atomix Opaque Mix Base	81.900
2	P7217	AST PC Atomix White	10.000
3	P7199	AST PC Atomix Black	1.000
4	P7207	AST PC Atomix Red MX	5.400
5	P8258	AST PC Atomix Yellow II	1.700
TOTAL			100%

PANTONE® 4995 C

1	P7218	AST PC Atomix Opaque Mix Base	74.650
2	P7217	AST PC Atomix White	17.500
3	P7199	AST PC Atomix Black	0.950
4	P7207	AST PC Atomix Red MX	5.200
5	P8258	AST PC Atomix Yellow II	1.700
TOTAL			100%

PANTONE® 5005 C

1	P7218	AST PC Atomix Opaque Mix Base	76.030
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.520
4	P7207	AST PC Atomix Red MX	2.500
5	P8258	AST PC Atomix Yellow II	0.950
TOTAL			100%

PANTONE® 5015 C

1	P7218	AST PC Atomix Opaque Mix Base	78.360
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.240
4	P7207	AST PC Atomix Red MX	0.960
5	P8258	AST PC Atomix Yellow II	0.440
TOTAL			100%

PANTONE® 5025 C

1	P7218	AST PC Atomix Opaque Mix Base	79.270
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.120
4	P7207	AST PC Atomix Red MX	0.410
5	P8258	AST PC Atomix Yellow II	0.200
TOTAL			100%

PANTONE® 5035 C

1	P7218	AST PC Atomix Opaque Mix Base	79.600
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.090
4	P7207	AST PC Atomix Red MX	0.210
5	P8258	AST PC Atomix Yellow II	0.100
TOTAL			100%

PANTONE® 504 C

1	P7218	AST PC Atomix Opaque Mix Base	86.150
2	P7217	AST PC Atomix White	0.300
3	P7199	AST PC Atomix Black	1.550
4	P7211	AST PC Atomix Magenta MX	6.500
5	P7207	AST PC Atomix Red MX	5.500
TOTAL			100%

PANTONE® 505 C

1	P7218	AST PC Atomix Opaque Mix Base	84.140
2	P7217	AST PC Atomix White	1.100
3	P7199	AST PC Atomix Black	0.760
4	P7211	AST PC Atomix Magenta MX	10.800
5	P7207	AST PC Atomix Red MX	3.200
TOTAL			100%

PANTONE® 506 C

1	P7218	AST PC Atomix Opaque Mix Base	88.050
2	P7217	AST PC Atomix White	1.000
3	P7199	AST PC Atomix Black	0.450
4	P7211	AST PC Atomix Magenta MX	8.300
5	P7207	AST PC Atomix Red MX	2.200
TOTAL			100%

PANTONE® 507 C

1	P7218	AST PC Atomix Opaque Mix Base	79.520
2	P7217	AST PC Atomix White	18.500
3	P7199	AST PC Atomix Black	0.100
4	P7211	AST PC Atomix Magenta MX	1.700
5	P8258	AST PC Atomix Yellow II	0.180
TOTAL			100%

PANTONE® 508 C

1	P7218	AST PC Atomix Opaque Mix Base	79.680
2	P7217	AST PC Atomix White	19.000
3	P7199	AST PC Atomix Black	0.080
4	P7211	AST PC Atomix Magenta MX	1.100
5	P8258	AST PC Atomix Yellow II	0.140
TOTAL			100%

PANTONE® 509 C

1	P7218	AST PC Atomix Opaque Mix Base	80.540
2	P7217	AST PC Atomix White	18.500
3	P7199	AST PC Atomix Black	0.060
4	P7211	AST PC Atomix Magenta MX	0.800
5	P8258	AST PC Atomix Yellow II	0.100
TOTAL			100%

PANTONE® 510 C

1	P7218	AST PC Atomix Opaque Mix Base	79.490
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.040
4	P7211	AST PC Atomix Magenta MX	0.400
5	P8258	AST PC Atomix Yellow II	0.070
TOTAL			100%

PANTONE® 511 C

1	P7218	AST PC Atomix Opaque Mix Base	74.900
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	10.000
3	P7213	AST PC Atomix Blue RQ	10.500
4	P7211	AST PC Atomix Magenta MX	4.600
TOTAL			100%

PANTONE® 512 C

1	P7218	AST PC Atomix Opaque Mix Base	62.000
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	28.000
3	P7213	AST PC Atomix Blue RQ	9.200
4	P7211	AST PC Atomix Magenta MX	0.800
TOTAL			100%

PANTONE® 513 C

1	P7218	AST PC Atomix Opaque Mix Base	66.120
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	26.400
3	P7213	AST PC Atomix Blue RQ	7.480
TOTAL			100%

PANTONE® 514 C

1	P7218	AST PC Atomix Opaque Mix Base	78.400
2	P7217	AST PC Atomix White	13.200
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	5.450
4	P7213	AST PC Atomix Blue RQ	2.500
5	P7211	AST PC Atomix Magenta MX	0.450
TOTAL			100%

PANTONE® 515 C

1	P7218	AST PC Atomix Opaque Mix Base	85.230
2	P7217	AST PC Atomix White	12.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	1.200
4	P7213	AST PC Atomix Blue RQ	1.320
5	P7211	AST PC Atomix Magenta MX	0.250
TOTAL			100%

PANTONE® 516 C

1	P7218	AST PC Atomix Opaque Mix Base	81.300
2	P7217	AST PC Atomix White	17.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	0.520
4	P7213	AST PC Atomix Blue RQ	0.940
5	P7211	AST PC Atomix Magenta MX	0.240
TOTAL			100%

PANTONE® 517 C

1	P7218	AST PC Atomix Opaque Mix Base	79.390
2	P7217	AST PC Atomix White	19.500
3	P7213	AST PC Atomix Blue RQ	0.770
4	P7211	AST PC Atomix Magenta MX	0.280
5	P8258	AST PC Atomix Yellow II	0.060
TOTAL			100%

PANTONE® 5115 C

1	P7218	AST PC Atomix Opaque Mix Base	88.050
2	P7217	AST PC Atomix White	1.000
3	P7199	AST PC Atomix Black	1.250
4	P7213	AST PC Atomix Blue RQ	2.800
5	P7211	AST PC Atomix Magenta MX	6.900
TOTAL			100%

PANTONE® 518 C

1	P7218	AST PC Atomix Opaque Mix Base	83.200
2	P7217	AST PC Atomix White	2.000
3	P7199	AST PC Atomix Black	0.500
4	P7204	AST PC Atomix Blue B	1.600
5	P7211	AST PC Atomix Magenta MX	12.700
TOTAL			100%

PANTONE® 5125 C

1	P7218	AST PC Atomix Opaque Mix Base	91.000
2	P7217	AST PC Atomix White	1.000
3	P7199	AST PC Atomix Black	0.600
4	P7213	AST PC Atomix Blue RQ	3.500
5	P7211	AST PC Atomix Magenta MX	3.900
TOTAL			100%

PANTONE® 519 C

1	P7218	AST PC Atomix Opaque Mix Base	76.030
2	P7217	AST PC Atomix White	2.000
3	P7199	AST PC Atomix Black	0.170
4	P7213	AST PC Atomix Blue RQ	15.500
5	P7211	AST PC Atomix Magenta MX	6.300
TOTAL			100%

PANTONE® 5135 C

1	P7218	AST PC Atomix Opaque Mix Base	88.800
2	P7217	AST PC Atomix White	6.400
3	P7199	AST PC Atomix Black	1.200
4	P7211	AST PC Atomix Magenta MX	3.600
TOTAL			100%

PANTONE® 520 C

1	P7218	AST PC Atomix Opaque Mix Base	82.400
2	P7217	AST PC Atomix White	2.000
3	P7213	AST PC Atomix Blue RQ	11.600
4	P7211	AST PC Atomix Magenta MX	4.000
TOTAL			100%

PANTONE® 5145 C

1	P7218	AST PC Atomix Opaque Mix Base	81.930
2	P7217	AST PC Atomix White	15.000
3	P7199	AST PC Atomix Black	0.820
4	P7211	AST PC Atomix Magenta MX	2.050
5	P8258	AST PC Atomix Yellow II	0.200
TOTAL			100%

PANTONE® 521 C

1	P7218	AST PC Atomix Opaque Mix Base	71.190
2	P7217	AST PC Atomix White	19.000
3	P7199	AST PC Atomix Black	0.160
4	P7213	AST PC Atomix Blue RQ	7.400
5	P7211	AST PC Atomix Magenta MX	2.250
TOTAL			100%

PANTONE® 5155 C

1	P7218	AST PC Atomix Opaque Mix Base	80.880
2	P7217	AST PC Atomix White	18.000
3	P7199	AST PC Atomix Black	0.370
4	P7211	AST PC Atomix Magenta MX	0.650
5	P8258	AST PC Atomix Yellow II	0.100
TOTAL			100%

PANTONE® 522 C

1	P7218	AST PC Atomix Opaque Mix Base	78.360
2	P7217	AST PC Atomix White	18.000
3	P7199	AST PC Atomix Black	0.140
4	P7213	AST PC Atomix Blue RQ	2.650
5	P7211	AST PC Atomix Magenta MX	0.850
TOTAL			100%

PANTONE® 5165 C

1	P7218	AST PC Atomix Opaque Mix Base	81.660
2	P7217	AST PC Atomix White	18.000
3	P7199	AST PC Atomix Black	0.200
4	P7211	AST PC Atomix Magenta MX	0.140
TOTAL			100%

PANTONE® 523 C

1	P7218	AST PC Atomix Opaque Mix Base	78.280
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.120
4	P7213	AST PC Atomix Blue RQ	1.250
5	P7211	AST PC Atomix Magenta MX	0.350
TOTAL			100%

PANTONE® 5175 C

1	P7218	AST PC Atomix Opaque Mix Base	81.740
2	P7217	AST PC Atomix White	18.000
3	P7199	AST PC Atomix Black	0.140
4	P7211	AST PC Atomix Magenta MX	0.100
5	P8258	AST PC Atomix Yellow II	0.020
TOTAL			100%

PANTONE® 524 C

1	P7218	AST PC Atomix Opaque Mix Base	79.160
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.100
4	P7213	AST PC Atomix Blue RQ	0.600
5	P7211	AST PC Atomix Magenta MX	0.140
TOTAL			100%

PANTONE® 5185 C

1	P7218	AST PC Atomix Opaque Mix Base	84.200
2	P7217	AST PC Atomix White	1.500
3	P7199	AST PC Atomix Black	2.320
4	P7211	AST PC Atomix Magenta MX	11.980
TOTAL			100%

PANTONE® 5195 C

1	P7218	AST PC Atomix Opaque Mix Base	88.400
2	P7217	AST PC Atomix White	2.000
3	P7199	AST PC Atomix Black	1.000
4	P7213	AST PC Atomix Blue RQ	3.000
5	P7211	AST PC Atomix Magenta MX	5.500
6	P8258	AST PC Atomix Yellow II	0.100
TOTAL			100%

PANTONE® 5205 C

1	P7218	AST PC Atomix Opaque Mix Base	84.230
2	P7217	AST PC Atomix White	10.900
3	P7199	AST PC Atomix Black	1.220
4	P7211	AST PC Atomix Magenta MX	3.200
5	P8258	AST PC Atomix Yellow II	0.450
TOTAL			100%

PANTONE® 5215 C

1	P7218	AST PC Atomix Opaque Mix Base	79.830
2	P7217	AST PC Atomix White	18.500
3	P7199	AST PC Atomix Black	0.570
4	P7211	AST PC Atomix Magenta MX	0.950
5	P8258	AST PC Atomix Yellow II	0.150
TOTAL			100%

PANTONE® 5225 C

1	P7218	AST PC Atomix Opaque Mix Base	79.340
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.260
4	P7211	AST PC Atomix Magenta MX	0.330
5	P8258	AST PC Atomix Yellow II	0.070
TOTAL			100%

PANTONE® 5235 C

1	P7218	AST PC Atomix Opaque Mix Base	79.610
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.190
4	P7211	AST PC Atomix Magenta MX	0.160
5	P8258	AST PC Atomix Yellow II	0.040
TOTAL			100%

PANTONE® 5245 C

1	P7218	AST PC Atomix Opaque Mix Base	79.800
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.110
4	P7211	AST PC Atomix Magenta MX	0.070
5	P8258	AST PC Atomix Yellow II	0.020
TOTAL			100%

PANTONE® 525 C

1	P7218	AST PC Atomix Opaque Mix Base	85.820
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	12.600
3	P7199	AST PC Atomix Black	0.460
4	P7206	AST PC Atomix Violet	1.120
TOTAL			100%

PANTONE® 526 C

1	P7218	AST PC Atomix Opaque Mix Base	77.320
2	P7217	AST PC Atomix White	1.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	20.000
4	P7206	AST PC Atomix Violet	1.680
TOTAL			100%

PANTONE® 527 C

1	P7218	AST PC Atomix Opaque Mix Base	71.880
2	P7217	AST PC Atomix White	0.520
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	17.800
4	P7213	AST PC Atomix Blue RQ	9.800
TOTAL			100%

PANTONE® 528 C

1	P7218	AST PC Atomix Opaque Mix Base	72.520
2	P7217	AST PC Atomix White	13.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	8.600
4	P7213	AST PC Atomix Blue RQ	5.800
5	P7211	AST PC Atomix Magenta MX	0.080
TOTAL			100%

PANTONE® 529 C

1	P7218	AST PC Atomix Opaque Mix Base	72.460
2	P7217	AST PC Atomix White	19.400
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	4.800
4	P7213	AST PC Atomix Blue RQ	3.300
5	P7211	AST PC Atomix Magenta MX	0.040
TOTAL			100%

PANTONE® 530 C

1	P7218	AST PC Atomix Opaque Mix Base	77.990
2	P7217	AST PC Atomix White	20.000
3	P7213	AST PC Atomix Blue RQ	1.520
4	P7211	AST PC Atomix Magenta MX	0.490
TOTAL			100%

PANTONE® 531 C

1	P7218	AST PC Atomix Opaque Mix Base	78.950
2	P7217	AST PC Atomix White	20.000
3	P7213	AST PC Atomix Blue RQ	0.820
4	P7211	AST PC Atomix Magenta MX	0.230
TOTAL			100%

PANTONE® 5255 C

1	P7218	AST PC Atomix Opaque Mix Base	91.650
2	P7199	AST PC Atomix Black	0.950
3	P7206	AST PC Atomix Violet	5.900
4	P7203	AST PC Atomix Blue 1500	1.500
TOTAL			100%

PANTONE® 5265 C

1	P7218	AST PC Atomix Opaque Mix Base	90.400
2	P7217	AST PC Atomix White	4.200
3	P7199	AST PC Atomix Black	1.600
4	P7206	AST PC Atomix Violet	3.300
5	P7203	AST PC Atomix Blue 1500	0.500
TOTAL			100%

PANTONE® 5275 C

1	P7218	AST PC Atomix Opaque Mix Base	84.620
2	P7217	AST PC Atomix White	11.000
3	P7199	AST PC Atomix Black	1.950
4	P7206	AST PC Atomix Violet	2.280
5	P7203	AST PC Atomix Blue 1500	0.150
TOTAL			100%

PANTONE® 5285 C

1	P7218	AST PC Atomix Opaque Mix Base	75.140
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.900
4	P7206	AST PC Atomix Violet	0.630
5	P7213	AST PC Atomix Blue RQ	3.330
TOTAL			100%

PANTONE® 5295 C

1	P7218	AST PC Atomix Opaque Mix Base	78.870
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.300
4	P7206	AST PC Atomix Violet	0.160
5	P7213	AST PC Atomix Blue RQ	0.670
TOTAL			100%

PANTONE® 5305 C

1	P7218	AST PC Atomix Opaque Mix Base	79.420
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.150
4	P7206	AST PC Atomix Violet	0.380
5	P7213	AST PC Atomix Blue RQ	0.050
TOTAL			100%

PANTONE® 5315 C

1	P7218	AST PC Atomix Opaque Mix Base	79.740
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.070
4	P7213	AST PC Atomix Blue RQ	0.190
TOTAL			100%

PANTONE® 532 C

1	P7218	AST PC Atomix Opaque Mix Base	86.100
2	P7217	AST PC Atomix White	1.000
3	P7199	AST PC Atomix Black	7.000
4	P7206	AST PC Atomix Violet	3.500
5	P7204	AST PC Atomix Blue B	2.400
TOTAL			100%

PANTONE® 533 C

1	P7218	AST PC Atomix Opaque Mix Base	88.500
2	P7199	AST PC Atomix Black	2.000
3	P7206	AST PC Atomix Violet	1.000
4	P7204	AST PC Atomix Blue B	8.500
TOTAL			100%

PANTONE® 534 C

1	P7218	AST PC Atomix Opaque Mix Base	86.500
2	P7217	AST PC Atomix White	1.500
3	P7199	AST PC Atomix Black	1.400
4	P7206	AST PC Atomix Violet	0.600
5	P7204	AST PC Atomix Blue B	10.000
TOTAL			100%

PANTONE® 535 C

1	P7218	AST PC Atomix Opaque Mix Base	84.640
2	P7217	AST PC Atomix White	13.300
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	1.520
4	P7199	AST PC Atomix Black	0.220
5	P7203	AST PC Atomix Blue 1500	0.320
TOTAL			100%

PANTONE® 536 C

1	P7218	AST PC Atomix Opaque Mix Base	82.990
2	P7217	AST PC Atomix White	16.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	0.700
4	P7199	AST PC Atomix Black	0.130
5	P7203	AST PC Atomix Blue 1500	0.180
TOTAL			100%

PANTONE® 537 C

1	P7218	AST PC Atomix Opaque Mix Base	80.890
2	P7217	AST PC Atomix White	18.500
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	0.400
4	P7199	AST PC Atomix Black	0.090
5	P7203	AST PC Atomix Blue 1500	0.120
TOTAL			100%

PANTONE® 538 C

1	P7218	AST PC Atomix Opaque Mix Base	79.760
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.170
4	P7203	AST PC Atomix Blue 1500	0.040
5	P7200	AST PC Atomix Green	0.030
TOTAL			100%

PANTONE® 539 C

1	P7218	AST PC Atomix Opaque Mix Base	87.120
2	P7199	AST PC Atomix Black	1.400
3	P7204	AST PC Atomix Blue B	11.250
4	P8258	AST PC Atomix Yellow II	0.230
TOTAL			100%

PANTONE® 540 C

1	P7218	AST PC Atomix Opaque Mix Base	87.050
2	P7199	AST PC Atomix Black	0.200
3	P7204	AST PC Atomix Blue B	12.500
4	P8258	AST PC Atomix Yellow II	0.250
TOTAL			100%

PANTONE® 541 C

1	P7218	AST PC Atomix Opaque Mix Base	89.790
2	P7217	AST PC Atomix White	0.500
3	P7199	AST PC Atomix Black	0.160
4	P7204	AST PC Atomix Blue B	9.500
5	P8258	AST PC Atomix Yellow II	0.050
TOTAL			100%

PANTONE® 542 C

1	P7218	AST PC Atomix Opaque Mix Base	82.280
2	P7217	AST PC Atomix White	17.000
3	P7199	AST PC Atomix Black	0.130
4	P7206	AST PC Atomix Violet	0.040
5	P7203	AST PC Atomix Blue 1500	0.550
TOTAL			100%

PANTONE® 543 C

1	P7218	AST PC Atomix Opaque Mix Base	79.720
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.050
4	P7206	AST PC Atomix Violet	0.030
5	P7203	AST PC Atomix Blue 1500	0.200
TOTAL			100%

PANTONE® 544 C

1	P7218	AST PC Atomix Opaque Mix Base	79.830
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.040
4	P7206	AST PC Atomix Violet	0.020
5	P7203	AST PC Atomix Blue 1500	0.110
TOTAL			100%

PANTONE® 545 C

1	P7218	AST PC Atomix Opaque Mix Base	79.880
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.050
4	P7203	AST PC Atomix Blue 1500	0.070
TOTAL			100%

PANTONE® 5395 C

1	P7218	AST PC Atomix Opaque Mix Base	89.200
2	P7199	AST PC Atomix Black	4.000
3	P7203	AST PC Atomix Blue 1500	6.800
TOTAL			100%

PANTONE® 5405 C

1	P7218	AST PC Atomix Opaque Mix Base	82.350
2	P7217	AST PC Atomix White	14.000
3	P7199	AST PC Atomix Black	1.800
4	P7203	AST PC Atomix Blue 1500	1.850
TOTAL			100%

PANTONE® 5415 C

1	P7218	AST PC Atomix Opaque Mix Base	81.050
2	P7217	AST PC Atomix White	17.000
3	P7199	AST PC Atomix Black	1.000
4	P7203	AST PC Atomix Blue 1500	0.950
TOTAL			100%

PANTONE® 5425 C

1	P7218	AST PC Atomix Opaque Mix Base	78.900
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.650
4	P7203	AST PC Atomix Blue 1500	0.450
TOTAL			100%

PANTONE® 5435 C

1	P7218	AST PC Atomix Opaque Mix Base	79.550
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.300
4	P7203	AST PC Atomix Blue 1500	0.150
TOTAL			100%

PANTONE® 5445 C

1	P7218	AST PC Atomix Opaque Mix Base	79.810
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.130
4	P7203	AST PC Atomix Blue 1500	0.060
TOTAL			100%

PANTONE® 5455 C

1	P7218	AST PC Atomix Opaque Mix Base	79.840
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.100
4	P7203	AST PC Atomix Blue 1500	0.060
TOTAL			100%

PANTONE® 546 C

1	P7218	AST PC Atomix Opaque Mix Base	86.600
2	P7199	AST PC Atomix Black	1.200
3	P7204	AST PC Atomix Blue B	6.000
4	P7200	AST PC Atomix Green	6.200
TOTAL			100%

PANTONE® 547 C

1	P7218	AST PC Atomix Opaque Mix Base	84.500
2	P7217	AST PC Atomix White	0.800
3	P7199	AST PC Atomix Black	0.700
4	P7204	AST PC Atomix Blue B	7.000
5	P7200	AST PC Atomix Green	7.000
TOTAL			100%

PANTONE® 548 C

1	P7218	AST PC Atomix Opaque Mix Base	81.500
2	P7217	AST PC Atomix White	1.600
3	P7199	AST PC Atomix Black	0.500
4	P7204	AST PC Atomix Blue B	8.200
5	P7200	AST PC Atomix Green	8.200
TOTAL			100%

PANTONE® 549 C

1	P7218	AST PC Atomix Opaque Mix Base	78.450
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.400
4	P7204	AST PC Atomix Blue B	0.750
5	P7200	AST PC Atomix Green	0.400
TOTAL			100%

PANTONE® 550 C

1	P7218	AST PC Atomix Opaque Mix Base	79.250
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.220
4	P7204	AST PC Atomix Blue B	0.350
5	P7200	AST PC Atomix Green	0.180
TOTAL			100%

PANTONE® 551 C

1	P7218	AST PC Atomix Opaque Mix Base	79.620
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.120
4	P7204	AST PC Atomix Blue B	0.180
5	P7200	AST PC Atomix Green	0.080
TOTAL			100%

PANTONE® 552 C

1	P7218	AST PC Atomix Opaque Mix Base	79.830
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.060
4	P7204	AST PC Atomix Blue B	0.080
5	P7200	AST PC Atomix Green	0.030
TOTAL			100%

PANTONE® 5463 C

1	P7218	AST PC Atomix Opaque Mix Base	83.000
2	P7199	AST PC Atomix Black	2.100
3	P7204	AST PC Atomix Blue B	7.800
4	P7200	AST PC Atomix Green	7.100
TOTAL			100%

PANTONE® 5473 C

1	P7218	AST PC Atomix Opaque Mix Base	94.200
2	P7217	AST PC Atomix White	1.500
3	P7199	AST PC Atomix Black	0.600
4	P7204	AST PC Atomix Blue B	1.700
5	P7200	AST PC Atomix Green	2.000
TOTAL			100%

PANTONE® 5483 C

1	P7218	AST PC Atomix Opaque Mix Base	91.000
2	P7217	AST PC Atomix White	6.700
3	P8410	AST PC Atomix Fluo Yellow DTA FF	0.900
4	P7199	AST PC Atomix Black	0.550
5	P7204	AST PC Atomix Blue B	0.850
TOTAL			100%

PANTONE® 5493 C

1	P7218	AST PC Atomix Opaque Mix Base	87.100
2	P7217	AST PC Atomix White	11.600
3	P8410	AST PC Atomix Fluo Yellow DTA FF	0.530
4	P7199	AST PC Atomix Black	0.330
5	P7204	AST PC Atomix Blue B	0.440
TOTAL			100%

PANTONE® 5503 C

1	P7218	AST PC Atomix Opaque Mix Base	88.330
2	P7217	AST PC Atomix White	11.000
3	P8410	AST PC Atomix Fluo Yellow DTA FF	0.300
4	P7199	AST PC Atomix Black	0.170
5	P7204	AST PC Atomix Blue B	0.200
TOTAL			100%

PANTONE® 5513 C

1	P7218	AST PC Atomix Opaque Mix Base	84.120
2	P7217	AST PC Atomix White	15.300
3	P8410	AST PC Atomix Fluo Yellow DTA FF	0.270
4	P7199	AST PC Atomix Black	0.140
5	P7204	AST PC Atomix Blue B	0.170
TOTAL			100%

PANTONE® 5523 C

1	P7218	AST PC Atomix Opaque Mix Base	82.500
2	P7217	AST PC Atomix White	17.000
3	P8410	AST PC Atomix Fluo Yellow DTA FF	0.300
4	P7199	AST PC Atomix Black	0.100
5	P7204	AST PC Atomix Blue B	0.100
TOTAL			100%

PANTONE® 5467 C

1	P7218	AST PC Atomix Opaque Mix Base	93.070
2	P7199	AST PC Atomix Black	1.950
3	P7204	AST PC Atomix Blue B	2.980
4	P7208	AST PC Atomix Lemon MX	2.000
TOTAL			100%

PANTONE® 5477 C

1	P7218	AST PC Atomix Opaque Mix Base	96.410
2	P7217	AST PC Atomix White	1.000
3	P7199	AST PC Atomix Black	1.000
4	P7204	AST PC Atomix Blue B	0.940
5	P7208	AST PC Atomix Lemon MX	0.650
TOTAL			100%

PANTONE® 5487 C

1	P7218	AST PC Atomix Opaque Mix Base	91.350
2	P7217	AST PC Atomix White	6.200
3	P7199	AST PC Atomix Black	1.100
4	P7204	AST PC Atomix Blue B	0.780
5	P7208	AST PC Atomix Lemon MX	0.570
TOTAL			100%

PANTONE® 5497 C

1	P7218	AST PC Atomix Opaque Mix Base	88.980
2	P7217	AST PC Atomix White	10.000
3	P7199	AST PC Atomix Black	0.620
4	P7204	AST PC Atomix Blue B	0.260
5	P7208	AST PC Atomix Lemon MX	0.140
TOTAL			100%

PANTONE® 556 C

1	P7218	AST PC Atomix Opaque Mix Base	79.630
2	P7217	AST PC Atomix White	17.000
3	P7199	AST PC Atomix Black	0.550
4	P7200	AST PC Atomix Green	2.250
5	P7208	AST PC Atomix Lemon MX	0.570
TOTAL			100%

PANTONE® 5507 C

1	P7218	AST PC Atomix Opaque Mix Base	86.430
2	P7217	AST PC Atomix White	13.000
3	P7199	AST PC Atomix Black	0.370
4	P7204	AST PC Atomix Blue B	0.130
5	P7208	AST PC Atomix Lemon MX	0.070
TOTAL			100%

PANTONE® 557 C

1	P7218	AST PC Atomix Opaque Mix Base	80.080
2	P7217	AST PC Atomix White	18.000
3	P7199	AST PC Atomix Black	0.360
4	P7200	AST PC Atomix Green	1.200
5	P7208	AST PC Atomix Lemon MX	0.360
TOTAL			100%

PANTONE® 5517 C

1	P7218	AST PC Atomix Opaque Mix Base	83.630
2	P7217	AST PC Atomix White	16.000
3	P7199	AST PC Atomix Black	0.220
4	P7204	AST PC Atomix Blue B	0.100
5	P7208	AST PC Atomix Lemon MX	0.050
TOTAL			100%

PANTONE® 558 C

1	P7218	AST PC Atomix Opaque Mix Base	79.900
2	P7217	AST PC Atomix White	19.000
3	P7199	AST PC Atomix Black	0.250
4	P7200	AST PC Atomix Green	0.600
5	P7208	AST PC Atomix Lemon MX	0.250
TOTAL			100%

PANTONE® 5527 C

1	P7218	AST PC Atomix Opaque Mix Base	91.810
2	P7217	AST PC Atomix White	7.800
3	P8410	AST PC Atomix Fluo Yellow DTA FF	0.220
4	P7199	AST PC Atomix Black	0.130
5	P7204	AST PC Atomix Blue B	0.040
TOTAL			100%

PANTONE® 559 C

1	P7218	AST PC Atomix Opaque Mix Base	79.340
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.180
4	P7200	AST PC Atomix Green	0.300
5	P7208	AST PC Atomix Lemon MX	0.180
TOTAL			100%

PANTONE® 553 C

1	P7218	AST PC Atomix Opaque Mix Base	90.700
2	P7199	AST PC Atomix Black	1.300
3	P7200	AST PC Atomix Green	5.400
4	P7208	AST PC Atomix Lemon MX	2.600
TOTAL			100%

PANTONE® 5535 C

1	P7218	AST PC Atomix Opaque Mix Base	86.300
2	P7199	AST PC Atomix Black	3.200
3	P7200	AST PC Atomix Green	8.200
4	P7208	AST PC Atomix Lemon MX	2.300
TOTAL			100%

PANTONE® 554 C

1	P7218	AST PC Atomix Opaque Mix Base	89.300
2	P7217	AST PC Atomix White	2.500
3	P7199	AST PC Atomix Black	1.000
4	P7200	AST PC Atomix Green	5.520
5	P7208	AST PC Atomix Lemon MX	1.680
TOTAL			100%

PANTONE® 5545 C

1	P7218	AST PC Atomix Opaque Mix Base	89.800
2	P7217	AST PC Atomix White	4.000
3	P7199	AST PC Atomix Black	1.800
4	P7200	AST PC Atomix Green	3.000
5	P7208	AST PC Atomix Lemon MX	1.400
TOTAL			100%

PANTONE® 555 C

1	P7218	AST PC Atomix Opaque Mix Base	86.150
2	P7217	AST PC Atomix White	7.000
3	P7199	AST PC Atomix Black	0.850
4	P7200	AST PC Atomix Green	4.600
5	P7208	AST PC Atomix Lemon MX	1.400
TOTAL			100%

PANTONE® 5555 C

1	P7218	AST PC Atomix Opaque Mix Base	88.400
2	P7217	AST PC Atomix White	8.000
3	P7199	AST PC Atomix Black	1.200
4	P7200	AST PC Atomix Green	1.600
5	P7208	AST PC Atomix Lemon MX	0.800
TOTAL			100%

PANTONE® 5565 C

1	P7218	AST PC Atomix Opaque Mix Base	83.100
2	P7217	AST PC Atomix White	15.000
3	P7199	AST PC Atomix Black	0.800
4	P7200	AST PC Atomix Green	0.820
5	P7208	AST PC Atomix Lemon MX	0.280
TOTAL			100%

PANTONE® 563 C

1	P7218	AST PC Atomix Opaque Mix Base	77.600
2	P7217	AST PC Atomix White	19.500
3	P7199	AST PC Atomix Black	0.420
4	P7200	AST PC Atomix Green	2.400
5	P7208	AST PC Atomix Lemon MX	0.080
TOTAL			100%

PANTONE® 5575 C

1	P7218	AST PC Atomix Opaque Mix Base	78.820
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.520
4	P7200	AST PC Atomix Green	0.410
5	P7208	AST PC Atomix Lemon MX	0.250
TOTAL			100%

PANTONE® 564 C

1	P7218	AST PC Atomix Opaque Mix Base	78.470
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.250
4	P7200	AST PC Atomix Green	1.200
5	P7208	AST PC Atomix Lemon MX	0.080
TOTAL			100%

PANTONE® 5585 C

1	P7218	AST PC Atomix Opaque Mix Base	79.300
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.300
4	P7200	AST PC Atomix Green	0.200
5	P7208	AST PC Atomix Lemon MX	0.200
TOTAL			100%

PANTONE® 565 C

1	P7218	AST PC Atomix Opaque Mix Base	79.160
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.180
4	P7200	AST PC Atomix Green	0.600
5	P7208	AST PC Atomix Lemon MX	0.060
TOTAL			100%

PANTONE® 5595 C

1	P7218	AST PC Atomix Opaque Mix Base	79.540
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.210
4	P7200	AST PC Atomix Green	0.100
5	P7208	AST PC Atomix Lemon MX	0.150
TOTAL			100%

PANTONE® 566 C

1	P7218	AST PC Atomix Opaque Mix Base	79.530
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.100
4	P7200	AST PC Atomix Green	0.300
5	P7208	AST PC Atomix Lemon MX	0.070
TOTAL			100%

PANTONE® 560 C

1	P7218	AST PC Atomix Opaque Mix Base	91.200
2	P7199	AST PC Atomix Black	1.600
3	P7200	AST PC Atomix Green	7.000
4	P7208	AST PC Atomix Lemon MX	0.200
TOTAL			100%

PANTONE® 5605 C

1	P7218	AST PC Atomix Opaque Mix Base	86.870
2	P7199	AST PC Atomix Black	3.800
3	P7200	AST PC Atomix Green	4.830
4	P7208	AST PC Atomix Lemon MX	4.500
TOTAL			100%

PANTONE® 561 C

1	P7218	AST PC Atomix Opaque Mix Base	93.020
2	P7217	AST PC Atomix White	0.500
3	P7199	AST PC Atomix Black	0.750
4	P7200	AST PC Atomix Green	5.600
5	P7208	AST PC Atomix Lemon MX	0.130
TOTAL			100%

PANTONE® 5615 C

1	P7218	AST PC Atomix Opaque Mix Base	93.100
2	P7217	AST PC Atomix White	3.500
3	P7199	AST PC Atomix Black	1.280
4	P7200	AST PC Atomix Green	0.930
5	P7208	AST PC Atomix Lemon MX	1.190
TOTAL			100%

PANTONE® 562 C

1	P7218	AST PC Atomix Opaque Mix Base	91.380
2	P7217	AST PC Atomix White	3.000
3	P7199	AST PC Atomix Black	0.720
4	P7200	AST PC Atomix Green	4.800
5	P7208	AST PC Atomix Lemon MX	0.100
TOTAL			100%

PANTONE® 5625 C

1	P7218	AST PC Atomix Opaque Mix Base	92.370
2	P7217	AST PC Atomix White	5.000
3	P7199	AST PC Atomix Black	0.940
4	P7200	AST PC Atomix Green	0.740
5	P7208	AST PC Atomix Lemon MX	0.950
TOTAL			100%

PANTONE® 5635 C

1	P7218	AST PC Atomix Opaque Mix Base	83.610
2	P7217	AST PC Atomix White	15.000
3	P7199	AST PC Atomix Black	0.600
4	P7200	AST PC Atomix Green	0.400
5	P7208	AST PC Atomix Lemon MX	0.390
TOTAL			100%

PANTONE® 570 C

1	P7218	AST PC Atomix Opaque Mix Base	78.530
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.130
4	P7200	AST PC Atomix Green	1.300
5	P7208	AST PC Atomix Lemon MX	0.040
TOTAL			100%

PANTONE® 5645 C

1	P7218	AST PC Atomix Opaque Mix Base	80.630
2	P7217	AST PC Atomix White	18.500
3	P7199	AST PC Atomix Black	0.430
4	P7200	AST PC Atomix Green	0.200
5	P7208	AST PC Atomix Lemon MX	0.240
TOTAL			100%

PANTONE® 571 C

1	P7218	AST PC Atomix Opaque Mix Base	79.560
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.070
4	P7200	AST PC Atomix Green	0.340
5	P7208	AST PC Atomix Lemon MX	0.030
TOTAL			100%

PANTONE® 5655 C

1	P7218	AST PC Atomix Opaque Mix Base	80.530
2	P7217	AST PC Atomix White	19.000
3	P7199	AST PC Atomix Black	0.250
4	P7200	AST PC Atomix Green	0.100
5	P7208	AST PC Atomix Lemon MX	0.120
TOTAL			100%

PANTONE® 572 C

1	P7218	AST PC Atomix Opaque Mix Base	79.280
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.090
4	P7200	AST PC Atomix Green	0.600
5	P7208	AST PC Atomix Lemon MX	0.030
TOTAL			100%

PANTONE® 5665 C

1	P7218	AST PC Atomix Opaque Mix Base	80.590
2	P7217	AST PC Atomix White	19.000
3	P7199	AST PC Atomix Black	0.210
4	P7200	AST PC Atomix Green	0.050
5	P7208	AST PC Atomix Lemon MX	0.150
TOTAL			100%

PANTONE® 573 C

1	P7218	AST PC Atomix Opaque Mix Base	79.580
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.070
4	P7200	AST PC Atomix Green	0.300
5	P7208	AST PC Atomix Lemon MX	0.050
TOTAL			100%

PANTONE® 567 C

1	P7218	AST PC Atomix Opaque Mix Base	90.300
2	P7199	AST PC Atomix Black	1.800
3	P7200	AST PC Atomix Green	7.000
4	P7208	AST PC Atomix Lemon MX	0.900
TOTAL			100%

PANTONE® 574 C

1	P7218	AST PC Atomix Opaque Mix Base	91.400
2	P7217	AST PC Atomix White	0.500
3	P7199	AST PC Atomix Black	1.300
4	P7200	AST PC Atomix Green	0.300
5	P7208	AST PC Atomix Lemon MX	6.500
TOTAL			100%

PANTONE® 568 C

1	P7218	AST PC Atomix Opaque Mix Base	90.850
2	P7217	AST PC Atomix White	1.200
3	P7199	AST PC Atomix Black	0.550
4	P7200	AST PC Atomix Green	7.200
5	P7208	AST PC Atomix Lemon MX	0.200
TOTAL			100%

PANTONE® 575 C

1	P7218	AST PC Atomix Opaque Mix Base	93.150
2	P7217	AST PC Atomix White	1.500
3	P7199	AST PC Atomix Black	0.450
4	P7200	AST PC Atomix Green	0.600
5	P7208	AST PC Atomix Lemon MX	4.300
TOTAL			100%

PANTONE® 569 C

1	P7218	AST PC Atomix Opaque Mix Base	87.910
2	P7217	AST PC Atomix White	4.500
3	P7199	AST PC Atomix Black	0.320
4	P7200	AST PC Atomix Green	7.200
5	P7208	AST PC Atomix Lemon MX	0.070
TOTAL			100%

PANTONE® 576 C

1	P7218	AST PC Atomix Opaque Mix Base	92.900
2	P7217	AST PC Atomix White	3.000
3	P7199	AST PC Atomix Black	0.250
4	P7200	AST PC Atomix Green	0.550
5	P7208	AST PC Atomix Lemon MX	3.300
TOTAL			100%

PANTONE® 577 C

1	P7218	AST PC Atomix Opaque Mix Base	86.620
2	P7217	AST PC Atomix White	12.000
3	P7199	AST PC Atomix Black	0.130
4	P7200	AST PC Atomix Green	0.250
5	P7208	AST PC Atomix Lemon MX	1.000
TOTAL			100%

PANTONE® 5773 C

1	P7218	AST PC Atomix Opaque Mix Base	84.310
2	P7217	AST PC Atomix White	12.000
3	P7199	AST PC Atomix Black	0.650
4	P7200	AST PC Atomix Green	0.390
5	P8258	AST PC Atomix Yellow II	2.650
TOTAL			100%

PANTONE® 578 C

1	P7218	AST PC Atomix Opaque Mix Base	79.070
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.110
4	P7200	AST PC Atomix Green	0.170
5	P7208	AST PC Atomix Lemon MX	0.650
TOTAL			100%

PANTONE® 5783 C

1	P7218	AST PC Atomix Opaque Mix Base	88.800
2	P7217	AST PC Atomix White	9.500
3	P7199	AST PC Atomix Black	0.400
4	P7200	AST PC Atomix Green	0.150
5	P8258	AST PC Atomix Yellow II	1.150
TOTAL			100%

PANTONE® 579 C

1	P7218	AST PC Atomix Opaque Mix Base	79.170
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.100
4	P7200	AST PC Atomix Green	0.130
5	P7208	AST PC Atomix Lemon MX	0.600
TOTAL			100%

PANTONE® 5793 C

1	P7218	AST PC Atomix Opaque Mix Base	78.850
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.260
4	P7200	AST PC Atomix Green	0.090
5	P8258	AST PC Atomix Yellow II	0.800
TOTAL			100%

PANTONE® 580 C

1	P7218	AST PC Atomix Opaque Mix Base	79.200
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.100
4	P7200	AST PC Atomix Green	0.100
5	P7208	AST PC Atomix Lemon MX	0.600
TOTAL			100%

PANTONE® 5803 C

1	P7218	AST PC Atomix Opaque Mix Base	79.190
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.200
4	P7200	AST PC Atomix Green	0.060
5	P8258	AST PC Atomix Yellow II	0.550
TOTAL			100%

PANTONE® 5743 C

1	P7218	AST PC Atomix Opaque Mix Base	88.610
2	P7217	AST PC Atomix White	0.600
3	P7199	AST PC Atomix Black	1.100
4	P7200	AST PC Atomix Green	1.190
5	P8258	AST PC Atomix Yellow II	8.500
TOTAL			100%

PANTONE® 5747 C

1	P7218	AST PC Atomix Opaque Mix Base	82.110
2	P7217	AST PC Atomix White	0.400
3	P7199	AST PC Atomix Black	0.950
4	P7200	AST PC Atomix Green	1.040
5	P8258	AST PC Atomix Yellow II	15.500
TOTAL			100%

PANTONE® 5753 C

1	P7218	AST PC Atomix Opaque Mix Base	89.200
2	P7217	AST PC Atomix White	3.800
3	P7199	AST PC Atomix Black	1.000
4	P7200	AST PC Atomix Green	0.700
5	P8258	AST PC Atomix Yellow II	5.300
TOTAL			100%

PANTONE® 5757 C

1	P7218	AST PC Atomix Opaque Mix Base	81.690
2	P7217	AST PC Atomix White	6.080
3	P7199	AST PC Atomix Black	0.780
4	P7200	AST PC Atomix Green	1.000
5	P8258	AST PC Atomix Yellow II	10.450
TOTAL			100%

PANTONE® 5763 C

1	P7218	AST PC Atomix Opaque Mix Base	90.100
2	P7217	AST PC Atomix White	4.000
3	P7199	AST PC Atomix Black	0.800
4	P7200	AST PC Atomix Green	0.600
5	P8258	AST PC Atomix Yellow II	4.500
TOTAL			100%

PANTONE® 5767 C

1	P7218	AST PC Atomix Opaque Mix Base	80.620
2	P7217	AST PC Atomix White	11.000
3	P7199	AST PC Atomix Black	0.680
4	P7200	AST PC Atomix Green	0.700
5	P8258	AST PC Atomix Yellow II	7.000
TOTAL			100%

PANTONE® 5777 C

1	P7218	AST PC Atomix Opaque Mix Base	74.460
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.580
4	P7200	AST PC Atomix Green	0.460
5	P8258	AST PC Atomix Yellow II	4.500
TOTAL			100%

PANTONE® 5787 C

1	P7218	AST PC Atomix Opaque Mix Base	78.280
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.260
4	P7200	AST PC Atomix Green	0.160
5	P8258	AST PC Atomix Yellow II	1.300
TOTAL			100%

PANTONE® 5797 C

1	P7218	AST PC Atomix Opaque Mix Base	78.850
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.200
4	P7200	AST PC Atomix Green	0.100
5	P8258	AST PC Atomix Yellow II	0.850
TOTAL			100%

PANTONE® 5807 C

1	P7218	AST PC Atomix Opaque Mix Base	79.110
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.130
4	P7200	AST PC Atomix Green	0.080
5	P8258	AST PC Atomix Yellow II	0.680
TOTAL			100%

PANTONE® 581 C

1	P7218	AST PC Atomix Opaque Mix Base	80.150
2	P7217	AST PC Atomix White	0.500
3	P7199	AST PC Atomix Black	0.400
4	P7200	AST PC Atomix Green	0.550
5	P8258	AST PC Atomix Yellow II	18.400
TOTAL			100%

PANTONE® 582 C

1	P7218	AST PC Atomix Opaque Mix Base	85.200
2	P8410	AST PC Atomix Fluo Yellow DTA FF	10.000
3	P7213	AST PC Atomix Blue RQ	2.200
4	P8258	AST PC Atomix Yellow II	2.600
TOTAL			100%

PANTONE® 583 C

1	P7218	AST PC Atomix Opaque Mix Base	76.290
2	P7217	AST PC Atomix White	10.000
3	P7200	AST PC Atomix Green	0.450
4	P8258	AST PC Atomix Yellow II	4.680
5	P7208	AST PC Atomix Lemon MX	8.580
TOTAL			100%

PANTONE® 584 C

1	P7218	AST PC Atomix Opaque Mix Base	77.320
2	P7217	AST PC Atomix White	19.000
3	P7200	AST PC Atomix Green	0.180
4	P8258	AST PC Atomix Yellow II	1.200
5	P7208	AST PC Atomix Lemon MX	2.300
TOTAL			100%

PANTONE® 585 C

1	P7218	AST PC Atomix Opaque Mix Base	87.750
2	P7217	AST PC Atomix White	10.000
3	P8410	AST PC Atomix Fluo Yellow DTA FF	0.300
4	P7213	AST PC Atomix Blue RQ	0.550
5	P7208	AST PC Atomix Lemon MX	1.400
TOTAL			100%

PANTONE® 586 C

1	P7218	AST PC Atomix Opaque Mix Base	78.400
2	P7217	AST PC Atomix White	18.800
3	P7213	AST PC Atomix Blue RQ	0.800
4	P7208	AST PC Atomix Lemon MX	2.000
TOTAL			100%

PANTONE® 587 C

1	P7218	AST PC Atomix Opaque Mix Base	78.080
2	P7217	AST PC Atomix White	20.000
3	P7213	AST PC Atomix Blue RQ	0.500
4	P8258	AST PC Atomix Yellow II	0.120
5	P7208	AST PC Atomix Lemon MX	1.300
TOTAL			100%

PANTONE® 5815 C

1	P7218	AST PC Atomix Opaque Mix Base	85.840
2	P7199	AST PC Atomix Black	0.660
3	P7200	AST PC Atomix Green	0.400
4	P8258	AST PC Atomix Yellow II	13.100
TOTAL			100%

PANTONE® 5825 C

1	P7218	AST PC Atomix Opaque Mix Base	93.130
2	P7217	AST PC Atomix White	3.000
3	P7199	AST PC Atomix Black	0.380
4	P7200	AST PC Atomix Green	0.190
5	P8258	AST PC Atomix Yellow II	3.300
TOTAL			100%

PANTONE® 5835 C

1	P7218	AST PC Atomix Opaque Mix Base	89.640
2	P7217	AST PC Atomix White	7.000
3	P7199	AST PC Atomix Black	0.400
4	P7200	AST PC Atomix Green	0.160
5	P8258	AST PC Atomix Yellow II	2.800
TOTAL			100%

PANTONE® 5845 C

1	P7218	AST PC Atomix Opaque Mix Base	81.150
2	P7217	AST PC Atomix White	15.000
3	P7199	AST PC Atomix Black	0.500
4	P7200	AST PC Atomix Green	0.150
5	P8258	AST PC Atomix Yellow II	3.200
TOTAL			100%

PANTONE® 5855 C

1	P7218	AST PC Atomix Opaque Mix Base	78.250
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.280
4	P7200	AST PC Atomix Green	0.070
5	P8258	AST PC Atomix Yellow II	1.400
TOTAL			100%

PANTONE® 5865 C

1	P7218	AST PC Atomix Opaque Mix Base	78.630
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.220
4	P7200	AST PC Atomix Green	0.050
5	P8258	AST PC Atomix Yellow II	1.100
TOTAL			100%

PANTONE® 5875 C

1	P7218	AST PC Atomix Opaque Mix Base	78.800
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.200
4	P7200	AST PC Atomix Green	0.050
5	P8258	AST PC Atomix Yellow II	0.950
TOTAL			100%

PANTONE® 600 C

1	P7218	AST PC Atomix Opaque Mix Base	79.000
2	P7217	AST PC Atomix White	20.000
3	P7213	AST PC Atomix Blue RQ	0.250
4	P8258	AST PC Atomix Yellow II	0.150
5	P7208	AST PC Atomix Lemon MX	0.600
TOTAL			100%

PANTONE® 601 C

1	P7218	AST PC Atomix Opaque Mix Base	78.460
2	P7217	AST PC Atomix White	20.000
3	P7213	AST PC Atomix Blue RQ	0.350
4	P8258	AST PC Atomix Yellow II	0.270
5	P7208	AST PC Atomix Lemon MX	0.920
TOTAL			100%

PANTONE® 602 C

1	P7218	AST PC Atomix Opaque Mix Base	78.470
2	P7217	AST PC Atomix White	20.000
3	P7213	AST PC Atomix Blue RQ	0.330
4	P8258	AST PC Atomix Yellow II	0.180
5	P7208	AST PC Atomix Lemon MX	1.020
TOTAL			100%

PANTONE® 603 C

1	P7218	AST PC Atomix Opaque Mix Base	85.860
2	P7217	AST PC Atomix White	11.000
3	P7213	AST PC Atomix Blue RQ	0.500
4	P8258	AST PC Atomix Yellow II	0.360
5	P7208	AST PC Atomix Lemon MX	2.280
TOTAL			100%

PANTONE® 604 C

1	P7218	AST PC Atomix Opaque Mix Base	91.340
2	P7217	AST PC Atomix White	5.000
3	P7213	AST PC Atomix Blue RQ	0.400
4	P8258	AST PC Atomix Yellow II	0.260
5	P7208	AST PC Atomix Lemon MX	3.000
TOTAL			100%

PANTONE® 605 C

1	P7218	AST PC Atomix Opaque Mix Base	93.340
2	P7217	AST PC Atomix White	0.500
3	P7213	AST PC Atomix Blue RQ	0.480
4	P8258	AST PC Atomix Yellow II	0.380
5	P7208	AST PC Atomix Lemon MX	5.300
TOTAL			100%

PANTONE® 606 C

1	P7218	AST PC Atomix Opaque Mix Base	73.050
2	P7213	AST PC Atomix Blue RQ	0.950
3	P8258	AST PC Atomix Yellow II	2.000
4	P7208	AST PC Atomix Lemon MX	24.000
TOTAL			100%

PANTONE® 607 C

1	P7218	AST PC Atomix Opaque Mix Base	79.220
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.030
4	P7208	AST PC Atomix Lemon MX	0.750
TOTAL			100%

PANTONE® 608 C

1	P7218	AST PC Atomix Opaque Mix Base	78.450
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.050
4	P7208	AST PC Atomix Lemon MX	1.500
TOTAL			100%

PANTONE® 609 C

1	P7218	AST PC Atomix Opaque Mix Base	78.850
2	P7217	AST PC Atomix White	19.000
3	P7199	AST PC Atomix Black	0.050
4	P7208	AST PC Atomix Lemon MX	2.100
TOTAL			100%

PANTONE® 610 C

1	P7218	AST PC Atomix Opaque Mix Base	80.700
2	P7217	AST PC Atomix White	15.000
3	P7199	AST PC Atomix Black	0.100
4	P7208	AST PC Atomix Lemon MX	4.200
TOTAL			100%

PANTONE® 611 C

1	P7218	AST PC Atomix Opaque Mix Base	78.030
2	P7217	AST PC Atomix White	8.360
3	P7199	AST PC Atomix Black	0.140
4	P7208	AST PC Atomix Lemon MX	13.470
TOTAL			100%

PANTONE® 612 C

1	P7218	AST PC Atomix Opaque Mix Base	76.660
2	P7217	AST PC Atomix White	4.020
3	P7199	AST PC Atomix Black	0.160
4	P8258	AST PC Atomix Yellow II	1.170
5	P7208	AST PC Atomix Lemon MX	17.990
TOTAL			100%

PANTONE® 613 C

1	P7218	AST PC Atomix Opaque Mix Base	73.780
2	P7217	AST PC Atomix White	1.500
3	P7199	AST PC Atomix Black	0.220
4	P8258	AST PC Atomix Yellow II	3.500
5	P7208	AST PC Atomix Lemon MX	21.000
TOTAL			100%

PANTONE® 614 C

1	P7218	AST PC Atomix Opaque Mix Base	78.650
2	P7217	AST PC Atomix White	20.000
3	P7213	AST PC Atomix Blue RQ	0.750
4	P8258	AST PC Atomix Yellow II	0.600
TOTAL			100%

PANTONE® 615 C

1	P7218	AST PC Atomix Opaque Mix Base	77.250
2	P7217	AST PC Atomix White	20.000
3	P7213	AST PC Atomix Blue RQ	1.550
4	P8258	AST PC Atomix Yellow II	1.200
TOTAL			100%

PANTONE® 616 C

1	P7218	AST PC Atomix Opaque Mix Base	76.550
2	P7217	AST PC Atomix White	20.000
3	P7213	AST PC Atomix Blue RQ	1.800
4	P8258	AST PC Atomix Yellow II	1.650
TOTAL			100%

PANTONE® 617 C

1	P7218	AST PC Atomix Opaque Mix Base	71.380
2	P7217	AST PC Atomix White	20.000
3	P7213	AST PC Atomix Blue RQ	4.500
4	P8258	AST PC Atomix Yellow II	4.120
TOTAL			100%

PANTONE® 618 C

1	P7218	AST PC Atomix Opaque Mix Base	82.380
2	P7217	AST PC Atomix White	8.000
3	P7213	AST PC Atomix Blue RQ	4.500
4	P8258	AST PC Atomix Yellow II	5.120
TOTAL			100%

PANTONE® 619 C

1	P7218	AST PC Atomix Opaque Mix Base	87.800
2	P7217	AST PC Atomix White	3.800
3	P7213	AST PC Atomix Blue RQ	3.800
4	P8258	AST PC Atomix Yellow II	4.600
TOTAL			100%

PANTONE® 620 C

1	P7218	AST PC Atomix Opaque Mix Base	88.100
2	P7217	AST PC Atomix White	1.700
3	P7213	AST PC Atomix Blue RQ	4.200
4	P8258	AST PC Atomix Yellow II	6.000
TOTAL			100%

PANTONE® 621 C

1	P7218	AST PC Atomix Opaque Mix Base	79.740
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.080
4	P7200	AST PC Atomix Green	0.100
5	P8258	AST PC Atomix Yellow II	0.080
TOTAL			100%

PANTONE® 622 C

1	P7218	AST PC Atomix Opaque Mix Base	79.430
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.160
4	P7200	AST PC Atomix Green	0.270
5	P8258	AST PC Atomix Yellow II	0.140
TOTAL			100%

PANTONE® 623 C

1	P7218	AST PC Atomix Opaque Mix Base	78.890
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.290
4	P7200	AST PC Atomix Green	0.560
5	P8258	AST PC Atomix Yellow II	0.260
TOTAL			100%

PANTONE® 624 C

1	P7218	AST PC Atomix Opaque Mix Base	83.740
2	P7217	AST PC Atomix White	14.000
3	P7199	AST PC Atomix Black	0.580
4	P7200	AST PC Atomix Green	1.160
5	P8258	AST PC Atomix Yellow II	0.520
TOTAL			100%

PANTONE® 625 C

1	P7218	AST PC Atomix Opaque Mix Base	90.000
2	P7217	AST PC Atomix White	6.000
3	P7199	AST PC Atomix Black	0.850
4	P7200	AST PC Atomix Green	2.350
5	P8258	AST PC Atomix Yellow II	0.800
TOTAL			100%

PANTONE® 626 C

1	P7218	AST PC Atomix Opaque Mix Base	90.350
2	P7217	AST PC Atomix White	2.500
3	P7199	AST PC Atomix Black	1.150
4	P7200	AST PC Atomix Green	4.900
5	P8258	AST PC Atomix Yellow II	1.100
TOTAL			100%

PANTONE® 627 C

1	P7218	AST PC Atomix Opaque Mix Base	83.480
2	P7199	AST PC Atomix Black	1.320
3	P7200	AST PC Atomix Green	13.000
4	P8258	AST PC Atomix Yellow II	2.200
TOTAL			100%

PANTONE® 628 C

1	P7218	AST PC Atomix Opaque Mix Base	79.810
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.030
4	P7204	AST PC Atomix Blue B	0.050
5	P7200	AST PC Atomix Green	0.110
TOTAL			100%

PANTONE® 629 C

1	P7218	AST PC Atomix Opaque Mix Base	82.640
2	P7217	AST PC Atomix White	17.000
3	P7199	AST PC Atomix Black	0.040
4	P7204	AST PC Atomix Blue B	0.150
5	P7200	AST PC Atomix Green	0.170
TOTAL			100%

PANTONE® 630 C

1	P7218	AST PC Atomix Opaque Mix Base	83.170
2	P7217	AST PC Atomix White	16.000
3	P7199	AST PC Atomix Black	0.080
4	P7204	AST PC Atomix Blue B	0.450
5	P7200	AST PC Atomix Green	0.300
TOTAL			100%

PANTONE® 631 C

1	P7218	AST PC Atomix Opaque Mix Base	92.150
2	P7217	AST PC Atomix White	6.500
3	P7199	AST PC Atomix Black	0.050
4	P7204	AST PC Atomix Blue B	0.900
5	P7200	AST PC Atomix Green	0.400
TOTAL			100%

PANTONE® 632 C

1	P7218	AST PC Atomix Opaque Mix Base	94.360
2	P7217	AST PC Atomix White	3.000
3	P7199	AST PC Atomix Black	0.040
4	P7204	AST PC Atomix Blue B	1.800
5	P7200	AST PC Atomix Green	0.800
TOTAL			100%

PANTONE® 633 C

1	P7218	AST PC Atomix Opaque Mix Base	95.250
2	P7217	AST PC Atomix White	1.000
3	P7204	AST PC Atomix Blue B	2.750
4	P7200	AST PC Atomix Green	1.000
TOTAL			100%

PANTONE® 634 C

1	P7218	AST PC Atomix Opaque Mix Base	93.800
2	P7217	AST PC Atomix White	0.800
3	P7204	AST PC Atomix Blue B	4.200
4	P7200	AST PC Atomix Green	1.200
TOTAL			100%

PANTONE® 635 C

1	P7218	AST PC Atomix Opaque Mix Base	79.650
2	P7217	AST PC Atomix White	20.000
3	P8410	AST PC Atomix Fluo Yellow DTA FF	0.130
4	P7204	AST PC Atomix Blue B	0.220
TOTAL			100%

PANTONE® 636 C

1	P7218	AST PC Atomix Opaque Mix Base	79.080
2	P7217	AST PC Atomix White	20.000
3	P8410	AST PC Atomix Fluo Yellow DTA FF	0.550
4	P7203	AST PC Atomix Blue 1500	0.370
TOTAL			100%

PANTONE® 637 C

1	P7218	AST PC Atomix Opaque Mix Base	79.100
2	P7217	AST PC Atomix White	19.000
3	P8410	AST PC Atomix Fluo Yellow DTA FF	0.550
4	P7204	AST PC Atomix Blue B	1.350
TOTAL			100%

PANTONE® 638 C

1	P7218	AST PC Atomix Opaque Mix Base	92.950
2	P7217	AST PC Atomix White	4.800
3	P8410	AST PC Atomix Fluo Yellow DTA FF	0.550
4	P7204	AST PC Atomix Blue B	1.700
TOTAL			100%

PANTONE® 639 C

1	P7218	AST PC Atomix Opaque Mix Base	98.200
2	P8410	AST PC Atomix Fluo Yellow DTA FF	0.350
3	P7204	AST PC Atomix Blue B	1.450
TOTAL			100%

PANTONE® 640 C

1	P7218	AST PC Atomix Opaque Mix Base	97.400
2	P8410	AST PC Atomix Fluo Yellow DTA FF	0.480
3	P7204	AST PC Atomix Blue B	2.120
TOTAL			100%

PANTONE® 641 C

1	P7218	AST PC Atomix Opaque Mix Base	94.750
2	P8410	AST PC Atomix Fluo Yellow DTA FF	0.950
3	P7204	AST PC Atomix Blue B	4.300
TOTAL			100%

PANTONE® 642 C

1	P7218	AST PC Atomix Opaque Mix Base	79.880
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.050
4	P7206	AST PC Atomix Violet	0.010
5	P7203	AST PC Atomix Blue 1500	0.060
TOTAL			100%

PANTONE® 643 C

1	P7218	AST PC Atomix Opaque Mix Base	79.850
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.060
4	P7206	AST PC Atomix Violet	0.020
5	P7203	AST PC Atomix Blue 1500	0.070
TOTAL			100%

PANTONE® 644 C

1	P7218	AST PC Atomix Opaque Mix Base	79.480
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.210
4	P7206	AST PC Atomix Violet	0.060
5	P7203	AST PC Atomix Blue 1500	0.250
TOTAL			100%

PANTONE® 645 C

1	P7218	AST PC Atomix Opaque Mix Base	80.010
2	P7217	AST PC Atomix White	19.000
3	P7199	AST PC Atomix Black	0.360
4	P7206	AST PC Atomix Violet	0.130
5	P7203	AST PC Atomix Blue 1500	0.500
TOTAL			100%

PANTONE® 646 C

1	P7218	AST PC Atomix Opaque Mix Base	90.440
2	P7217	AST PC Atomix White	8.000
3	P7199	AST PC Atomix Black	0.360
4	P7206	AST PC Atomix Violet	0.200
5	P7203	AST PC Atomix Blue 1500	1.000
TOTAL			100%

PANTONE® 647 C

1	P7218	AST PC Atomix Opaque Mix Base	92.930
2	P7217	AST PC Atomix White	3.500
3	P7199	AST PC Atomix Black	0.530
4	P7206	AST PC Atomix Violet	0.240
5	P7203	AST PC Atomix Blue 1500	2.800
TOTAL			100%

PANTONE® 648 C

1	P7218	AST PC Atomix Opaque Mix Base	85.250
2	P7199	AST PC Atomix Black	0.350
3	P7204	AST PC Atomix Blue B	14.400
TOTAL			100%

PANTONE® 649 C

1	P7218	AST PC Atomix Opaque Mix Base	80.950
2	P7217	AST PC Atomix White	18.800
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	0.180
4	P7199	AST PC Atomix Black	0.020
5	P7203	AST PC Atomix Blue 1500	0.050
TOTAL			100%

PANTONE® 650 C

1	P7218	AST PC Atomix Opaque Mix Base	79.570
2	P7217	AST PC Atomix White	20.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	0.320
4	P7199	AST PC Atomix Black	0.030
5	P7203	AST PC Atomix Blue 1500	0.080
TOTAL			100%

PANTONE® 651 C

1	P7218	AST PC Atomix Opaque Mix Base	89.230
2	P7217	AST PC Atomix White	9.700
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	0.750
4	P7199	AST PC Atomix Black	0.090
5	P7203	AST PC Atomix Blue 1500	0.230
TOTAL			100%

PANTONE® 652 C

1	P7218	AST PC Atomix Opaque Mix Base	80.580
2	P7217	AST PC Atomix White	16.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	2.400
4	P7199	AST PC Atomix Black	0.220
5	P7203	AST PC Atomix Blue 1500	0.800
TOTAL			100%

PANTONE® 653 C

1	P7218	AST PC Atomix Opaque Mix Base	87.100
2	P7217	AST PC Atomix White	4.900
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	4.000
4	P7199	AST PC Atomix Black	0.500
5	P7203	AST PC Atomix Blue 1500	3.500
TOTAL			100%

PANTONE® 654 C

1	P7218	AST PC Atomix Opaque Mix Base	77.720
2	P7217	AST PC Atomix White	2.500
3	P7199	AST PC Atomix Black	0.480
4	P7203	AST PC Atomix Blue 1500	3.900
5	P7204	AST PC Atomix Blue B	15.400
TOTAL			100%

PANTONE® 655 C

1	P7218	AST PC Atomix Opaque Mix Base	82.600
2	P7199	AST PC Atomix Black	0.600
3	P7203	AST PC Atomix Blue 1500	0.800
4	P7204	AST PC Atomix Blue B	16.000
TOTAL			100%

PANTONE® 656 C

1	P7218	AST PC Atomix Opaque Mix Base	79.560
2	P7217	AST PC Atomix White	20.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	0.370
4	P7204	AST PC Atomix Blue B	0.070
TOTAL			100%

PANTONE® 657 C

1	P7218	AST PC Atomix Opaque Mix Base	80.750
2	P7217	AST PC Atomix White	18.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	0.100
4	P7203	AST PC Atomix Blue 1500	0.050
5	P7213	AST PC Atomix Blue RQ	1.100
TOTAL			100%

PANTONE® 658 C

1	P7218	AST PC Atomix Opaque Mix Base	81.100
2	P7217	AST PC Atomix White	17.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	0.200
4	P7203	AST PC Atomix Blue 1500	0.100
5	P7213	AST PC Atomix Blue RQ	1.600
TOTAL			100%

PANTONE® 659 C

1	P7218	AST PC Atomix Opaque Mix Base	79.740
2	P7217	AST PC Atomix White	17.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	2.400
4	P7199	AST PC Atomix Black	0.020
5	P7203	AST PC Atomix Blue 1500	0.840
TOTAL			100%

PANTONE® 660 C

1	P7218	AST PC Atomix Opaque Mix Base	83.200
2	P7217	AST PC Atomix White	7.400
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	6.000
4	P7204	AST PC Atomix Blue B	3.400
TOTAL			100%

PANTONE® 661 C

1	P7218	AST PC Atomix Opaque Mix Base	89.660
2	P7217	AST PC Atomix White	2.600
3	P7206	AST PC Atomix Violet	0.340
4	P7203	AST PC Atomix Blue 1500	7.400
TOTAL			100%

PANTONE® 662 C

1	P7218	AST PC Atomix Opaque Mix Base	88.450
2	P7206	AST PC Atomix Violet	0.350
3	P7203	AST PC Atomix Blue 1500	11.200
TOTAL			100%

PANTONE® 663 C

1	P7218	AST PC Atomix Opaque Mix Base	79.950
2	P7217	AST PC Atomix White	20.000
3	P7203	AST PC Atomix Blue 1500	0.020
4	P7211	AST PC Atomix Magenta MX	0.030
TOTAL			100%

PANTONE® 664 C

1	P7218	AST PC Atomix Opaque Mix Base	79.920
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.010
4	P7203	AST PC Atomix Blue 1500	0.020
5	P7211	AST PC Atomix Magenta MX	0.050
TOTAL			100%

PANTONE® 665 C

1	P7218	AST PC Atomix Opaque Mix Base	79.560
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.120
4	P7203	AST PC Atomix Blue 1500	0.080
5	P7211	AST PC Atomix Magenta MX	0.240
TOTAL			100%

PANTONE® 666 C

1	P7218	AST PC Atomix Opaque Mix Base	78.580
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.300
4	P7203	AST PC Atomix Blue 1500	0.220
5	P7211	AST PC Atomix Magenta MX	0.900
TOTAL			100%

PANTONE® 667 C

1	P7218	AST PC Atomix Opaque Mix Base	79.190
2	P7217	AST PC Atomix White	16.000
3	P7199	AST PC Atomix Black	0.570
4	P7203	AST PC Atomix Blue 1500	0.820
5	P7211	AST PC Atomix Magenta MX	3.420
TOTAL			100%

PANTONE® 668 C

1	P7218	AST PC Atomix Opaque Mix Base	84.100
2	P7217	AST PC Atomix White	8.000
3	P7199	AST PC Atomix Black	0.350
4	P7203	AST PC Atomix Blue 1500	1.450
5	P7211	AST PC Atomix Magenta MX	6.100
TOTAL			100%

PANTONE® 669 C

1	P7218	AST PC Atomix Opaque Mix Base	78.000
2	P7217	AST PC Atomix White	5.600
3	P7199	AST PC Atomix Black	0.400
4	P7206	AST PC Atomix Violet	9.200
5	P7211	AST PC Atomix Magenta MX	6.800
TOTAL			100%

PANTONE® 670 C

1	P7218	AST PC Atomix Opaque Mix Base	79.840
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.020
4	P7206	AST PC Atomix Violet	0.010
5	P7211	AST PC Atomix Magenta MX	0.130
TOTAL			100%

PANTONE® 671 C

1	P7218	AST PC Atomix Opaque Mix Base	79.590
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.030
4	P7211	AST PC Atomix Magenta MX	0.380
TOTAL			100%

PANTONE® 672 C

1	P7218	AST PC Atomix Opaque Mix Base	78.880
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.050
4	P7206	AST PC Atomix Violet	0.020
5	P7211	AST PC Atomix Magenta MX	1.050
TOTAL			100%

PANTONE® 673 C

1	P7218	AST PC Atomix Opaque Mix Base	78.220
2	P7217	AST PC Atomix White	19.500
3	P7199	AST PC Atomix Black	0.050
4	P7206	AST PC Atomix Violet	0.030
5	P7211	AST PC Atomix Magenta MX	2.200
TOTAL			100%

PANTONE® 674 C

1	P7218	AST PC Atomix Opaque Mix Base	83.180
2	P7217	AST PC Atomix White	12.000
3	P7206	AST PC Atomix Violet	0.220
4	P7211	AST PC Atomix Magenta MX	4.600
TOTAL			100%

PANTONE® 675 C

1	P7218	AST PC Atomix Opaque Mix Base	72.250
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	24.800
3	P7213	AST PC Atomix Blue RQ	1.900
4	P7211	AST PC Atomix Magenta MX	1.050
TOTAL			100%

PANTONE® 676 C

1	P7218	AST PC Atomix Opaque Mix Base	69.750
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	28.000
3	P7206	AST PC Atomix Violet	0.250
4	P7211	AST PC Atomix Magenta MX	2.000
TOTAL			100%

PANTONE® 677 C

1	P7218	AST PC Atomix Opaque Mix Base	79.830
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.050
4	P7211	AST PC Atomix Magenta MX	0.120
TOTAL			100%

PANTONE® 678 C

1	P7218	AST PC Atomix Opaque Mix Base	79.700
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.080
4	P7206	AST PC Atomix Violet	0.020
5	P7211	AST PC Atomix Magenta MX	0.200
TOTAL			100%

PANTONE® 679 C

1	P7218	AST PC Atomix Opaque Mix Base	79.660
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.060
4	P7206	AST PC Atomix Violet	0.040
5	P7211	AST PC Atomix Magenta MX	0.240
TOTAL			100%

PANTONE® 680 C

1	P7218	AST PC Atomix Opaque Mix Base	78.370
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.180
4	P7211	AST PC Atomix Magenta MX	1.400
5	P8258	AST PC Atomix Yellow II	0.050
TOTAL			100%

PANTONE® 681 C

1	P7218	AST PC Atomix Opaque Mix Base	86.780
2	P7217	AST PC Atomix White	10.000
3	P7199	AST PC Atomix Black	0.360
4	P7211	AST PC Atomix Magenta MX	2.800
5	P8258	AST PC Atomix Yellow II	0.060
TOTAL			100%

PANTONE® 682 C

1	P7218	AST PC Atomix Opaque Mix Base	92.930
2	P7217	AST PC Atomix White	2.700
3	P7199	AST PC Atomix Black	0.330
4	P7206	AST PC Atomix Violet	0.040
5	P7211	AST PC Atomix Magenta MX	4.000
TOTAL			100%

PANTONE® 683 C

1	P7218	AST PC Atomix Opaque Mix Base	93.830
2	P7217	AST PC Atomix White	1.000
3	P7199	AST PC Atomix Black	0.320
4	P7206	AST PC Atomix Violet	0.050
5	P7211	AST PC Atomix Magenta MX	4.800
TOTAL			100%

PANTONE® 684 C

1	P7218	AST PC Atomix Opaque Mix Base	79.690
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.040
4	P7211	AST PC Atomix Magenta MX	0.230
5	P7208	AST PC Atomix Lemon MX	0.040
TOTAL			100%

PANTONE® 685 C

1	P7218	AST PC Atomix Opaque Mix Base	79.370
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.100
4	P7211	AST PC Atomix Magenta MX	0.500
5	P7208	AST PC Atomix Lemon MX	0.030
TOTAL			100%

PANTONE® 692 C

1	P7218	AST PC Atomix Opaque Mix Base	79.650
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.050
4	P7211	AST PC Atomix Magenta MX	0.240
5	P7208	AST PC Atomix Lemon MX	0.060
TOTAL			100%

PANTONE® 686 C

1	P7218	AST PC Atomix Opaque Mix Base	85.460
2	P7217	AST PC Atomix White	13.600
3	P7199	AST PC Atomix Black	0.100
4	P7211	AST PC Atomix Magenta MX	0.800
5	P7208	AST PC Atomix Lemon MX	0.040
TOTAL			100%

PANTONE® 693 C

1	P7218	AST PC Atomix Opaque Mix Base	82.650
2	P7217	AST PC Atomix White	16.400
3	P7199	AST PC Atomix Black	0.120
4	P7211	AST PC Atomix Magenta MX	0.630
5	P7208	AST PC Atomix Lemon MX	0.200
TOTAL			100%

PANTONE® 687 C

1	P7218	AST PC Atomix Opaque Mix Base	88.420
2	P7217	AST PC Atomix White	10.000
3	P7199	AST PC Atomix Black	0.180
4	P7211	AST PC Atomix Magenta MX	1.360
5	P7208	AST PC Atomix Lemon MX	0.040
TOTAL			100%

PANTONE® 694 C

1	P7218	AST PC Atomix Opaque Mix Base	89.000
2	P7217	AST PC Atomix White	9.000
3	P7199	AST PC Atomix Black	0.200
4	P7211	AST PC Atomix Magenta MX	1.300
5	P7208	AST PC Atomix Lemon MX	0.500
TOTAL			100%

PANTONE® 688 C

1	P7218	AST PC Atomix Opaque Mix Base	89.480
2	P7217	AST PC Atomix White	7.400
3	P7199	AST PC Atomix Black	0.320
4	P7211	AST PC Atomix Magenta MX	2.800
TOTAL			100%

PANTONE® 695 C

1	P7218	AST PC Atomix Opaque Mix Base	92.160
2	P7217	AST PC Atomix White	4.800
3	P7199	AST PC Atomix Black	0.280
4	P7211	AST PC Atomix Magenta MX	2.040
5	P7208	AST PC Atomix Lemon MX	0.720
TOTAL			100%

PANTONE® 689 C

1	P7218	AST PC Atomix Opaque Mix Base	86.260
2	P7217	AST PC Atomix White	5.400
3	P7199	AST PC Atomix Black	0.180
4	P7206	AST PC Atomix Violet	0.560
5	P7211	AST PC Atomix Magenta MX	7.600
TOTAL			100%

PANTONE® 696 C

1	P7218	AST PC Atomix Opaque Mix Base	93.920
2	P7217	AST PC Atomix White	2.600
3	P7199	AST PC Atomix Black	0.280
4	P7211	AST PC Atomix Magenta MX	2.400
5	P7208	AST PC Atomix Lemon MX	0.800
TOTAL			100%

PANTONE® 690 C

1	P7218	AST PC Atomix Opaque Mix Base	92.100
2	P7217	AST PC Atomix White	0.900
3	P7199	AST PC Atomix Black	0.520
4	P7206	AST PC Atomix Violet	0.080
5	P7211	AST PC Atomix Magenta MX	6.400
TOTAL			100%

PANTONE® 697 C

1	P7218	AST PC Atomix Opaque Mix Base	95.110
2	P7217	AST PC Atomix White	0.800
3	P7199	AST PC Atomix Black	0.290
4	P7211	AST PC Atomix Magenta MX	2.800
5	P7208	AST PC Atomix Lemon MX	1.000
TOTAL			100%

PANTONE® 691 C

1	P7218	AST PC Atomix Opaque Mix Base	79.820
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.040
4	P7211	AST PC Atomix Magenta MX	0.120
5	P7208	AST PC Atomix Lemon MX	0.020
TOTAL			100%

PANTONE® 698 C

1	P7218	AST PC Atomix Opaque Mix Base	76.870
2	P7217	AST PC Atomix White	23.000
3	P7199	AST PC Atomix Black	0.020
4	P7211	AST PC Atomix Magenta MX	0.100
5	P7208	AST PC Atomix Lemon MX	0.010
TOTAL			100%

PANTONE® 699 C

1	P7218	AST PC Atomix Opaque Mix Base	79.660
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.010
4	P7211	AST PC Atomix Magenta MX	0.270
5	P7208	AST PC Atomix Lemon MX	0.060
TOTAL			100%

PANTONE® 700 C

1	P7218	AST PC Atomix Opaque Mix Base	84.340
2	P7217	AST PC Atomix White	15.000
3	P7199	AST PC Atomix Black	0.020
4	P7211	AST PC Atomix Magenta MX	0.550
5	P7208	AST PC Atomix Lemon MX	0.090
TOTAL			100%

PANTONE® 701 C

1	P7218	AST PC Atomix Opaque Mix Base	81.840
2	P7217	AST PC Atomix White	16.000
3	P7199	AST PC Atomix Black	0.030
4	P7211	AST PC Atomix Magenta MX	1.630
5	P7208	AST PC Atomix Lemon MX	0.500
TOTAL			100%

PANTONE® 702 C

1	P7218	AST PC Atomix Opaque Mix Base	82.500
2	P7217	AST PC Atomix White	11.200
3	P7199	AST PC Atomix Black	0.100
4	P7211	AST PC Atomix Magenta MX	4.800
5	P7208	AST PC Atomix Lemon MX	1.400
TOTAL			100%

PANTONE® 703 C

1	P7218	AST PC Atomix Opaque Mix Base	80.200
2	P7217	AST PC Atomix White	7.600
3	P7199	AST PC Atomix Black	0.120
4	P7211	AST PC Atomix Magenta MX	9.200
5	P7208	AST PC Atomix Lemon MX	2.880
TOTAL			100%

PANTONE® 704 C

1	P7218	AST PC Atomix Opaque Mix Base	94.600
2	P7199	AST PC Atomix Black	0.100
3	P7211	AST PC Atomix Magenta MX	3.400
4	P7208	AST PC Atomix Lemon MX	1.900
TOTAL			100%

PANTONE® 705 C

1	P7218	AST PC Atomix Opaque Mix Base	77.910
2	P7217	AST PC Atomix White	22.000
3	P7211	AST PC Atomix Magenta MX	0.080
4	P7208	AST PC Atomix Lemon MX	0.010
TOTAL			100%

PANTONE® 706 C

1	P7218	AST PC Atomix Opaque Mix Base	77.250
2	P7217	AST PC Atomix White	22.500
3	P7211	AST PC Atomix Magenta MX	0.210
4	P7208	AST PC Atomix Lemon MX	0.040
TOTAL			100%

PANTONE® 707 C

1	P7218	AST PC Atomix Opaque Mix Base	83.190
2	P7217	AST PC Atomix White	16.200
3	P7211	AST PC Atomix Magenta MX	0.510
4	P7208	AST PC Atomix Lemon MX	0.100
TOTAL			100%

PANTONE® 708 C

1	P7218	AST PC Atomix Opaque Mix Base	82.220
2	P7217	AST PC Atomix White	16.000
3	P7211	AST PC Atomix Magenta MX	1.400
4	P7208	AST PC Atomix Lemon MX	0.380
TOTAL			100%

PANTONE® 709 C

1	P7218	AST PC Atomix Opaque Mix Base	81.550
2	P7217	AST PC Atomix White	13.100
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	2.700
4	P7207	AST PC Atomix Red MX	2.400
5	P7208	AST PC Atomix Lemon MX	0.250
TOTAL			100%

PANTONE® 710 C

1	P7218	AST PC Atomix Opaque Mix Base	86.500
2	P7217	AST PC Atomix White	3.200
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	5.200
4	P7211	AST PC Atomix Magenta MX	3.400
5	P7208	AST PC Atomix Lemon MX	1.700
TOTAL			100%

PANTONE® 711 C

1	P7218	AST PC Atomix Opaque Mix Base	78.050
2	P7217	AST PC Atomix White	2.700
3	P7199	AST PC Atomix Black	0.050
4	P7207	AST PC Atomix Red MX	10.200
5	P8258	AST PC Atomix Yellow II	9.000
TOTAL			100%

PANTONE® 712 C

1	P7218	AST PC Atomix Opaque Mix Base	85.210
2	P7217	AST PC Atomix White	14.000
3	P7211	AST PC Atomix Magenta MX	0.190
4	P7208	AST PC Atomix Lemon MX	0.600
TOTAL			100%

PANTONE® 713 C

1	P7218	AST PC Atomix Opaque Mix Base	82.400
2	P7217	AST PC Atomix White	15.600
3	P8412	AST PC Atomix Fluo Orange DTA FF	0.300
4	P7211	AST PC Atomix Magenta MX	0.300
5	P7208	AST PC Atomix Lemon MX	1.400
TOTAL			100%

PANTONE® 714 C

1	P7218	AST PC Atomix Opaque Mix Base	85.840
2	P7217	AST PC Atomix White	10.000
3	P8412	AST PC Atomix Fluo Orange DTA FF	1.200
4	P7207	AST PC Atomix Red MX	0.360
5	P7208	AST PC Atomix Lemon MX	2.600
TOTAL			100%

PANTONE® 715 C

1	P7218	AST PC Atomix Opaque Mix Base	82.450
2	P7217	AST PC Atomix White	5.000
3	P7207	AST PC Atomix Red MX	0.750
4	P7208	AST PC Atomix Lemon MX	11.800
TOTAL			100%

PANTONE® 716 C

1	P7218	AST PC Atomix Opaque Mix Base	75.350
2	P7217	AST PC Atomix White	2.600
3	P7207	AST PC Atomix Red MX	1.050
4	P7208	AST PC Atomix Lemon MX	21.000
TOTAL			100%

PANTONE® 717 C

1	P7218	AST PC Atomix Opaque Mix Base	78.550
2	P7217	AST PC Atomix White	1.000
3	P7207	AST PC Atomix Red MX	1.450
4	P7208	AST PC Atomix Lemon MX	19.000
TOTAL			100%

PANTONE® 718 C

1	P7218	AST PC Atomix Opaque Mix Base	89.850
2	P7199	AST PC Atomix Black	0.050
3	P7207	AST PC Atomix Red MX	0.500
4	P8258	AST PC Atomix Yellow II	9.600
TOTAL			100%

PANTONE® 719 C

1	P7218	AST PC Atomix Opaque Mix Base	78.040
2	P7217	AST PC Atomix White	21.000
3	P7199	AST PC Atomix Black	0.030
4	P7207	AST PC Atomix Red MX	0.230
5	P7208	AST PC Atomix Lemon MX	0.700
TOTAL			100%

PANTONE® 720 C

1	P7218	AST PC Atomix Opaque Mix Base	88.870
2	P7217	AST PC Atomix White	10.000
3	P7199	AST PC Atomix Black	0.030
4	P7207	AST PC Atomix Red MX	0.250
5	P7208	AST PC Atomix Lemon MX	0.850
TOTAL			100%

PANTONE® 721 C

1	P7218	AST PC Atomix Opaque Mix Base	85.890
2	P7217	AST PC Atomix White	11.500
3	P7199	AST PC Atomix Black	0.060
4	P7207	AST PC Atomix Red MX	0.550
5	P7208	AST PC Atomix Lemon MX	2.000
TOTAL			100%

PANTONE® 722 C

1	P7218	AST PC Atomix Opaque Mix Base	91.340
2	P7217	AST PC Atomix White	4.000
3	P7199	AST PC Atomix Black	0.120
4	P7207	AST PC Atomix Red MX	0.540
5	P8258	AST PC Atomix Yellow II	4.000
TOTAL			100%

PANTONE® 723 C

1	P7218	AST PC Atomix Opaque Mix Base	90.760
2	P7217	AST PC Atomix White	0.600
3	P7199	AST PC Atomix Black	0.160
4	P7207	AST PC Atomix Red MX	0.480
5	P8258	AST PC Atomix Yellow II	8.000
TOTAL			100%

PANTONE® 724 C

1	P7218	AST PC Atomix Opaque Mix Base	91.160
2	P7199	AST PC Atomix Black	0.200
3	P7207	AST PC Atomix Red MX	0.640
4	P8258	AST PC Atomix Yellow II	8.000
TOTAL			100%

PANTONE® 725 C

1	P7218	AST PC Atomix Opaque Mix Base	90.290
2	P7199	AST PC Atomix Black	0.310
3	P7207	AST PC Atomix Red MX	0.900
4	P8258	AST PC Atomix Yellow II	8.500
TOTAL			100%

PANTONE® 726 C

1	P7218	AST PC Atomix Opaque Mix Base	79.090
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.050
4	P7207	AST PC Atomix Red MX	0.200
5	P7208	AST PC Atomix Lemon MX	0.660
TOTAL			100%

PANTONE® 727 C

1	P7218	AST PC Atomix Opaque Mix Base	79.570
2	P7217	AST PC Atomix White	18.200
3	P7199	AST PC Atomix Black	0.130
4	P7207	AST PC Atomix Red MX	0.500
5	P7208	AST PC Atomix Lemon MX	1.600
TOTAL			100%

PANTONE® 728 C

1	P7218	AST PC Atomix Opaque Mix Base	85.960
2	P7217	AST PC Atomix White	11.500
3	P7199	AST PC Atomix Black	0.150
4	P7207	AST PC Atomix Red MX	0.590
5	P7208	AST PC Atomix Lemon MX	1.800
TOTAL			100%

PANTONE® 729 C

1	P7218	AST PC Atomix Opaque Mix Base	84.700
2	P7217	AST PC Atomix White	10.000
3	P7199	AST PC Atomix Black	0.290
4	P7211	AST PC Atomix Magenta MX	1.010
5	P8258	AST PC Atomix Yellow II	4.000
TOTAL			100%

PANTONE® 730 C

1	P7218	AST PC Atomix Opaque Mix Base	85.730
2	P7217	AST PC Atomix White	4.000
3	P7199	AST PC Atomix Black	0.370
4	P7207	AST PC Atomix Red MX	1.000
5	P8258	AST PC Atomix Yellow II	8.900
TOTAL			100%

PANTONE® 731 C

1	P7218	AST PC Atomix Opaque Mix Base	92.140
2	P7199	AST PC Atomix Black	0.360
3	P7207	AST PC Atomix Red MX	0.700
4	P8258	AST PC Atomix Yellow II	6.800
TOTAL			100%

PANTONE® 732 C

1	P7218	AST PC Atomix Opaque Mix Base	90.670
2	P7199	AST PC Atomix Black	0.530
3	P7211	AST PC Atomix Magenta MX	1.200
4	P8258	AST PC Atomix Yellow II	7.600
TOTAL			100%

PANTONE® 7401 C

1	P7218	AST PC Atomix Opaque Mix Base	79.500
2	P7217	AST PC Atomix White	20.000
3	P7211	AST PC Atomix Magenta MX	0.020
4	P8258	AST PC Atomix Yellow II	0.480
TOTAL			100%

PANTONE® 7402 C

1	P7218	AST PC Atomix Opaque Mix Base	79.870
2	P7217	AST PC Atomix White	19.200
3	P7213	AST PC Atomix Blue RQ	0.150
4	P7207	AST PC Atomix Red MX	0.010
5	P8258	AST PC Atomix Yellow II	0.770
TOTAL			100%

PANTONE® 7403 C

1	P7218	AST PC Atomix Opaque Mix Base	78.150
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.030
4	P7207	AST PC Atomix Red MX	0.020
5	P8258	AST PC Atomix Yellow II	1.800
TOTAL			100%

PANTONE® 7404 C

1	P7218	AST PC Atomix Opaque Mix Base	84.900
2	P7217	AST PC Atomix White	12.000
3	P8258	AST PC Atomix Yellow II	0.500
4	P7208	AST PC Atomix Lemon MX	2.600
TOTAL			100%

PANTONE® 7405 C

1	P7218	AST PC Atomix Opaque Mix Base	79.490
2	P7217	AST PC Atomix White	6.000
3	P7199	AST PC Atomix Black	0.030
4	P8258	AST PC Atomix Yellow II	1.800
5	P7208	AST PC Atomix Lemon MX	12.680
TOTAL			100%

PANTONE® 7406 C

1	P7218	AST PC Atomix Opaque Mix Base	93.870
2	P7217	AST PC Atomix White	1.400
3	P7199	AST PC Atomix Black	0.030
4	P8258	AST PC Atomix Yellow II	3.000
5	P7208	AST PC Atomix Lemon MX	1.700
TOTAL			100%

PANTONE® 7407 C

1	P7218	AST PC Atomix Opaque Mix Base	83.800
2	P7217	AST PC Atomix White	11.000
3	P7199	AST PC Atomix Black	0.150
4	P7207	AST PC Atomix Red MX	0.250
5	P8258	AST PC Atomix Yellow II	4.800
TOTAL			100%

PANTONE® 7408 C

1	P7218	AST PC Atomix Opaque Mix Base	78.360
2	P7217	AST PC Atomix White	5.200
3	P7199	AST PC Atomix Black	0.040
4	P8258	AST PC Atomix Yellow II	9.600
5	P7208	AST PC Atomix Lemon MX	6.800
TOTAL			100%

PANTONE® 7409 C

1	P7218	AST PC Atomix Opaque Mix Base	78.720
2	P7217	AST PC Atomix White	7.000
3	P7199	AST PC Atomix Black	0.030
4	P7207	AST PC Atomix Red MX	0.250
5	P7208	AST PC Atomix Lemon MX	14.000
TOTAL			100%

PANTONE® 7410 C

1	P7218	AST PC Atomix Opaque Mix Base	85.240
2	P7217	AST PC Atomix White	11.600
3	P7211	AST PC Atomix Magenta MX	0.560
4	P8258	AST PC Atomix Yellow II	2.600
TOTAL			100%

PANTONE® 7411 C

1	P7218	AST PC Atomix Opaque Mix Base	89.550
2	P7217	AST PC Atomix White	6.600
3	P7199	AST PC Atomix Black	0.050
4	P7207	AST PC Atomix Red MX	0.300
5	P8258	AST PC Atomix Yellow II	3.500
TOTAL			100%

PANTONE® 7412 C

1	P7218	AST PC Atomix Opaque Mix Base	89.910
2	P7217	AST PC Atomix White	2.000
3	P7199	AST PC Atomix Black	0.090
4	P7207	AST PC Atomix Red MX	0.500
5	P8258	AST PC Atomix Yellow II	7.500
TOTAL			100%

PANTONE® 7413 C

1	P7218	AST PC Atomix Opaque Mix Base	88.840
2	P7217	AST PC Atomix White	2.800
3	P7199	AST PC Atomix Black	0.040
4	P7207	AST PC Atomix Red MX	0.320
5	P8258	AST PC Atomix Yellow II	8.000
TOTAL			100%

PANTONE® 7414 C

1	P7218	AST PC Atomix Opaque Mix Base	91.250
2	P7217	AST PC Atomix White	1.600
3	P7199	AST PC Atomix Black	0.120
4	P7207	AST PC Atomix Red MX	0.630
5	P8258	AST PC Atomix Yellow II	6.400
TOTAL			100%

PANTONE® 7415 C

1	P7218	AST PC Atomix Opaque Mix Base	79.280
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.020
4	P7211	AST PC Atomix Magenta MX	0.300
5	P7208	AST PC Atomix Lemon MX	0.400
TOTAL			100%

PANTONE® 7416 C

1	P7218	AST PC Atomix Opaque Mix Base	79.550
2	P7217	AST PC Atomix White	11.500
3	P7207	AST PC Atomix Red MX	2.550
4	P7208	AST PC Atomix Lemon MX	6.400
TOTAL			100%

PANTONE® 7417 C

1	P7218	AST PC Atomix Opaque Mix Base	78.000
2	P7217	AST PC Atomix White	6.200
3	P7207	AST PC Atomix Red MX	4.000
4	P7208	AST PC Atomix Lemon MX	11.800
TOTAL			100%

PANTONE® 7418 C

1	P7218	AST PC Atomix Opaque Mix Base	83.820
2	P7217	AST PC Atomix White	7.600
3	P7199	AST PC Atomix Black	0.080
4	P7211	AST PC Atomix Magenta MX	4.900
5	P7208	AST PC Atomix Lemon MX	3.600
TOTAL			100%

PANTONE® 7419 C

1	P7218	AST PC Atomix Opaque Mix Base	73.050
2	P7217	AST PC Atomix White	11.500
3	P7199	AST PC Atomix Black	0.350
4	P7211	AST PC Atomix Magenta MX	11.200
5	P7208	AST PC Atomix Lemon MX	3.900
TOTAL			100%

PANTONE® 7420 C

1	P7218	AST PC Atomix Opaque Mix Base	84.400
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	7.000
3	P7199	AST PC Atomix Black	0.200
4	P7211	AST PC Atomix Magenta MX	7.700
5	P7208	AST PC Atomix Lemon MX	0.700
TOTAL			100%

PANTONE® 7421 C

1	P7218	AST PC Atomix Opaque Mix Base	79.050
2	P7217	AST PC Atomix White	0.500
3	P7199	AST PC Atomix Black	0.940
4	P7211	AST PC Atomix Magenta MX	10.790
5	P7207	AST PC Atomix Red MX	8.720
TOTAL			100%

PANTONE® 7422 C

1	P7218	AST PC Atomix Opaque Mix Base	79.810
2	P7217	AST PC Atomix White	20.000
3	P7211	AST PC Atomix Magenta MX	0.160
4	P7208	AST PC Atomix Lemon MX	0.030
TOTAL			100%

PANTONE® 7423 C

1	P7218	AST PC Atomix Opaque Mix Base	81.680
2	P7217	AST PC Atomix White	12.800
3	P7211	AST PC Atomix Magenta MX	4.800
4	P7208	AST PC Atomix Lemon MX	0.720
TOTAL			100%

PANTONE® 7424 C

1	P7218	AST PC Atomix Opaque Mix Base	84.080
2	P7217	AST PC Atomix White	8.520
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	2.200
4	P7211	AST PC Atomix Magenta MX	5.200
TOTAL			100%

PANTONE® 7425 C

1	P7218	AST PC Atomix Opaque Mix Base	86.580
2	P7217	AST PC Atomix White	2.000
3	P7199	AST PC Atomix Black	0.070
4	P7211	AST PC Atomix Magenta MX	10.800
5	P7208	AST PC Atomix Lemon MX	0.550
TOTAL			100%

PANTONE® 7426 C

1	P7218	AST PC Atomix Opaque Mix Base	85.970
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	6.400
3	P7199	AST PC Atomix Black	0.080
4	P7211	AST PC Atomix Magenta MX	7.500
5	P7208	AST PC Atomix Lemon MX	0.050
TOTAL			100%

PANTONE® 7427 C

1	P7218	AST PC Atomix Opaque Mix Base	85.040
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	5.600
3	P7199	AST PC Atomix Black	0.160
4	P7211	AST PC Atomix Magenta MX	6.800
5	P7208	AST PC Atomix Lemon MX	2.400
TOTAL			100%

PANTONE® 7428 C

1	P7218	AST PC Atomix Opaque Mix Base	79.600
2	P7217	AST PC Atomix White	0.800
3	P7199	AST PC Atomix Black	1.100
4	P7211	AST PC Atomix Magenta MX	14.000
5	P7207	AST PC Atomix Red MX	4.500
TOTAL			100%

PANTONE® 7429 C

1	P7218	AST PC Atomix Opaque Mix Base	79.440
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.060
4	P7211	AST PC Atomix Magenta MX	0.450
5	P7208	AST PC Atomix Lemon MX	0.050
TOTAL			100%

PANTONE® 7430 C

1	P7218	AST PC Atomix Opaque Mix Base	82.470
2	P7217	AST PC Atomix White	16.500
3	P7199	AST PC Atomix Black	0.100
4	P7211	AST PC Atomix Magenta MX	0.850
5	P7208	AST PC Atomix Lemon MX	0.080
TOTAL			100%

PANTONE® 7431 C

1	P7218	AST PC Atomix Opaque Mix Base	85.400
2	P7217	AST PC Atomix White	12.000
3	P7199	AST PC Atomix Black	0.180
4	P7211	AST PC Atomix Magenta MX	2.200
5	P7208	AST PC Atomix Lemon MX	0.220
TOTAL			100%

PANTONE® 7432 C

1	P7218	AST PC Atomix Opaque Mix Base	88.380
2	P7217	AST PC Atomix White	6.600
3	P7199	AST PC Atomix Black	0.270
4	P7211	AST PC Atomix Magenta MX	4.400
5	P7208	AST PC Atomix Lemon MX	0.350
TOTAL			100%

PANTONE® 7433 C

1	P7218	AST PC Atomix Opaque Mix Base	80.450
2	P7217	AST PC Atomix White	7.000
3	P7199	AST PC Atomix Black	0.250
4	P7211	AST PC Atomix Magenta MX	11.850
5	P8258	AST PC Atomix Yellow II	0.450
TOTAL			100%

PANTONE® 7434 C

1	P7218	AST PC Atomix Opaque Mix Base	77.000
2	P7217	AST PC Atomix White	6.500
3	P7199	AST PC Atomix Black	0.300
4	P7211	AST PC Atomix Magenta MX	15.500
5	P8258	AST PC Atomix Yellow II	0.700
TOTAL			100%

PANTONE® 7435 C

1	P7218	AST PC Atomix Opaque Mix Base	90.450
2	P7217	AST PC Atomix White	1.200
3	P7199	AST PC Atomix Black	0.350
4	P7211	AST PC Atomix Magenta MX	8.000
TOTAL			100%

PANTONE® 7436 C

1	P7218	AST PC Atomix Opaque Mix Base	79.690
2	P7217	AST PC Atomix White	20.000
3	P7213	AST PC Atomix Blue RQ	0.230
4	P7211	AST PC Atomix Magenta MX	0.080
TOTAL			100%

PANTONE® 7437 C

1	P7218	AST PC Atomix Opaque Mix Base	80.400
2	P7217	AST PC Atomix White	19.200
3	P7199	AST PC Atomix Black	0.040
4	P7206	AST PC Atomix Violet	0.160
5	P7211	AST PC Atomix Magenta MX	0.200
TOTAL			100%

PANTONE® 7438 C

1	P7218	AST PC Atomix Opaque Mix Base	78.120
2	P7217	AST PC Atomix White	14.000
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	5.040
4	P7213	AST PC Atomix Blue RQ	2.720
5	P7211	AST PC Atomix Magenta MX	0.120
TOTAL			100%

PANTONE® 7439 C

1	P7218	AST PC Atomix Opaque Mix Base	83.710
2	P7217	AST PC Atomix White	15.200
3	P7199	AST PC Atomix Black	0.120
4	P7206	AST PC Atomix Violet	0.370
5	P7211	AST PC Atomix Magenta MX	0.600
TOTAL			100%

PANTONE® 7440 C

1	P7218	AST PC Atomix Opaque Mix Base	79.100
2	P7217	AST PC Atomix White	18.000
3	P7199	AST PC Atomix Black	0.300
4	P7206	AST PC Atomix Violet	0.600
5	P7211	AST PC Atomix Magenta MX	2.000
TOTAL			100%

PANTONE® 7441 C

1	P7218	AST PC Atomix Opaque Mix Base	86.940
2	P7217	AST PC Atomix White	1.600
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	6.600
4	P7213	AST PC Atomix Blue RQ	4.700
5	P7211	AST PC Atomix Magenta MX	0.160
TOTAL			100%

PANTONE® 7442 C

1	P7218	AST PC Atomix Opaque Mix Base	79.100
2	P7217	AST PC Atomix White	0.400
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	13.100
4	P7213	AST PC Atomix Blue RQ	7.400
TOTAL			100%

PANTONE® 7443 C

1	P7218	AST PC Atomix Opaque Mix Base	79.600
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.010
4	P7206	AST PC Atomix Violet	0.040
5	P7213	AST PC Atomix Blue RQ	0.350
TOTAL			100%

PANTONE® 7444 C

1	P7218	AST PC Atomix Opaque Mix Base	79.600
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.090
4	P7206	AST PC Atomix Violet	0.220
5	P7203	AST PC Atomix Blue 1500	0.090
TOTAL			100%

PANTONE® 7445 C

1	P7218	AST PC Atomix Opaque Mix Base	79.230
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.310
4	P7206	AST PC Atomix Violet	0.400
5	P7203	AST PC Atomix Blue 1500	0.060
TOTAL			100%

PANTONE® 7446 C

1	P7218	AST PC Atomix Opaque Mix Base	78.050
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.200
4	P7206	AST PC Atomix Violet	1.470
5	P7203	AST PC Atomix Blue 1500	0.280
TOTAL			100%

PANTONE® 7447 C

1	P7218	AST PC Atomix Opaque Mix Base	93.480
2	P7217	AST PC Atomix White	3.200
3	P7199	AST PC Atomix Black	0.670
4	P7206	AST PC Atomix Violet	1.800
5	P7211	AST PC Atomix Magenta MX	0.850
TOTAL			100%

PANTONE® 7448 C

1	P7218	AST PC Atomix Opaque Mix Base	89.400
2	P7217	AST PC Atomix White	2.800
3	P7199	AST PC Atomix Black	2.200
4	P7206	AST PC Atomix Violet	1.400
5	P7211	AST PC Atomix Magenta MX	4.200
TOTAL			100%

PANTONE® 7449 C

1	P7218	AST PC Atomix Opaque Mix Base	85.200
2	P7217	AST PC Atomix White	2.800
3	P7199	AST PC Atomix Black	3.200
4	P7206	AST PC Atomix Violet	0.400
5	P7211	AST PC Atomix Magenta MX	8.400
TOTAL			100%

PANTONE® 7450 C

1	P7218	AST PC Atomix Opaque Mix Base	79.910
2	P7217	AST PC Atomix White	19.900
3	P7199	AST PC Atomix Black	0.060
4	P7206	AST PC Atomix Violet	0.070
5	P7203	AST PC Atomix Blue 1500	0.060
TOTAL			100%

PANTONE® 7451 C

1	P7218	AST PC Atomix Opaque Mix Base	80.700
2	P7217	AST PC Atomix White	18.300
3	P7206	AST PC Atomix Violet	0.350
4	P7204	AST PC Atomix Blue B	0.650
TOTAL			100%

PANTONE® 7458 C

1	P7218	AST PC Atomix Opaque Mix Base	78.920
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.220
4	P7204	AST PC Atomix Blue B	0.860
TOTAL			100%

PANTONE® 7452 C

1	P7218	AST PC Atomix Opaque Mix Base	79.980
2	P7217	AST PC Atomix White	18.800
3	P7206	AST PC Atomix Violet	0.580
4	P7203	AST PC Atomix Blue 1500	0.640
TOTAL			100%

PANTONE® 7459 C

1	P7218	AST PC Atomix Opaque Mix Base	76.930
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.550
4	P7204	AST PC Atomix Blue B	2.500
5	P7208	AST PC Atomix Lemon MX	0.020
TOTAL			100%

PANTONE® 7453 C

1	P7218	AST PC Atomix Opaque Mix Base	78.640
2	P7217	AST PC Atomix White	20.000
3	P7206	AST PC Atomix Violet	0.440
4	P7204	AST PC Atomix Blue B	0.920
TOTAL			100%

PANTONE® 7460 C

1	P7218	AST PC Atomix Opaque Mix Base	97.800
2	P8410	AST PC Atomix Fluo Yellow DTA FF	0.440
3	P7204	AST PC Atomix Blue B	1.760
TOTAL			100%

PANTONE® 7454 C

1	P7218	AST PC Atomix Opaque Mix Base	77.480
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.400
4	P7206	AST PC Atomix Violet	0.520
5	P7204	AST PC Atomix Blue B	1.600
TOTAL			100%

PANTONE® 7461 C

1	P7218	AST PC Atomix Opaque Mix Base	77.220
2	P7217	AST PC Atomix White	14.500
3	P8410	AST PC Atomix Fluo Yellow DTA FF	0.080
4	P7199	AST PC Atomix Black	0.200
5	P7204	AST PC Atomix Blue B	8.000
TOTAL			100%

PANTONE® 7455 C

1	P7218	AST PC Atomix Opaque Mix Base	77.260
2	P7217	AST PC Atomix White	14.640
3	P7199	AST PC Atomix Black	0.120
4	P7206	AST PC Atomix Violet	2.490
5	P7203	AST PC Atomix Blue 1500	5.490
TOTAL			100%

PANTONE® 7462 C

1	P7218	AST PC Atomix Opaque Mix Base	88.530
2	P7217	AST PC Atomix White	3.500
3	P7199	AST PC Atomix Black	0.500
4	P7206	AST PC Atomix Violet	0.070
5	P7204	AST PC Atomix Blue B	7.400
TOTAL			100%

PANTONE® 7456 C

1	P7218	AST PC Atomix Opaque Mix Base	81.890
2	P7217	AST PC Atomix White	15.200
3	P7199	AST PC Atomix Black	0.160
4	P7206	AST PC Atomix Violet	1.500
5	P7203	AST PC Atomix Blue 1500	1.250
TOTAL			100%

PANTONE® 7463 C

1	P7218	AST PC Atomix Opaque Mix Base	86.600
2	P7217	AST PC Atomix White	1.800
3	P7199	AST PC Atomix Black	1.500
4	P7206	AST PC Atomix Violet	0.500
5	P7204	AST PC Atomix Blue B	9.600
TOTAL			100%

PANTONE® 7457 C

1	P7218	AST PC Atomix Opaque Mix Base	79.780
2	P7217	AST PC Atomix White	20.000
3	P8410	AST PC Atomix Fluo Yellow DTA FF	0.030
4	P7199	AST PC Atomix Black	0.040
5	P7204	AST PC Atomix Blue B	0.150
TOTAL			100%

PANTONE® 7464 C

1	P7218	AST PC Atomix Opaque Mix Base	81.220
2	P7217	AST PC Atomix White	18.000
3	P7199	AST PC Atomix Black	0.100
4	P7200	AST PC Atomix Green	0.640
5	P7208	AST PC Atomix Lemon MX	0.040
TOTAL			100%

PANTONE® 7465 C

1	P7218	AST PC Atomix Opaque Mix Base	83.450
2	P7217	AST PC Atomix White	13.700
3	P7199	AST PC Atomix Black	0.090
4	P7200	AST PC Atomix Green	2.700
5	P7208	AST PC Atomix Lemon MX	0.060
TOTAL			100%

PANTONE® 7466 C

1	P7218	AST PC Atomix Opaque Mix Base	95.000
2	P7217	AST PC Atomix White	2.200
3	P8410	AST PC Atomix Fluo Yellow DTA FF	1.600
4	P7204	AST PC Atomix Blue B	1.200
TOTAL			100%

PANTONE® 7467 C

1	P7218	AST PC Atomix Opaque Mix Base	94.000
2	P7217	AST PC Atomix White	1.200
3	P8410	AST PC Atomix Fluo Yellow DTA FF	2.800
4	P7204	AST PC Atomix Blue B	2.000
TOTAL			100%

PANTONE® 7468 C

1	P7218	AST PC Atomix Opaque Mix Base	87.360
2	P7217	AST PC Atomix White	7.000
3	P7199	AST PC Atomix Black	0.360
4	P7204	AST PC Atomix Blue B	4.480
5	P7200	AST PC Atomix Green	0.800
TOTAL			100%

PANTONE® 7469 C

1	P7218	AST PC Atomix Opaque Mix Base	86.900
2	P7217	AST PC Atomix White	5.000
3	P7199	AST PC Atomix Black	0.400
4	P7204	AST PC Atomix Blue B	6.700
5	P7200	AST PC Atomix Green	1.000
TOTAL			100%

PANTONE® 7470 C

1	P7218	AST PC Atomix Opaque Mix Base	84.900
2	P7217	AST PC Atomix White	4.000
3	P7199	AST PC Atomix Black	0.500
4	P7204	AST PC Atomix Blue B	6.000
5	P7200	AST PC Atomix Green	4.600
TOTAL			100%

PANTONE® 7471 C

1	P7218	AST PC Atomix Opaque Mix Base	91.750
2	P7217	AST PC Atomix White	6.700
3	P8410	AST PC Atomix Fluo Yellow DTA FF	1.300
4	P7203	AST PC Atomix Blue 1500	0.250
TOTAL			100%

PANTONE® 7472 C

1	P7218	AST PC Atomix Opaque Mix Base	78.020
2	P7217	AST PC Atomix White	19.000
3	P7199	AST PC Atomix Black	0.280
4	P7204	AST PC Atomix Blue B	0.100
5	P7200	AST PC Atomix Green	2.600
TOTAL			100%

PANTONE® 7473 C

1	P7218	AST PC Atomix Opaque Mix Base	78.210
2	P7217	AST PC Atomix White	15.000
3	P7199	AST PC Atomix Black	0.520
4	P7200	AST PC Atomix Green	6.200
5	P7208	AST PC Atomix Lemon MX	0.070
TOTAL			100%

PANTONE® 7474 C

1	P7218	AST PC Atomix Opaque Mix Base	79.010
2	P7217	AST PC Atomix White	11.000
3	P7199	AST PC Atomix Black	0.490
4	P7204	AST PC Atomix Blue B	4.300
5	P7200	AST PC Atomix Green	5.200
TOTAL			100%

PANTONE® 7475 C

1	P7218	AST PC Atomix Opaque Mix Base	74.050
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	1.950
4	P7204	AST PC Atomix Blue B	0.300
5	P7200	AST PC Atomix Green	3.700
TOTAL			100%

PANTONE® 7476 C

1	P7218	AST PC Atomix Opaque Mix Base	72.160
2	P7217	AST PC Atomix White	11.200
3	P7199	AST PC Atomix Black	3.040
4	P7204	AST PC Atomix Blue B	4.000
5	P7200	AST PC Atomix Green	9.600
TOTAL			100%

PANTONE® 7477 C

1	P7218	AST PC Atomix Opaque Mix Base	75.000
2	P7217	AST PC Atomix White	8.800
3	P7199	AST PC Atomix Black	3.400
4	P7204	AST PC Atomix Blue B	8.000
5	P7200	AST PC Atomix Green	4.800
TOTAL			100%

PANTONE® 7478 C

1	P7218	AST PC Atomix Opaque Mix Base	79.220
2	P7217	AST PC Atomix White	20.000
3	P7200	AST PC Atomix Green	0.620
4	P7208	AST PC Atomix Lemon MX	0.160
TOTAL			100%

PANTONE® 7479 C

1	P7218	AST PC Atomix Opaque Mix Base	95.020
2	P7217	AST PC Atomix White	3.000
3	P7200	AST PC Atomix Green	1.300
4	P7208	AST PC Atomix Lemon MX	0.680
TOTAL			100%

PANTONE® 7480 C

1	P7218	AST PC Atomix Opaque Mix Base	97.800
2	P7200	AST PC Atomix Green	1.750
3	P7208	AST PC Atomix Lemon MX	0.450
TOTAL			100%

PANTONE® 7481 C

1	P7218	AST PC Atomix Opaque Mix Base	95.800
2	P7217	AST PC Atomix White	0.400
3	P8410	AST PC Atomix Fluo Yellow DTA FF	0.800
4	P7200	AST PC Atomix Green	1.600
5	P7208	AST PC Atomix Lemon MX	1.400
TOTAL			100%

PANTONE® 7482 C

1	P7218	AST PC Atomix Opaque Mix Base	89.000
2	P7217	AST PC Atomix White	4.000
3	P7200	AST PC Atomix Green	5.200
4	P7208	AST PC Atomix Lemon MX	1.800
TOTAL			100%

PANTONE® 7483 C

1	P7218	AST PC Atomix Opaque Mix Base	78.850
2	P7217	AST PC Atomix White	3.500
3	P7199	AST PC Atomix Black	1.050
4	P7200	AST PC Atomix Green	8.600
5	P8258	AST PC Atomix Yellow II	8.000
TOTAL			100%

PANTONE® 7484 C

1	P7218	AST PC Atomix Opaque Mix Base	78.240
2	P7217	AST PC Atomix White	4.000
3	P7199	AST PC Atomix Black	1.120
4	P7200	AST PC Atomix Green	13.000
5	P8258	AST PC Atomix Yellow II	3.640
TOTAL			100%

PANTONE® 7485 C

1	P7218	AST PC Atomix Opaque Mix Base	79.640
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.030
4	P7200	AST PC Atomix Green	0.080
5	P8258	AST PC Atomix Yellow II	0.250
TOTAL			100%

PANTONE® 7486 C

1	P7218	AST PC Atomix Opaque Mix Base	80.760
2	P7217	AST PC Atomix White	18.500
3	P7200	AST PC Atomix Green	0.240
4	P7208	AST PC Atomix Lemon MX	0.500
TOTAL			100%

PANTONE® 7487 C

1	P7218	AST PC Atomix Opaque Mix Base	83.090
2	P7217	AST PC Atomix White	14.250
3	P7200	AST PC Atomix Green	0.760
4	P7208	AST PC Atomix Lemon MX	1.900
TOTAL			100%

PANTONE® 7488 C

1	P7218	AST PC Atomix Opaque Mix Base	91.050
2	P7217	AST PC Atomix White	5.700
3	P7200	AST PC Atomix Green	0.800
4	P7208	AST PC Atomix Lemon MX	2.450
TOTAL			100%

PANTONE® 7489 C

1	P7218	AST PC Atomix Opaque Mix Base	80.550
2	P7217	AST PC Atomix White	12.500
3	P7199	AST PC Atomix Black	0.150
4	P7200	AST PC Atomix Green	2.200
5	P8258	AST PC Atomix Yellow II	4.600
TOTAL			100%

PANTONE® 7490 C

1	P7218	AST PC Atomix Opaque Mix Base	82.670
2	P7217	AST PC Atomix White	9.500
3	P7199	AST PC Atomix Black	0.350
4	P7203	AST PC Atomix Blue 1500	0.030
5	P7200	AST PC Atomix Green	1.700
6	P8258	AST PC Atomix Yellow II	5.750
TOTAL			100%

PANTONE® 7491 C

1	P7218	AST PC Atomix Opaque Mix Base	85.310
2	P7217	AST PC Atomix White	4.000
3	P7199	AST PC Atomix Black	0.440
4	P7200	AST PC Atomix Green	1.050
5	P8258	AST PC Atomix Yellow II	9.200
TOTAL			100%

PANTONE® 7492 C

1	P7218	AST PC Atomix Opaque Mix Base	82.860
2	P7217	AST PC Atomix White	16.000
3	P7199	AST PC Atomix Black	0.020
4	P7204	AST PC Atomix Blue B	0.120
5	P8258	AST PC Atomix Yellow II	1.000
TOTAL			100%

PANTONE® 7493 C

1	P7218	AST PC Atomix Opaque Mix Base	78.610
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.120
4	P7204	AST PC Atomix Blue B	0.150
5	P8258	AST PC Atomix Yellow II	1.120
TOTAL			100%

PANTONE® 7494 C

1	P7218	AST PC Atomix Opaque Mix Base	78.320
2	P7217	AST PC Atomix White	19.700
3	P7199	AST PC Atomix Black	0.480
4	P7200	AST PC Atomix Green	0.500
5	P8258	AST PC Atomix Yellow II	1.000
TOTAL			100%

PANTONE® 7495 C

1	P7218	AST PC Atomix Opaque Mix Base	73.440
2	P7217	AST PC Atomix White	17.200
3	P7199	AST PC Atomix Black	0.360
4	P7204	AST PC Atomix Blue B	0.600
5	P8258	AST PC Atomix Yellow II	8.400
TOTAL			100%

PANTONE® 7496 C

1	P7218	AST PC Atomix Opaque Mix Base	86.620
2	P7217	AST PC Atomix White	3.500
3	P7199	AST PC Atomix Black	0.100
4	P7204	AST PC Atomix Blue B	0.580
5	P8258	AST PC Atomix Yellow II	9.200
TOTAL			100%

PANTONE® 7497 C

1	P7218	AST PC Atomix Opaque Mix Base	79.060
2	P7217	AST PC Atomix White	15.400
3	P7199	AST PC Atomix Black	1.800
4	P7211	AST PC Atomix Magenta MX	0.340
5	P8258	AST PC Atomix Yellow II	3.400
TOTAL			100%

PANTONE® 7498 C

1	P7218	AST PC Atomix Opaque Mix Base	90.100
2	P7217	AST PC Atomix White	3.200
3	P7199	AST PC Atomix Black	1.200
4	P7200	AST PC Atomix Green	0.500
5	P8258	AST PC Atomix Yellow II	5.000
TOTAL			100%

PANTONE® 7499 C

1	P7218	AST PC Atomix Opaque Mix Base	79.750
2	P7217	AST PC Atomix White	20.000
3	P7213	AST PC Atomix Blue RQ	0.060
4	P8258	AST PC Atomix Yellow II	0.190
TOTAL			100%

PANTONE® 7500 C

1	P7218	AST PC Atomix Opaque Mix Base	79.300
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.090
4	P7211	AST PC Atomix Magenta MX	0.060
5	P7208	AST PC Atomix Lemon MX	0.550
TOTAL			100%

PANTONE® 7501 C

1	P7218	AST PC Atomix Opaque Mix Base	79.130
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.110
4	P7211	AST PC Atomix Magenta MX	0.110
5	P7208	AST PC Atomix Lemon MX	0.650
TOTAL			100%

PANTONE® 7502 C

1	P7218	AST PC Atomix Opaque Mix Base	80.880
2	P7217	AST PC Atomix White	17.800
3	P7199	AST PC Atomix Black	0.140
4	P7211	AST PC Atomix Magenta MX	0.180
5	P7208	AST PC Atomix Lemon MX	1.000
TOTAL			100%

PANTONE® 7503 C

1	P7218	AST PC Atomix Opaque Mix Base	76.800
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.600
4	P7211	AST PC Atomix Magenta MX	0.200
5	P7208	AST PC Atomix Lemon MX	2.400
TOTAL			100%

PANTONE® 7504 C

1	P7218	AST PC Atomix Opaque Mix Base	84.480
2	P7217	AST PC Atomix White	11.600
3	P7199	AST PC Atomix Black	0.690
4	P7207	AST PC Atomix Red MX	0.880
5	P7208	AST PC Atomix Lemon MX	2.350
TOTAL			100%

PANTONE® 7505 C

1	P7218	AST PC Atomix Opaque Mix Base	76.980
2	P7217	AST PC Atomix White	11.600
3	P7199	AST PC Atomix Black	1.120
4	P7207	AST PC Atomix Red MX	2.250
5	P7208	AST PC Atomix Lemon MX	8.050
TOTAL			100%

PANTONE® 7506 C

1	P7218	AST PC Atomix Opaque Mix Base	79.580
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.010
4	P7211	AST PC Atomix Magenta MX	0.060
5	P7208	AST PC Atomix Lemon MX	0.350
TOTAL			100%

PANTONE® 7507 C

1	P7218	AST PC Atomix Opaque Mix Base	79.290
2	P7217	AST PC Atomix White	20.000
3	P7211	AST PC Atomix Magenta MX	0.110
4	P7208	AST PC Atomix Lemon MX	0.600
TOTAL			100%

PANTONE® 7508 C

1	P7218	AST PC Atomix Opaque Mix Base	78.130
2	P7217	AST PC Atomix White	19.600
3	P7199	AST PC Atomix Black	0.100
4	P7211	AST PC Atomix Magenta MX	0.270
5	P8258	AST PC Atomix Yellow II	1.900
TOTAL			100%

PANTONE® 7509 C

1	P7218	AST PC Atomix Opaque Mix Base	77.670
2	P7217	AST PC Atomix White	18.000
3	P7199	AST PC Atomix Black	0.130
4	P7211	AST PC Atomix Magenta MX	0.400
5	P8258	AST PC Atomix Yellow II	3.800
TOTAL			100%

PANTONE® 7510 C

1	P7218	AST PC Atomix Opaque Mix Base	78.400
2	P7217	AST PC Atomix White	11.600
3	P7199	AST PC Atomix Black	0.200
4	P7211	AST PC Atomix Magenta MX	0.600
5	P8258	AST PC Atomix Yellow II	9.200
TOTAL			100%

PANTONE® 7511 C

1	P7218	AST PC Atomix Opaque Mix Base	86.100
2	P7217	AST PC Atomix White	4.000
3	P7199	AST PC Atomix Black	0.180
4	P7211	AST PC Atomix Magenta MX	0.520
5	P8258	AST PC Atomix Yellow II	9.200
TOTAL			100%

PANTONE® 7512 C

1	P7218	AST PC Atomix Opaque Mix Base	90.480
2	P7199	AST PC Atomix Black	0.160
3	P7211	AST PC Atomix Magenta MX	0.360
4	P8258	AST PC Atomix Yellow II	9.000
TOTAL			100%

PANTONE® 7513 C

1	P7218	AST PC Atomix Opaque Mix Base	81.550
2	P7217	AST PC Atomix White	18.000
3	P7199	AST PC Atomix Black	0.040
4	P7207	AST PC Atomix Red MX	0.200
5	P7208	AST PC Atomix Lemon MX	0.210
TOTAL			100%

PANTONE® 7514 C

1	P7218	AST PC Atomix Opaque Mix Base	83.000
2	P7217	AST PC Atomix White	15.000
3	P7199	AST PC Atomix Black	0.120
4	P7207	AST PC Atomix Red MX	0.580
5	P7208	AST PC Atomix Lemon MX	1.300
TOTAL			100%

PANTONE® 7515 C

1	P7218	AST PC Atomix Opaque Mix Base	77.970
2	P7217	AST PC Atomix White	17.600
3	P7199	AST PC Atomix Black	0.210
4	P7207	AST PC Atomix Red MX	1.220
5	P7208	AST PC Atomix Lemon MX	3.000
TOTAL			100%

PANTONE® 7516 C

1	P7218	AST PC Atomix Opaque Mix Base	90.450
2	P7217	AST PC Atomix White	0.400
3	P7199	AST PC Atomix Black	0.230
4	P7211	AST PC Atomix Magenta MX	0.920
5	P8258	AST PC Atomix Yellow II	8.000
TOTAL			100%

PANTONE® 7517 C

1	P7218	AST PC Atomix Opaque Mix Base	90.770
2	P7199	AST PC Atomix Black	0.280
3	P7211	AST PC Atomix Magenta MX	0.950
4	P8258	AST PC Atomix Yellow II	8.000
TOTAL			100%

PANTONE® 7518 C

1	P7218	AST PC Atomix Opaque Mix Base	78.800
2	P7217	AST PC Atomix White	10.000
3	P7199	AST PC Atomix Black	2.200
4	P7207	AST PC Atomix Red MX	3.600
5	P7208	AST PC Atomix Lemon MX	5.400
TOTAL			100%

PANTONE® 7519 C

1	P7218	AST PC Atomix Opaque Mix Base	79.380
2	P7217	AST PC Atomix White	9.000
3	P7199	AST PC Atomix Black	2.700
4	P7207	AST PC Atomix Red MX	2.720
5	P7208	AST PC Atomix Lemon MX	6.200
TOTAL			100%

PANTONE® 7520 C

1	P7218	AST PC Atomix Opaque Mix Base	81.340
2	P7217	AST PC Atomix White	17.500
3	P7213	AST PC Atomix Blue RQ	0.520
4	P7211	AST PC Atomix Magenta MX	0.290
5	P7208	AST PC Atomix Lemon MX	0.350
TOTAL			100%

PANTONE® 7521 C

1	P7218	AST PC Atomix Opaque Mix Base	76.960
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.280
4	P7207	AST PC Atomix Red MX	0.760
5	P7208	AST PC Atomix Lemon MX	2.000
TOTAL			100%

PANTONE® 7522 C

1	P7218	AST PC Atomix Opaque Mix Base	82.250
2	P7217	AST PC Atomix White	12.400
3	P7199	AST PC Atomix Black	0.290
4	P7207	AST PC Atomix Red MX	2.060
5	P7208	AST PC Atomix Lemon MX	3.000
TOTAL			100%

PANTONE® 7523 C

1	P7218	AST PC Atomix Opaque Mix Base	81.380
2	P7217	AST PC Atomix White	12.500
3	P7199	AST PC Atomix Black	0.470
4	P7207	AST PC Atomix Red MX	2.850
5	P7208	AST PC Atomix Lemon MX	2.800
TOTAL			100%

PANTONE® 7524 C

1	P7218	AST PC Atomix Opaque Mix Base	82.410
2	P7217	AST PC Atomix White	9.400
3	P7199	AST PC Atomix Black	0.480
4	P7207	AST PC Atomix Red MX	3.510
5	P7208	AST PC Atomix Lemon MX	4.200
TOTAL			100%

PANTONE® 7525 C

1	P7218	AST PC Atomix Opaque Mix Base	80.050
2	P7217	AST PC Atomix White	11.200
3	P7199	AST PC Atomix Black	0.750
4	P7207	AST PC Atomix Red MX	1.850
5	P8258	AST PC Atomix Yellow II	6.150
TOTAL			100%

PANTONE® 7526 C

1	P7218	AST PC Atomix Opaque Mix Base	86.120
2	P7199	AST PC Atomix Black	0.280
3	P7207	AST PC Atomix Red MX	1.600
4	P8258	AST PC Atomix Yellow II	12.000
TOTAL			100%

PANTONE® 7527 C

1	P7218	AST PC Atomix Opaque Mix Base	79.870
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.080
4	P7211	AST PC Atomix Magenta MX	0.020
5	P7208	AST PC Atomix Lemon MX	0.030
TOTAL			100%

PANTONE® 7528 C

1	P7218	AST PC Atomix Opaque Mix Base	80.490
2	P7217	AST PC Atomix White	19.000
3	P7199	AST PC Atomix Black	0.190
4	P7211	AST PC Atomix Magenta MX	0.140
5	P7208	AST PC Atomix Lemon MX	0.180
TOTAL			100%

PANTONE® 7529 C

1	P7218	AST PC Atomix Opaque Mix Base	80.110
2	P7217	AST PC Atomix White	19.000
3	P7199	AST PC Atomix Black	0.400
4	P7211	AST PC Atomix Magenta MX	0.230
5	P7208	AST PC Atomix Lemon MX	0.260
TOTAL			100%

PANTONE® 7530 C

1	P7218	AST PC Atomix Opaque Mix Base	81.570
2	P7217	AST PC Atomix White	17.000
3	P7199	AST PC Atomix Black	0.510
4	P7211	AST PC Atomix Magenta MX	0.380
5	P7208	AST PC Atomix Lemon MX	0.540
TOTAL			100%

PANTONE® 7531 C

1	P7218	AST PC Atomix Opaque Mix Base	81.030
2	P7217	AST PC Atomix White	15.000
3	P7199	AST PC Atomix Black	1.150
4	P7211	AST PC Atomix Magenta MX	1.020
5	P7208	AST PC Atomix Lemon MX	1.800
TOTAL			100%

PANTONE® 7532 C

1	P7218	AST PC Atomix Opaque Mix Base	71.960
2	P7217	AST PC Atomix White	15.400
3	P7199	AST PC Atomix Black	2.600
4	P7211	AST PC Atomix Magenta MX	3.240
5	P7208	AST PC Atomix Lemon MX	6.800
TOTAL			100%

PANTONE® 7533 C

1	P7218	AST PC Atomix Opaque Mix Base	92.000
2	P7217	AST PC Atomix White	1.500
3	P7199	AST PC Atomix Black	1.500
4	P7211	AST PC Atomix Magenta MX	1.800
5	P7208	AST PC Atomix Lemon MX	3.200
TOTAL			100%

PANTONE® 7534 C

1	P7218	AST PC Atomix Opaque Mix Base	80.180
2	P7217	AST PC Atomix White	19.500
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	0.080
4	P7199	AST PC Atomix Black	0.140
5	P8258	AST PC Atomix Yellow II	0.100
TOTAL			100%

PANTONE® 7535 C

1	P7218	AST PC Atomix Opaque Mix Base	79.090
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.370
4	P7211	AST PC Atomix Magenta MX	0.070
5	P8258	AST PC Atomix Yellow II	0.470
TOTAL			100%

PANTONE® 7536 C

1	P7218	AST PC Atomix Opaque Mix Base	78.480
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.580
4	P7211	AST PC Atomix Magenta MX	0.110
5	P8258	AST PC Atomix Yellow II	0.830
TOTAL			100%

PANTONE® 7537 C

1	P7218	AST PC Atomix Opaque Mix Base	81.740
2	P7217	AST PC Atomix White	16.000
3	P7199	AST PC Atomix Black	0.370
4	P7213	AST PC Atomix Blue RQ	1.600
5	P8258	AST PC Atomix Yellow II	0.290
TOTAL			100%

PANTONE® 7538 C

1	P7218	AST PC Atomix Opaque Mix Base	77.000
2	P7217	AST PC Atomix White	19.400
3	P7199	AST PC Atomix Black	0.800
4	P7213	AST PC Atomix Blue RQ	2.300
5	P8258	AST PC Atomix Yellow II	0.500
TOTAL			100%

PANTONE® 7539 C

1	P7218	AST PC Atomix Opaque Mix Base	83.430
2	P7217	AST PC Atomix White	14.300
3	P7199	AST PC Atomix Black	1.150
4	P7213	AST PC Atomix Blue RQ	0.600
5	P8258	AST PC Atomix Yellow II	0.520
TOTAL			100%

PANTONE® 7540 C

1	P7218	AST PC Atomix Opaque Mix Base	73.800
2	P7217	AST PC Atomix White	12.000
3	P7199	AST PC Atomix Black	5.600
4	P7213	AST PC Atomix Blue RQ	8.250
5	P8258	AST PC Atomix Yellow II	0.350
TOTAL			100%

PANTONE® 7541 C

1	P7218	AST PC Atomix Opaque Mix Base	79.920
2	P7217	AST PC Atomix White	20.000
3	P7199	AST PC Atomix Black	0.040
4	P7203	AST PC Atomix Blue 1500	0.040
TOTAL			100%

PANTONE® 7542 C

1	P7218	AST PC Atomix Opaque Mix Base	80.790
2	P7217	AST PC Atomix White	18.800
3	P7199	AST PC Atomix Black	0.220
4	P7203	AST PC Atomix Blue 1500	0.150
5	P7208	AST PC Atomix Lemon MX	0.040
TOTAL			100%

PANTONE® 7543 C

1	P7218	AST PC Atomix Opaque Mix Base	76.650
2	P7217	AST PC Atomix White	18.700
3	P7199	AST PC Atomix Black	0.600
4	P7213	AST PC Atomix Blue RQ	4.000
5	P7208	AST PC Atomix Lemon MX	0.050
TOTAL			100%

PANTONE® 7544 C

1	P7218	AST PC Atomix Opaque Mix Base	76.040
2	P7217	AST PC Atomix White	14.500
3	P7199	AST PC Atomix Black	1.400
4	P7213	AST PC Atomix Blue RQ	8.000
5	P7208	AST PC Atomix Lemon MX	0.060
TOTAL			100%

PANTONE® 7545 C

1	P7218	AST PC Atomix Opaque Mix Base	78.900
2	P7217	AST PC Atomix White	11.000
3	P7199	AST PC Atomix Black	6.000
4	P7206	AST PC Atomix Violet	0.200
5	P7203	AST PC Atomix Blue 1500	3.900
TOTAL			100%

PANTONE® 7546 C

1	P7218	AST PC Atomix Opaque Mix Base	84.640
2	P7217	AST PC Atomix White	5.600
3	P7199	AST PC Atomix Black	5.200
4	P7206	AST PC Atomix Violet	0.560
5	P7203	AST PC Atomix Blue 1500	4.000
TOTAL			100%

PANTONE® 7547 C

1	P7218	AST PC Atomix Opaque Mix Base	79.720
2	P7217	AST PC Atomix White	1.400
3	P7199	AST PC Atomix Black	9.200
4	P7206	AST PC Atomix Violet	0.480
5	P7203	AST PC Atomix Blue 1500	9.200
TOTAL			100%

PANTONE® 801 C

1	P7218	AST PC Atomix Opaque Mix Base	96.810
2	P7217	AST PC Atomix White	1.530
3	P8410	AST PC Atomix Fluo Yellow DTA FF	0.400
4	P7204	AST PC Atomix Blue B	1.260
TOTAL			100%

PANTONE® 802 C

1	P7218	AST PC Atomix Opaque Mix Base	79.300
2	P7217	AST PC Atomix White	1.200
3	P8410	AST PC Atomix Fluo Yellow DTA FF	17.000
4	P7200	AST PC Atomix Green	0.550
5	P7208	AST PC Atomix Lemon MX	1.950
TOTAL			100%

PANTONE® 803 C

1	P7218	AST PC Atomix Opaque Mix Base	82.160
2	P7217	AST PC Atomix White	3.320
3	P8412	AST PC Atomix Fluo Orange DTA FF	0.480
4	P8410	AST PC Atomix Fluo Yellow DTA FF	12.600
5	P7208	AST PC Atomix Lemon MX	1.440
TOTAL			100%

PANTONE® 804 C

1	P7218	AST PC Atomix Opaque Mix Base	84.630
2	P7217	AST PC Atomix White	1.600
3	P8412	AST PC Atomix Fluo Orange DTA FF	5.000
4	P8410	AST PC Atomix Fluo Yellow DTA FF	8.160
5	P7208	AST PC Atomix Lemon MX	0.610
TOTAL			100%

PANTONE® 805 C

1	P7218	AST PC Atomix Opaque Mix Base	77.550
2	P7217	AST PC Atomix White	2.800
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	4.900
4	P8412	AST PC Atomix Fluo Orange DTA FF	14.750
TOTAL			100%

PANTONE® 806 C

1	P7218	AST PC Atomix Opaque Mix Base	88.300
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	11.000
3	P8412	AST PC Atomix Fluo Orange DTA FF	0.700
TOTAL			100%

PANTONE® 807 C

1	P7218	AST PC Atomix Opaque Mix Base	87.940
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	12.000
3	P7206	AST PC Atomix Violet	0.060
TOTAL			100%

PANTONE® 808 C

1	P7218	AST PC Atomix Opaque Mix Base	92.280
2	P7217	AST PC Atomix White	4.600
3	P7200	AST PC Atomix Green	3.100
4	P7208	AST PC Atomix Lemon MX	0.020
TOTAL			100%

PANTONE® 809 C

1	P7218	AST PC Atomix Opaque Mix Base	84.950
2	P7217	AST PC Atomix White	1.700
3	P8410	AST PC Atomix Fluo Yellow DTA FF	11.500
4	P7213	AST PC Atomix Blue RQ	0.050
5	P7208	AST PC Atomix Lemon MX	1.800
TOTAL			100%

PANTONE® 810 C

1	P7218	AST PC Atomix Opaque Mix Base	87.000
2	P7217	AST PC Atomix White	0.700
3	P8412	AST PC Atomix Fluo Orange DTA FF	1.750
4	P8410	AST PC Atomix Fluo Yellow DTA FF	9.600
5	P7208	AST PC Atomix Lemon MX	0.950
TOTAL			100%

PANTONE® 811 C

1	P7218	AST PC Atomix Opaque Mix Base	78.800
2	P7217	AST PC Atomix White	2.600
3	P8412	AST PC Atomix Fluo Orange DTA FF	18.000
4	P7213	AST PC Atomix Blue RQ	0.200
5	P7208	AST PC Atomix Lemon MX	0.400
TOTAL			100%

PANTONE® 812 C

1	P7218	AST PC Atomix Opaque Mix Base	90.200
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	7.600
3	P8412	AST PC Atomix Fluo Orange DTA FF	2.200
TOTAL			100%

PANTONE® 813 C

1	P7218	AST PC Atomix Opaque Mix Base	88.190
2	P8411	AST PC Atomix Fluo Fuchsia DTA FF	11.800
3	P7206	AST PC Atomix Violet	0.010
TOTAL			100%

PANTONE® 814 C

1	P7218	AST PC Atomix Opaque Mix Base	81.650
2	P7217	AST PC Atomix White	2.600
3	P8411	AST PC Atomix Fluo Fuchsia DTA FF	6.300
4	P7213	AST PC Atomix Blue RQ	9.450
TOTAL			100%